Nokia AirScale □□□□

□ **RAN Monitor** □□□□□□□

□□

1. □□
2. □□□□
3. □□ WebLM □□
4. □□□□□□□
5. □□□□□□□
6. □□
7. □□□□

□□

□□□ RAN Monitor □□□ Nokia AirScale □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ RAN Monitor □□□□□□□□□□□□ Nokia Web Element Manager (WebLM) □□□□□□□

□□□□□□□□□□□□□□□□□ (PMCADM) □□

□□□□□□□□

□□□ □□ Nokia AirScale □□□□□□□ **Omnitouch** □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

- □□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□□□□
- □□□□□ □□□□□□□□□
- □□□□□□□□□□□□□□□□□□

□□□□□ **Omnitouch** □□□□□□□□□□ **Omnitouch** □□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□ Nokia Counter Reference□□□□□□□□□□□□ Runtime Configuration Guide□

□□□□

□□□□□□□□□□□□□□□□□

- □□□□□ - □□□□□□□□□□
- □□□□□□ - □□□□□□□□□□□□□□□
- **RAN Monitor** □□□□□ - RAN Monitor □□□□ IP □□□□□□
- □□□□□□ - □□□□ Nokia AirScale □□□□□□□

□□□□□□

□□	□	□□
RAN Monitor IP □□	RAN Monitor □□□□ IP	10.179.2.139
RAN Monitor □□	□□□□□ (□□: 9076)	9076
□□□□□	□□□□□□□□	60 □

□□ WebLM □□

□□ 1□□□ Web Element Manager

1. □□□□□□□□□□□

2. □□□□□□□□□□□□

```
http://<base-station-ip>/
```

□

```
https://<base-station-ip>/
```

3. □□□□□□□□□□□□

□□ 2□□□□□□□□

□□□□

1. □□□□□□□□□ **Configuration**
2. □□□□□□□□ **Configuration Management**
3. □□ **Parameter Editor** □□

□□□□□□□□□□□

□□□ □ RAN Monitor □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ `forced` □□□□□□□□□□ TLS □□□

□□ 2□□□ PMCADM □□□□

□□□□□□□□ (□□□) □□

1. □□ **Current BTS configuration**
2. □□ **CURRENT_BTS_CONF-1**
3. □□ **MRBTS-X** (□□ X □□□□□□ ID)
4. □□ **MNL-1** (□□□□)
5. □□ **MNLENT-1** (□□□□□□□)
6. □□ **PMCADM-1** (□□□□□□□□□□)

□□□□□□□□□ PMCADM-1 □□□□□□

□□ 3□□□□□□□□□□

□□□□□ **Structure 1** □□□□□□□□□□□□□□□□□□□□

□□	□□	□□□
TLS □□□□□□□□	□□□□□□□	RSA (□□□□ TLS)
□□□□□□□□□□□□□□	RAN Monitor □ IP □□	□□ RAN Monitor IP (□□□ 10.179.2.139)
□□□□□□□□□□□□□□□	RAN Monitor □□□□□	9076 (□□)
□□□□□□□□□□□	□□□□□□□□	60s (□□□□□□□)
□□ **TLS**	□□□□□□□	false (□□□□□□□)

□□□□□

□□	□□	□□□
SDL □□□□□□□□□	□□□□□□□	1
SDL Nonce	□□□□□□□□□	12345678
□□□□□□□□□□	□□□□ 0 □□□□	false (□□□□□□□□□)

□□ 4□□□□□□□□

□□□□□□□□

1. □□□□□□□ - □□□□ IP □□□□□□□□□
2. □□□□□□□□
    - □□□□□ **Create Plan** □□
    - □□□□□□□□□□
    - □□□□□□□□ ID
3. □□□□□

- □□ **Validate Plan** □□
- □□□□ ID
- □□□□□□
- □□□□□□□□

4. □□□□□

- □□ **Activate Plan** □□
- □□□□ ID
- □□□□
- □□□□□□□□

□□□□XML □□

□□□□□□□□□□□□□□□□□ XML □□ PMCADM □□□□□□□□□□□□□□□□□□□□□□□□

```
<managedObject class="com.nokia.srbts.mnl:PMCADM" distName="MRBTS-
132/MNL-1/MNLENT-1/PMCADM-1" version="MNL25R1_2420_110"
operation="create">
  <p name="act3gppXmlEnrichment">false</p>
  <p name="reportingIntervalPm">5min</p>
  <p name="sdlMaxUploadFileNumber">1</p>
  <p name="sdlPrimaryDestIp">10.179.2.139</p>
  <list name="rTPmCollEntity">
    <item>
      <p name="certTypeForTlsAuth">RSA</p>
      <p name="rTPmCollEntityHost">10.179.2.139</p>
      <p name="rTPmCollEntityPortNum">9076</p>
      <p name="rTPmCollInterval">60s</p>
      <p name="tlsEnabled">false</p>
    </item>
  </list>
</managedObject>
```

XML □□□□□□□□

- `rTPmCollEntityHost` - □□□□□ RAN Monitor IP □□
- `rTPmCollEntityPortNum` - □□□ 9076 (□□ webhook □□)
- `rTPmCollInterval` - □□□□ (□□ 60s)

- `tlsEnabled` - □□□□□□□□ false
- `sdlPrimaryDestIp` - □□□□□ RAN Monitor IP □□

□□□ □ `10.179.2.139` □□□□□□□□ RAN Monitor IP □□□□□□□□□□ ID □□ `MRBTS-132`□

□□□□□□

LNBTS □□□□□□

LNBTS (LTE NodeB) □□□□□□□□□□

□□ **XML** □□□

```
<managedObject class="NOKLTE:LNBTS" distName="MRBTS-XXXX/LNBTS-
XXXX" operation="update">
  <p name="actL1PM">true</p>
</managedObject>
```

□□ **WebLM** □□□

1. □□□ Configuration > Configuration Management > Parameter Editor
2. □□ MRBTS-X > LNBTS-X
3. □□ `actL1PM` □□
4. □□□□□ `true`
5. □□□□□□□□□□□□□

actPCMDReport - □□□□□□□□□□□□

□□	□
□□	actPCMDReport
□□	NOKLTE:LNBTS □□□□
□□	□□□ (true/false)
□□	false
□□	□□□□□□□□

□□□ □□□□□□□□□□ (PCMD) □□□□□□□□□□□□□□□□□□□□

□□ **XML** □□□

```
<managedObject class="NOKLTE:LNBTS" distName="MRBTS-XXXX/LNBTS-
XXXX" operation="update">
  <p name="actPCMDReport">true</p>
</managedObject>
```

PMCADM-1 □□□□

PMCADM (□□□□□□□□□□) □□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□□

- □□□□□□□□□□□□□
- □□□□□□□□□□□□□□
- □□□□□□□□□□□□□□
- □□□□□□□□□□□□□□

PMCADM □□□□

reportingIntervalPm - PM □□□□

□□	□
□□	reportingIntervalPm
□□	com.nokia.srbts.mnl:PMCADM □□□□
□□	□□
□□	5min, 15min, 30min, 60min
□□	5min □ 15min □□□□□□

□□□ □□□□□□□□□□□□□□□□□□□□

```
<managedObject class="com.nokia.srbts.mnl:PMCADM" distName="MRBTS-
XXXX/MNL-1/MNLENT-1/PMCADM-1" operation="update">
  <p name="reportingIntervalPm">5min</p>
</managedObject>
```

□□ **WebLM** □□□

1. □□□ Configuration > Configuration Management > Parameter Editor
2. □□ MRBTS-X > MNL-1 > MNLENT-1 > PMCADM-1
3. □□ `reportingIntervalPm` □□
4. □□□□□□□□□□ (□□□`5min`)
5. □□□□□□□□□□□□

□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□

certTypeForTlsAuth - TLS □□□□□□□

- □□□ □□ (RSA, DSA, ECDSA)
- □□□ □□□□ TLS □□□□□□
- □□□ RSA
- □□□ □□ tlsEnabled = true □□□

rTpmCollEntityHost - □□□□□□

- □□□ IP □□ (IPv4 □ IPv6)
- □□□ □□□□□□□ IP □□
- □□□ □
- □□□ 10.179.2.139
- □□□ □□□□□□□□□□□□□□

rTpmCollEntityPortNum - □□□□□□□

- □□□ □□ (1-65535)
- □□□ □□□□□□□ TCP □□

默认： 9076
备注：必须与 RAN Monitor 配置匹配

rTpmCollInterval - 收集间隔

类型：时间 (秒)
目的：性能数据传输的频率
选项： 15s, 30s, 60s, 300s, 900s, 1800s
默认： 60s
推荐：标准监控为 60s，详细故障排除为 15s

tlsEnabled - 启用 TLS

类型：布尔值 (true/false)
目的：加密传输中的性能数据
默认： false
备注：如果启用，双方需要有效的证书

sdlMaxUploadFileNumber - SDL 最大上传文件数量

类型：整数
目的：最大并发文件上传数量
默认： 1
备注：在高流量环境中增加

sdlNonce - SDL Nonce

类型：字符串 (8 位数字)
目的： SDL 协议安全的唯一标识符
默认： 12345678
备注：可以出于安全目的更改

suppressZeroValueCount - 抑制零值计数器

类型：布尔值 (true/false)
目的：从报告中省略值为零的计数器
默认： false

推荐：保持为 false 以维护完整的数据以进行趋势分析

验证

激活配置后，验证基站是否成功向 RAN Monitor 发送数据。

检查 RAN Monitor Web UI

1. 打开 RAN Monitor Web UI: http://<ran-monitor-ip>:4000/
2. 导航到eNodeB Status页面
3. 在设备列表中找到您的基站
4. 验证状态显示为 Connected (绿色指示)
5. 检查Session显示为Active

预期状态：

状态： Connected (绿色)
会话： Active
地址：与基站 IP 匹配

操作：所有按钮启用

如果状态显示为 Pending：

设备正在尝试注册，但尚未完成身份验证。

可能的原因：

管理器 ID 和注册密钥不匹配
RAN Monitor 未配置为接受此设备
网络连接问题

如果状态显示连接错误：

设备无法到达 RAN Monitor。

可能的原因：

PMCADM 配置中的 IP 地址不正确
网络路由问题
防火墙阻止端口 8080
RAN Monitor 服务未运行

检查数据收集

查看 InfluxDB 状态：

1. 在 RAN Monitor Web UI 中，导航到InfluxDB Status
2. 验证数据点是否在增加
3. 检查 Performance Metrics 计数是否在增长
4. 确认 Last Update 时间戳是最近的

预期指标：

Performance Metrics：计数定期增加
Configuration：存在数据点
Alarms：如果没有活动故障，可能为 0

检查数据保留：

1. 导航到Data Retention Policy页面
2. 找到您的基站
3. 验证Performance Metrics、Configuration和Alarms计数

□□□□

□□□□□□□ RAN Monitor □

□□□ □□□□□□□ eNodeB □□□□

□□□□□□

1. □□□□□□□□□

   ```
   ping <base-station-ip>
   ```

2. □□ **RAN Monitor** □□□

   - □□□□□□□□□ `config/runtime.exs`
   - □□ IP □□□□□□□□
   - □□□□□□□

3. □□ **RAN Monitor** □□□

    - □□□ **Live Logs** □□
    - □□□□□□□
    - □□□□□□□□□□□□□□

4. □□□□□□□□

    - □□□□ WebLM □□ PMCADM-1 □□
    - □□ RAN Monitor IP □□□□
    - □□□□□□□□ 9076

□□□□“Pending”□□

□□□ □□□□□□□□□□□“Pending”

□□□□□□

1. □□□□□□□□□

    - □□ RAN Monitor □□□□□□ ID □□□□□□□□□□
    - □□□□□□□□□□□□□□□

2. □□□□□□□□

    - □□ runtime.exs □□□□
    - □□□□□□/□□□□□□□□□□

3. □□□□□□□□

    - □□□□□□□ 30-60 □
    - □□□□□□□□

□□□□

□□□ “□□□□□□enetunreach”□□□□□

□□□□□□

1. □□□□□□□□

   - □□□□□ RAN Monitor □□□
   - □□□□□□
   - □□ VLAN/subnet □□□□□□□

2. □□□□□□□□□

   - □□□□ 9076 □□□□ (□□□□□□□□□□)
   - □□□□ 8080 □□□□ (□□ SOAP API □□)
   - □□□□ ACL □□□□
   - □□ RAN Monitor □□□□□ iptables □□

3. □□ **RAN Monitor** □□□□□□

```
# □□ SOAP API □ webhook □□
netstat -tlnp | grep -E '8080|9076'
```

RTWP □□ 1 □□□□□

□□□ □□□□□□□□□□ InfluxDB □□□ RTWP □□□ (M8005C306-339)

□□□ LNBTS □□□□ `actL1PM` □□□□□ `false`□□□□□□ 1 □□□□□

□□□□□

1. □□□□□□□□

   - □□□□□□
   - □ LNBTS □□□□ `actL1PM`
   - □□□□ `false`□□□□□□

2. □□□ **1 PM**□

   - □□□□□□ WebLM
   - □□□ MRBTS-X > LNBTS-X
   - □ `actL1PM` □□□ `true`
   - □□□□□□□□□□□□□

3. 激活后验证：

等待下一个收集间隔 (通常为 60 秒)
检查 InfluxDB 中的 M8005C306-309 计数器 RTWP 数据现在应该出现

相关参数：

actPCMDReport - 每通话测量数据 (可能也需要启用)

InfluxDB 中没有指标

症状：设备已连接，但数据库中没有数据

解决方案：

1. 验证收集间隔：

检查 PMCADM-1 rTpmCollInterval 设置
至少等待一个完整的间隔周期
刷新 InfluxDB 状态页面

2. 检查 InfluxDB 连接：

导航到 InfluxDB 状态页面
验证“已连接”指示器为绿色
确认桶名称正确

3. 查看 RAN Monitor 日志：

查找 InfluxDB 写入错误
检查数据解析问题
验证 API 令牌具有写入权限

TLS/证书问题

症状：启用 TLS 时连接失败

□□□□□

1. □□□□□□□□□□□
   - □□□□□□□□□□□□□
   - □□ RAN Monitor □□□□□ CA □□
2. □□□□□□ **TLS**□
   - □ tlsEnabled □□□ false
   - □□□□□□□□□□
   - □□□□□□□□□ TLS
3. □□□□□□□□
   - □□□□□□□□□
   - □□□□□□□□□□
   - □□□□□□□□□

□□□

□□□

- □□□ - □□□ RAN Monitor □□□
- □□□□□□□ - RAN Monitor □□□
- Nokia Counter Reference - □□□□□□□
- Grafana □□ - □□□□□□□□□□□□
- API □□ - □□□□□ REST API □□
- □□□□□□ - □□□□□□□□□

□□□

- **config/runtime.exs** - RAN Monitor □□□

支持

对于本指南未涵盖的问题：

1. 查看 RAN Monitor 应用日志
2. 检查适用于您软件版本的 Nokia 基站文档
3. 验证网络基础设施配置
4. 与网络运营团队咨询

□□□□□□□

□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□□□□

□□

1. □□
2. □□□□□□
3. □□□□□
4. □□□□
5. □□□□□□□
6. □□□□
7. □□□□□□
8. □□□□

□□

□□□□□□“□□”□□□□□□□ AirScale □□□□□□□□□□□□□□RAN Monitor □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□□□□

□□□□ 4G □□□□□□□□□□□□□□□□□□□□□□/□□□□□□□□□□□□□□□/□□□□□□□□□□□□□□□□□□□□

□□□□


Nokia AirScale
Base Station
Detects Issues
Detects Issues
Detects Issues
Detects Issues
Hardware
Sensors
Software
Processes
Configuration
Checks
Connectivity
Monitoring
Temperature, Power,
Fan Status
Process Crash,
Resource Exhaustion
Parameter Mismatch,
License Issue
Connectivity Loss,
Peer Down
Alarm
Event
Push to RAN Monitor
via Webhook
RAN Monitor
Alarm Manager
Store
Alert
InfluxDB
Alarms Measurement
Grafana
Dashboards

□□□□□□

□□□□□□□

□□	□□	□□
□□ **ID**	a1b2c3d4-e5f6-…	□□□□□
□□□	□□□□□□□□□	□□□□□
□□□□	"□□□□□"	□□□□□□
□□□□	"S1 □□□□"	□□□□
□□□□□	/BSC-1/BTS-23/Cell-A	□□□□□□□DN□
□□□□	2025-12-10 14:23:45	□□□□
□□	□□ / □□□	□□□□

□□□□□□□

□□□□



□□□□□□□

```
14:23:45 UTC - □□□□
            └─> □□□□□□□□□□
            └─> □□□□□□“S1 □□□□”□□□□

14:23:47 UTC - □□□□□ RAN Monitor
            └─> NE3S webhook □□□□□
            └─> □□□ InfluxDB
            └─> □□□□□□

14:23:50 UTC - □□□□
            └─> Grafana □□□□
            └─> □ NOC □□□□ Slack □□
            └─> □□ PagerDuty □□

14:24:15 UTC - □□□□□
            └─> NOC □□□□□□□□
            └─> □□□□□□□□□

14:28:35 UTC - □□□□□□□
            └─> □□□□
            └─> □□□□□□
            └─> RAN Monitor □□“□□□”

14:28:36 UTC - □□□□
            └─> □□□□□□□5 □□ 51 □
            └─> □□ SLA □□□□□
            └─> 30 □□□□
```

□□□□□

RAN Monitor □□

□□□□□

□□□ □□□□□□□□□□□□□□□



□□□

- □□□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□
- □□□□□□□□□□S1 □□□
- □□□□□□□□□
- □□□□□□□□

□□□

- □□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□
- □□□□□□□
- □□ SLA □□□□□□□□□□□

□□ **SLA**□ < 15 □□

□□□□□

□□□ □□□□□□□□□□□□



□□□

- □□□□□ < 95% □□ 15 □□
- □□□□□ < 95%
- DL/UL □□□□□□□> 95% □□□□□□
- RLC □□□ > 5%
- □□□□□□□□□
- □□□□□E1/T1 □□□□□

□□□

- □□ NOC □□ + □□□□□
- □□□□□□□□□□
- □□ 30 □□□□□□□□□□□□□□□□
- □□□□□□□□□/□□□□□□□□

□□ **SLA**□ < 30 □□□□

□□□□□

□□□ □□□□□□□□□



□□□

- □□□□□ 95-98%□□□□□□
- □□□□□□□
- □□□□□□□□□
- □□□□□□□
- □□□□□□□□
- □□□□□□< 5 □/□□

□□□

- □□□□□□□□□□□□□
- □□□□□□□□□□□
- □□□□□□□□□□□□□□□□□□□□□□□□□□□□
- □□□□□□□□□□

□□ **SLA**□ □□□□

警告严重性

定义：信息性，监控趋势

示例：

小区可用性 > 98% 但趋势下降
温度/电源在正常范围内但升高
资源利用率在 60-70%
配置不匹配（非关键参数）
新故障类型的首次出现

升级：

仅在仪表板上可见
无自动通知
按节奏手动审核

已清除

定义：先前活动的警报现在已解决

目的：

记录问题已解决
跟踪平均修复时间（MTTR）
启用 SLA 合规报告
识别重复问题

□□□□

□□□□

```
□□□□□□□□□
□□□□□□
  - S1 □□□□□       → MME/SGW □□□□
  - □□□□□□□□     → IP □□□□
  - USIM □□□□□     → HSS □□□□
  - NTP □□□□     → □□□□□□□□□

□□□□□□□□□□□□□□□□□
□□□
  1. □□□□□□□□□□□□□
  2. □□□□□□□□□□□□□□□
  3. □□□□□□□□□□□□□
  4. □□□□□□□□□□□□
```

□□□□□□□

```
□□□□□□□□□□□
□□□□□□
  - □□□□        → □□□□□□□
  - □□□□        → UPS/PSU □□
  - □□□□        → □□□□□□□
  - □□□□□□□     → □□□□□□□
  - □□□□□□      → □□□□□□□

□□□□□□□□□□□□□□□□□
□□□
  1. □□□□□□□□□□□□□□□
  2. □□□□□□□□
  3. □□□□□□□□□□
  4. □□□□□□ CPU □□□
```

□□□□□□□

```
□□□□□□□
□□□□□□
  - □□□□□            → □□□□□□ OOM
  - □ CPU □□□      → □□□□
  - □□□□□          → □□□□□□□
  - □□□□□□        → □□□□
```

```
□□□□□□□□□□□□
□□□
  1. □□□□□□□
  2. □□□□□□□□□□□
  3. □□ CPU/□□/□□□□
  4. □□□□□□□□
```

□□□□□□

```
□□□□□□□□
□□□□□□
  - □□□□□          → □□□□□/□□
  - DL □□□□□      → □□□□
  - □□□□□□        → □□□□□□
  - □□□□□        → RF □□□□□□□
```

```
□□□□□□□□□□
□□□
  1. □□□□□□□□□
  2. □□□□□□□□□
  3. □□ RF □□□□
  4. □□□□□□□
```

□□□□

```
□□□□□□□□
□□□□□□
  - □□□□□□        → □□□□□□
  - □□□□□□        → □□□□
  - □□□□□□□□□    → □□□□□□
  - □□□□□□□□□    → □□□□□□□□□□□

□□□□□□□□□□□□□□
□□□
  1. □□□□□□□
  2. □□□□□□□□□□
  3. □□□□□□□□□□□□□□
  4. □□□□□□□□□□
```

□□□□□□□

□□□□□□



□□□□□□□□□□□□

□□□□□□□□□□□□□□□

□□□□□□□□

- □□ ID □□□□□□□
- □□□□□□□□□□
- □□□□□□□ DN□□□/□□/□□□
- □□□□□□□□□□□□
- □□□□□□□□□□□□
- □□□□□□□□□□□□

□□□

- RAN Monitor Web UI → □□□□
- Grafana → □□□□□
- InfluxDB → □□□□□□□□□

□□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□

- □□□ AirScale □□□□□□
- □□□□□□□□□□□□□□□
- RAN Monitor □□□□□□□□
- □□□□□□□□□□□□□□

□□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□

```
□□□“DL □□□□□”□□
├─ □□ DL □□□□□□□ > 95%□
├─ □□□□□□□□□□□□□□□□
├─ □□□□□□□□□□□□□□□□
├─ □□□□□□□□□□□□□□□
└─ □□□□□□□□□□□□□□
```

□□□

- Grafana → □□□□□□□□
- Web UI → □□□□□□□□□ → □□□□
- InfluxDB □□□□□□□□□□

□□□□□□□□□□□□

□□□□□□□□□□□□□□□□□□

```
□□□□
├─ □□□□□□□□ 4 □□□
├─ □□□□□□□□ 24 □□□
├─ □□□□□□□□□□ 7 □□
├─ □□□□□□□□ 7 □□
├─ □□□□□□□□ 7 □□
└─ □□□□□□□□□□□□
```

□□□

- RAN Monitor → □□□□
- □□□□□□□
- □□□□□□□□□□□□□□□
- □□□□□□□□

□□□□□□□□□□

□□□□□□□□□□□□□□

□□□□□□□“□□□□□□”□□


□□□□□□□□
├─ □□□□□□□□□□
│ ├─ □ → □□□□□□□□□□□□□□□□
│ └─ □ → □□
├─ □□□□□□□□□□□□□□□□
│ ├─ □□□□□ → □□□□□/□□□□□
│ └─ □□□□□ → □□
├─ □□□□□□□□□□□□
│ ├─ □ → □□□□□□□□□□□□□□□
│ └─ □ → □□
├─ □□□□□□□□□□□□□□
│ ├─ □ → □□□□□□□□□□□□□□□
│ │   → □□□□□□□□□□□□□
│ └─ □ → □□□□□□□□□□
│   → □□□□□□□□DSP □□
├─ □□□□□□□□□□□□□
└─ □□□□□□□□□□□□
   → □□□□□
   → □□□□□□
   → □□□□□

□□□□□□□□□□

□□□□□□□□□□□□□□□□□□

□□□□□□□□

□□	□□	□□
□□	□□/□□	□□□□□□□□□□□□□□□
□□	□□□□	□□□□□□□
□□	□□/□□	□□□□□□□□□□
□□	□□/□□	□□□□□□□□□
□□	□□□□	□□ BGP □□□□□□□□

□□□□□□□□□□

□□□□□□□□□□□□

```
□□□□□□
□ RAN Monitor □□□□□□□
□ □□□□□□□□□□
□ □□□/□□□□
□ □□□□□□□□□
□ □□□□□□□□□□□□
□ □□□□□> 30 □□□□□
```

□□□□□□□□

□□□□□□□□□□□□

□□□

- □□□□□□□□□
- □□□□
- □□□□□□□□ SLA □□□
- □□□□□□□
- □□□□□□□□

□□□□

□□□□



□□□□□□

□□□□□□□□□□□□□□□□□ **2**□

- □□□□□ 15 □□□□□□
- □□□□□ 30 □□□□□□
- □□□ NOC □□□□□□□
- □□□□□□/□□□
- □□□ > 1 □□

□□□□□□□□□□□□□□□□□ **3**□

- □□ 2 □ 1 □□□□□□□
- □□□□□□ > 30 □□
- □□□□□□
- □□□□□□□
- □□□□□□□

□□□□□□□□□□□□□□□□ **4**□□□□□□□□□

- □□□□□□□□PSU□CMON □□
- □□□□□□□□□□□□□□□
- □□□/□□□
- □□□□□□□□□□□□□
- □□□□□□□□□□

□□□□

□□□□□ **2** □□□□

```
□□□□□□ - [□□□□] - [□□] - [□□]

□□□□□□[2025-12-10 14:30 UTC]
□□□□□□[15 □□]
□□□[SITE_A_BS1]
□□□[□□□□□□]

□□□
- □□ A1 □□□□□□
- □□□□□□□□□□□□□
- □□ ping □□

□□□□□□□□
- □□□□□□□
- □□□□□□□□□
- □□□□□□□□
- □□□□□□

□□□
- □□□□□□□0%
- □□□□□□
- □□□□□□□□

□□□□□□
- □□□□□□□□□□
- □□□□□□□□□□□

□□□□□□□□
- □□□□
- □□□□□□□□□□
- □□□□□□□□□□□

□□□□□□[□□□□□□]
```

□□□□□□

SLA □□

□□□□□□□□□□ SLA □□□

```
□□□□□□□
├─ □□□□□□14:23:45 ← □□□□□□□
├─ □□□□□□14:23:47□2 □□← □□□□□□
├─ □□□□□□14:23:50□5 □□← □□□□
├─ □□□□□□14:24:15□30 □□← □□□□□□
├─ □□□14:24:15 → 14:28:00□3.75 □□□
├─ □□□14:28:00 → 14:28:35□35 □□□ + □□□
└─ □□□□□□14:28:36 ← □□□□□□
    └─ □□□□□□□5 □□ 51 □

SLA □□□
├─ □□□□□□2 □
├─ □□□□□□□30 □
├─ □□□□□□5 □□ 51 □
└─ SLA □□□□□□□< 15 □□□□□□
```

□□□□

□□□□□□□□□□□□□

□□□□□□□

- □□□□□□□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□
- MTTR □□□□□□□□□□□□□□□□

□□□

- Grafana → □□□□□□□□
- □□□□□□□□□□□□

- □□□/□□□□ MTTR

□□□□□□



□□□

□□□

1. □□□□□□

- □□□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□□□□
- □□□□□□
- □□□□□□□

2. □□□

- □□□□□□□□
- □□□□□□□□□
- □□□□□□□□□□
- □□□□□□□□□

3. □□□□

记录每个事件
与团队共享经验
根据事件更新运行手册
交叉培训团队成员

4. 主动监控

在严重之前监控警告
容量规划的趋势分析
定期健康检查
建立性能基线

运行手册开发

每个频繁发生的警报都应有一个运行手册：

模板：

□□□[□□□□□□]
□□□[□]
MTTR□[5-15 □□]
SLA □□□[30 □□□□□]

□□□
- □□□“□□□□□”
- □□□□□□□
- □□□□□□□□ 0%

□□□□□□< 5 □□□□
1. □□□□□□□ ping□
2. □□□□□□□□□
3. □□□□□□□□□□□□□□□

□□□□□
□□ 1□□□□□□□
  - ping □□□ping 192.168.1.100
  - □□□□□□□ → □□□□□□□

□□ 2□□□□□
  - □□□□□□□□□
  - □□□□□□ LED
  - □□□□□□

□□ 3□□□□□
  - □□□□□□□□□□
  - □□ 60 □□□□
  - □□□□□□□□

□□ 4□□□□□□□
  - □□□□□ 2
  - □□□□□□
  - □□□

□□□
- □□ > 15 □□ → □□□ [□□□□□]
- □□ > 30 □□ → □□□ [□□□□□]
- □□□□□□ → □□□□□□□

□□□
- □□□□□□□□

- □□□□□□□□□□
- □□□□□□□□□□

API □□□□□□□

□□□□ **RAN □□□□□□□□ REST API**

□□□□□□□□□□□□□□□□□□□□□□□□ API □□□ RAN □□□□□

□□

1. □□
2. API □□
3. □□□□□□□
4. □□□□
5. □□□□
6. □□□□□□
7. □□□□□
8. □□□□
9. API □□

□□

RAN Monitor □□□□□□□□ REST API□□□□□ RAN □□□□□□□□□□□□□□ API □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ API □□□

- □□□□ - □□□□□□□□□□□
- □□□□ - □□□□□□□□□□□□
- □□□□ - □□□□□□□□□□□□□
- □□□□ - □□□□□□□□□□□
- □□□□ - □□□□□□□□□□

API □□



API □□

- **RESTful □□** - □□ HTTP □□ (GET, POST, PUT, DELETE)
- **JSON □□** - □□□□□□□□□ JSON
- □□□□□ - □□□□□□□□□□□ API
- □□□□□ - □□□□□□□□□

- □□□□ - □□□□□□□□□□□□
- □□□□ - □□□□□□□□□□□□□□

□□□□□□□

□□□□

□□□□□□□□□□□□□□□□ RAN Monitor □□□□□□□□□□ RAN Monitor □□□□□□□□□□□□□□□□□

□□□□

□□□□

□□□□□□□

```
GET /api/v1/devices
```

□□□

```
{
  "devices": [
    {
      "id": "nokia_bs1",
      "name": "SITE_A_BS1",
      "vendor": "Nokia",
      "address": "192.168.1.100",
      "port": 8080,
      "status": "registered",
      "registered_at": "2025-12-10T14:30:00Z",
      "session_active": true,
      "software_version": "BSC-2250.5.0",
      "license_required": false
    }
  ]
}
```

□□□□□□□

```
GET /api/v1/devices/:id
```

□□□

```
{
  "device": {
    "id": "nokia_bs1",
    "name": "SITE_A_BS1",
    "vendor": "Nokia",
    "address": "192.168.1.100",
    "registration_status": "registered",
    "registration_key": "base64_encoded_key",
    "session_id": "nonuniquesession",
    "session_expiry": "2025-12-11T14:30:00Z",
    "device_info": {
      "type": "AirScale",
      "software_release": "5.0.0",
      "hardware_version": "2.0",
      "agent_unique_id": "airscale-001"
    }
  }
}
```

□□□□

```
PUT /api/v1/devices/:id/register
Content-Type: application/json

{
  "address": "192.168.1.100:8080",
  "web_username": "admin",
  "web_password": "password",
  "webhook_url": "http://manager.example.com:9076/webhook",
  "private_key_path": "/etc/certs/private.key",
  "public_key_path": "/etc/certs/public.key"
}
```

□□□

```
{
  "result": "Success",
  "registration_key": "base64_encoded_nonce",
  "device_id": "nokia_bs1",
  "message": "□□□□□□□"
}
```

□□□□

- `200` - □□□□
- `400` - □□□□□□□□□□
- `409` - □□□□□□
- `500` - □□□□

□□□□

```
DELETE /api/v1/devices/:id
```

□□□

```
{
  "result": "Success",
  "message": "□□□□□□",
  "device_id": "nokia_bs1"
}
```

□□□□

□□□□

```
PUT /api/v1/devices/:id/sessions
Content-Type: application/json

{
  "session_id": "session_unique_identifier"
}
```

□□□

```
{
  "result": "Success",
  "session_id": "session_unique_identifier",
  "session_timeout": 86400,
  "expires_at": "2025-12-11T14:30:00Z"
}
```

□□□□□□□

- □□□□□24 □□
- □□□□□□□□□
- □ 20 □□□□□□

□□□□□

```
GET /api/v1/devices/:id/sessions
```

□□□

```
{
  "session": {
    "active": true,
    "session_id": "session_unique_identifier",
    "expires_at": "2025-12-11T14:30:00Z",
    "time_remaining_seconds": 82400,
    "last_activity": "2025-12-10T14:30:00Z"
  }
}
```

□□□□□□

```
POST /api/v1/devices/:id/sessions/keep-alive
```

□□□

```
{
  "result": "Success",
  "new_expiry": "2025-12-11T14:30:00Z"
}
```

□□□□

□□□□

□□□□□□□□□□

```
PUT /api/v1/devices/:id/config/upload
Content-Type: application/json

{
  "filter": {
    "uploadType": "configuration",
    "objects": [
      {
        "sdn": "/BSC-1/BTS-23/*",
        "depth": 100
      }
    ],
    "objectClass": ""
  }
}
```

□□□

```
{
  "result": "Success",
  "configuration": {
    "timestamp": "2025-12-10T14:30:00Z",
    "device_id": "nokia_bs1",
    "parameters": {
      "/BSC-1/BTS-23": {
        "BtsBasics": {
          "BtsName": "CELL_A",
          "BtsType": "MACRO",
          "EnvironmentalSpecifications": {
            "TemperatureRange": "Industrial"
          }
        },
        "CarrierAggregation": {
          "CarrierAggregationCapability": true,
          "MaxUECarriers": 5
        }
      }
    }
  }
}
```


□□□□□□

```
PUT /api/v1/devices/:id/config/set
Content-Type: application/json

{
  "parameter_path": "/BSC-1/BTS-23/BtsBasics/BtsName",
  "value": "NEW_CELL_NAME",
  "value_type": "string"
}
```

□□□

```
{
  "result": "Success",
  "parameter": "/BSC-1/BTS-23/BtsBasics/BtsName",
  "old_value": "CELL_A",
  "new_value": "NEW_CELL_NAME",
  "applied_at": "2025-12-10T14:30:45Z"
}
```

□□□□□□□

□□	□□	□□	□□
BtsName	□□□	"SITE_A_Cell_1"	□□/□□□□□
MaxUEsServed	□□	256	□□□□□□□
CellTXPower	□□	40 (dBm)	□□□□□□
EnableCarrierAgg	□□	true	□□□□□□
HandoverHysteresis	□□	3 (dB)	□□□□□□

□□□□□□

```
GET /api/v1/devices/:id/config/history?limit=10&days=7
```

□□□

```
{
  "history": [
    {
      "timestamp": "2025-12-10T14:30:45Z",
      "change_type": "parameter_modified",
      "parameter": "/BSC-1/BTS-23/BtsBasics/BtsName",
      "old_value": "CELL_A",
      "new_value": "NEW_CELL_NAME",
      "reason": "□□□□□□□"
    }
  ]
}
```

□□□□

□□□□□□□

□□□□□□□□□□□□

```
PUT /api/v1/devices/:id/metrics/upload
Content-Type: application/json

{
  "filter": {
    "uploadType": "measurement",
    "objects": [
      {
        "sdn": "*",
        "depth": 100
      }
    ]
  }
}
```

□□□

```
{
  "result": "Success",
  "metrics": {
    "timestamp": "2025-12-10T14:30:00Z",
    "measurement_interval": 300,
    "counters": [
      {
        "id": "M1C1",
        "name": "□□□□□□□□",
        "value": 125.4,
        "unit": "Mbps",
        "cell_dn": "/BSC-1/BTS-23/Cell-1"
      },
      {
        "id": "M1C2",
        "name": "□□□□□□□□",
        "value": 89.2,
        "unit": "Mbps",
        "cell_dn": "/BSC-1/BTS-23/Cell-1"
      }
    ]
  }
}
```

□□□□□□

```
PUT /api/v1/devices/:id/alarms/upload
Content-Type: application/json

{
  "filter": {
    "uploadType": "active_faults"
  }
}
```

□□□

```
{
  "result": "Success",
  "alarms": [
    {
      "alarm_id": "a1b2c3d4",
      "severity": "Critical",
      "probable_cause": "□□□□□□",
      "specific_problem": "□□□□□",
      "affected_dn": "/BSC-1/BTS-23/Cell-1",
      "event_time": "2025-12-10T14:15:30Z",
      "description": "□□ 1 □□□□□□□□□□□"
    }
  ]
}
```

□□□□□□□

```
PUT /api/v1/devices/:id/topology/upload
Content-Type: application/json

{
  "filter": {
    "uploadType": "topology",
    "objects": [
      {
        "sdn": "*",
        "depth": 100
      }
    ]
  }
}
```

□□□

```
{
  "result": "Success",
  "topology": {
    "device_dn": "/BSC-1",
    "managed_elements": [
      {
        "name": "BTS-23",
        "type": "□□□□□□□",
        "dn": "/BSC-1/BTS-23",
        "cells": [
          {
            "name": "Cell-1",
            "type": "EUtranCell",
            "physical_cell_id": 100,
            "frequency": 2110
          }
        ]
      }
    ]
  }
}
```

□□□□

Ping □□

```
PUT /api/v1/devices/:id/ping
```

□□□


```
{
  "result": "Success",
  "device_id": "nokia_bs1",
  "latency_ms": 45,
  "status": "□□"
}
```


□□□□□□

```
GET /api/v1/health/status
```

□□□

```
{
  "status": "healthy",
  "devices": {
    "total": 50,
    "registered": 48,
    "active_sessions": 45,
    "unreachable": 2
  },
  "database": {
    "mysql": "connected",
    "influxdb": "connected"
  },
  "timestamp": "2025-12-10T14:30:00Z"
}
```

□□□□

□□□□□□

Nokia eNodeB □□□□□□□□□□

```
/SystemFunctions
├── /BSC-1 (□□□□□□)
│   └── /BTS-23 (□□□□□□□)
│       ├── BtsBasics (□□□□□□□□□)
│       ├── /Cell-1
│       │   ├── CellCommonData
│       │   ├── CellAdvanced
│       │   └── CarrierAggregation
│       └── /Cell-2
│           └── ...
└── /Connectivity
    ├── S1Interface
    ├── X2Interface
    └── NetworkConfiguration
```

□□□□□□

□□/□□□□

```
{
  "parameter_path": "/BSC-1/BTS-23/Cell-
1/CellCommonData/AdminState",
  "value": "UNLOCKED",
  "value_type": "enum"
}
```

□□□□□`LOCKED`, `UNLOCKED`, `SHUTTING_DOWN`

□□□□□□

```
{
  "parameter_path": "/BSC-1/BTS-23/Cell-
1/CellAdvanced/CellTXPower",
  "value": "35",
  "value_type": "integer"
}
```

□□□0-46 dBm□□□□□□□

□□□□□□□

```
{
  "parameter_path": "/BSC-1/BTS-23/Cell-
1/CellAdvanced/HandoverHysteresis",
  "value": "3",
  "value_type": "integer"
}
```

□□□dB□□□□□□□0-8 dB

□□□□□□□□□□

```
{
  "parameter_path": "/BSC-1/BTS-23/MaxUEsServed",
  "value": "256",
  "value_type": "integer"
}
```

□□□□□□□□□

□□□□□

□□□ 1□□□□□


□□□□□□□
1. □□□□
POST /api/devices
2. □□□□
PUT
/api/devices/:id/register
3. □□□□
PUT
/api/devices/:id/sessions
4. □□□□
PUT
/api/devices/:id/config/upload
5. □□□□
PUT
/api/devices/:id/metrics/upload
□□□□□
□□□

□□□

```
# 1. □□□□□□
curl -X POST http://localhost:4000/api/v1/devices \
  -H "Content-Type: application/json" \
  -d '{
    "id": "site_a_bs1",
    "name": "SITE_A_BS1",
    "vendor": "Nokia",
    "address": "192.168.1.100:8080",
    "credentials": {
      "username": "admin",
      "password": "password"
    }
  }'

# 2. □□□□□
curl -X PUT
http://localhost:4000/api/v1/devices/site_a_bs1/register \
  -H "Content-Type: application/json" \
  -d '{
    "webhook_url": "http://manager.example.com:9076/webhook"
  }'

# 3. □□□□
curl -X PUT
http://localhost:4000/api/v1/devices/site_a_bs1/sessions \
  -H "Content-Type: application/json" \
  -d '{"session_id": "session_001"}'

# 4. □□□□
curl -X PUT
http://localhost:4000/api/v1/devices/site_a_bs1/config/upload \
  -H "Content-Type: application/json" \
  -d '{
    "filter": {
      "uploadType": "configuration",
      "objects": [{"sdn": "*", "depth": 100}]
    }
  }'
```

□□□ 2□□□□□

```
# 1. □□□□□
curl -X PUT
http://localhost:4000/api/v1/devices/site_a_bs1/config/upload \
  -H "Content-Type: application/json" \
  -d '{
    "filter": {
      "uploadType": "configuration",
      "objects": [{"sdn": "/BSC-1/BTS-23/Cell-1", "depth": 10}]
    }
  }' | jq '.configuration.parameters["/BSC-1/BTS-23/Cell-1"]'

# 2. □□□□
curl -X PUT
http://localhost:4000/api/v1/devices/site_a_bs1/config/set \
  -H "Content-Type: application/json" \
  -d '{
    "parameter_path": "/BSC-1/BTS-23/Cell-
1/CellAdvanced/CellTXPower",
    "value": "38",
    "value_type": "integer"
  }'

# 3. □□□□
curl -X PUT
http://localhost:4000/api/v1/devices/site_a_bs1/config/upload \
  -H "Content-Type: application/json" \
  -d '{
    "filter": {
      "uploadType": "configuration",
      "objects": [{"sdn": "/BSC-1/BTS-23/Cell-1/CellAdvanced",
"depth": 5}]
    }
  }' | jq '.configuration.parameters["/BSC-1/BTS-23/Cell-
1/CellAdvanced/CellTXPower"]'
```

□□□ 3□□□□□

```
# □□□□□□□□□□□□□□
#!/bin/bash

DEVICE="site_a_bs1"
INTERVAL=300  # 5 □□

while true; do
  # □□□□
  METRICS=$(curl -s -X PUT
http://localhost:4000/api/v1/devices/$DEVICE/metrics/upload \
    -H "Content-Type: application/json" \
    -d '{
      "filter": {
        "uploadType": "measurement",
        "objects": [{"sdn": "*", "depth": 100}]
      }
    }')

  # □□□□□□
  DL=$(echo $METRICS | jq '.metrics.counters[] |
select(.id=="M1C1") | .value')
  CELLS=$(echo $METRICS | jq '.metrics.counters | length')

  echo "$(date): DL=$DL Mbps, Cells=$CELLS"

  # □□□□
  ALARMS=$(curl -s -X PUT
http://localhost:4000/api/v1/devices/$DEVICE/alarms/upload \
    -H "Content-Type: application/json" \
    -d '{
      "filter": {
        "uploadType": "active_faults"
      }
    }' | jq '.alarms | length')

  if [ "$ALARMS" -gt 0 ]; then
    echo "□□□$ALARMS □□□□□"
  fi
```

```
  sleep $INTERVAL
done
```

□□□□

HTTP □□□

□□	□□	□□
`200`	□□	□□□□□□
`201`	□□	□□□□□□
`400`	□□□□□	□□□ JSON □□□
`401`	□□□	□□/□□□ API □□
`404`	□□□	□□□□□□
`409`	□□	□□□□□□
`500`	□□□□□□	□□□□□□□□
`503`	□□□	□□□□

□□□□□□

```
{
  "error": {
    "code": "DEVICE_NOT_FOUND",
    "message": "□□ 'site_a_bs1' □□□",
    "details": {
      "device_id": "site_a_bs1",
      "timestamp": "2025-12-10T14:30:00Z"
    }
  }
}
```

□□□□

□□□□□□

```
{
  "error": {
    "code": "NOT_REGISTERED",
    "message": "□□□□□□□□□□□□□",
    "solution": "□□□□ PUT /api/devices/:id/register"
  }
}
```

□□□□□

```
{
  "error": {
    "code": "SESSION_EXPIRED",
    "message": "□□□□□□□□",
    "solution": "□□ PUT /api/devices/:id/sessions □□□□□□"
  }
}
```

□□□□□□□

```
{
  "error": {
    "code": "INVALID_PARAMETER",
    "message": "□□□□□□□□",
    "details": {
      "parameter": "/BSC-1/BTS-23/Cell-
1/CellAdvanced/CellTXPower",
      "value": "99",
      "valid_range": "0-46 dBm"
    }
  }
}
```

API □□

Python □□□□□

```
import requests
import json

class RanMonitorClient:
    def __init__(self, base_url="http://localhost:4000/api/v1"):
        self.base_url = base_url
        self.session = requests.Session()

    def register_device(self, device_id, address, username,
password):
        """□□□□□"""
        url = f"{self.base_url}/devices/{device_id}/register"
        payload = {
            "address": address,
            "web_username": username,
            "web_password": password,
            "webhook_url": "http://manager:9076/webhook"
        }
        response = self.session.put(url, json=payload)
        return response.json()

    def get_config(self, device_id, sdn="*", depth=100):
        """□□□□□□"""
        url = f"{self.base_url}/devices/{device_id}/config/upload"
        payload = {
            "filter": {
                "uploadType": "configuration",
                "objects": [{"sdn": sdn, "depth": depth}]
            }
        }
        response = self.session.put(url, json=payload)
        return response.json()

    def set_config(self, device_id, parameter_path, value,
value_type="string"):
        """□□□□□□"""
        url = f"{self.base_url}/devices/{device_id}/config/set"
        payload = {
```

```
            "parameter_path": parameter_path,
            "value": value,
            "value_type": value_type
        }
        response = self.session.put(url, json=payload)
        return response.json()

    def get_metrics(self, device_id):
        """□□□□□□"""
        url = f"
{self.base_url}/devices/{device_id}/metrics/upload"
        payload = {
            "filter": {
                "uploadType": "measurement",
                "objects": [{"sdn": "*", "depth": 100}]
            }
        }
        response = self.session.put(url, json=payload)
        return response.json()

# □□□□
client = RanMonitorClient()

# □□□□
result = client.register_device(
    device_id="site_a_bs1",
    address="192.168.1.100:8080",
    username="admin",
    password="password"
)
print(f"□□□{result}")

# □□��□
config = client.get_config("site_a_bs1")
print(f"□□□{json.dumps(config, indent=2)}")

# □□□□
update = client.set_config(
    "site_a_bs1",
    "/BSC-1/BTS-23/Cell-1/CellAdvanced/CellTXPower",
    "38",
    "integer"
```

```
)
print(f"□□□{update}")
```

cURL □□

□□□□□

```
curl -X PUT
http://localhost:4000/api/v1/devices/site_a_bs1/register \
  -H "Content-Type: application/json" \
  -d '{
    "address": "192.168.1.100:8080",
    "web_username": "admin",
    "web_password": "password",
    "webhook_url": "http://manager:9076/webhook"
  }'
```

□□□□□□□

```
curl -X GET http://localhost:4000/api/v1/devices/site_a_bs1
```

□□□□□

```
curl -X PUT
http://localhost:4000/api/v1/devices/site_a_bs1/config/upload \
  -H "Content-Type: application/json" \
  -d '{
    "filter": {
      "uploadType": "configuration",
      "objects": [{"sdn": "/BSC-1/*", "depth": 50}]
    }
  }' | jq '.'
```

□□□□□□

AirScale □□□□□□□□□□□□□□□□

□□

□□□□□□□□□□□□□□□□□ AirScale □□□□□□□□□□□□□□□□□ InfluxDB □□□□□□□□□□□ XML □□□ □□□□□□□□□□□□□□□□□□□□□□□□□

□□□□

- □□□□□□□ - □□□□□□□□□□□□□
- □□□□□□ - □□□□□□□□□□□□□□□□□
- □□□□□ - □□□□□□□□□□□□□□□□□
- □□□□□□□□ - □□□□□□□□□ 100 MB□□□ ~690 □□□□
- **Web** □□ - □□□□□□□□□□□□□
- □□□□□ - □□□□□□□□□□□□□□□
- □ **InfluxDB** □□ - □□□□□□□□□□□□□□□□
- □□□□□ - □□□□□□□□□□□□□□□

□□□□

□□□□

□□□□□□□ AirScale □□□□□□□□

- □□□ □ 1 □□□□□□□
- □□□□□□ □□□□□□□□□□
- □□□□□□ □□□□□□□□□□□□□□
- □□□ □□□□□□□□□□□

□□□□□□□□□□□□□□□□□□□

□□□□

□□□□□ RAN Monitor □□□□□□□□□

```
priv/airscale_configs/
└── <airscale-name>/
    ├── current.xml                                          # □□□□
    ├── ONS-Lab-Airscale_config_20251230_143522.xml   # □□□□ 12 □
30 □□□□ 2:35
    ├── ONS-Lab-Airscale_config_20251229_120000.xml   # □□□□
    ├── ONS-Lab-Airscale_config_20251228_093045.xml   # □□□□
    └── ...                                                   # □□□□□□
100 MB □□
```

□□□□□□ `<AirScaleName>_config_YYYYMMDD_HHMMSS.xml`

□□□□□ AirScale □□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□

- □□□□□ □□□□□ `current.xml`
- □□□□□ □□□□□□□□□□□□□□□□□□
- □□□□□ □□□ 100 MB □□□□□□□□□□□
- □□□□□ □□ Web UI □□□□□□□`current.xml` □□□
- □□□□□ □□□□□□□□□□□□□□□□□
- □□□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□

□□□□□□□□□

□□□□□□□□□□□□□□□□□ □□□□□□□□ □□□□□□□□□

- □□□□□ □□□□ 100 MB□□□□□
- □□□□□ □□□□□□□□□□□□□□□

清理时机：每次保存新配置版本时
受保护文件：始终保留 current.xml 和至少一个版本
灵活性：每个版本约 145KB 时保留 ~690 个版本，如果文件较小则更多

工作原理

当保存新配置版本时：

1. 保存新版本 - 配置写入 <AirScale>_config_YYYYMMDD_HHMMSS.xml
2. 更新当前 - current.xml 更新为最新配置
3. 计算大小 - 系统计算所有版本文件的总大小
4. 清理旧版本 - 如果总大小 > 100 MB，删除最旧版本直到低于限制
5. 记录活动 - 删除记录并释放空间

□□□□

```
□□□□□□□□ 95 MB□655 □□□□□□□ 145KB□
├── ONS-Lab-Airscale_config_20240101_100000.xml  <- □□□145KB□
├── ONS-Lab-Airscale_config_20240102_100000.xml  (145KB)
├── ... (□□ 653 □□□)
└── ONS-Lab-Airscale_config_20251230_100000.xml  <- □□□145KB□

□ 2025-12-31 10:00:00 □□□□□□□□145KB□

□□□
1. □□□ONS-Lab-Airscale_config_20251231_100000.xml (145KB)
2. □□□□□□□95 MB + 145KB = 95.14 MB□□□ 100 MB □□□□
3. □□□□□□
4. □□□656 □□□□□□□ 95.14 MB

---

□□□□□□□□□□□□□□□□□□□□□□□□□□□ 500KB□

□□□
1. □□□ONS-Lab-Airscale_config_20251231_150000.xml (500KB)
2. □□□□□□□95.14 MB + 500KB = 95.64 MB□□□□□□□□
3. □□□□□□
4. □□□657 □□□□□□□ 95.64 MB

---

□□□□□□□□□□□□□□□

□□□□□99.8 MB□685 □□□□

□□□□200KB
1. □□□□□□
2. □□□□□□□100 MB□□□□□□□
3. □□□□□□□□□□□□□ < 100 MB
4. □□□□□□“□□ 3 □□□□□□□ 435 KB”
5. □□□682 □□□□□□□ 99.6 MB
```

□□□□

□□□□□□□□

- □□□□□ □□□□□□□□□□ 100 MB
- □□□□ □□□□□□□□□
- □□□□□ □□□□□□□
- □□□□□ □□□□□□□□□□□□□□□□□□□□□□
- □□□□□ □□□□□□□□□□□□

□□□□

□□□□□□□□□□□□□□□□

```
# □□□□□□□□
du -sh priv/airscale_configs/
# □□□215M□3 □□□□□ 70 MB□

# □□□□□□□□
du -sh priv/airscale_configs/*/
# □□□
# 95M     priv/airscale_configs/ons-lab-airscale/
# 68M     priv/airscale_configs/sector-1/
# 52M     priv/airscale_configs/sector-2/

# □□□□□□□□□□□□
find priv/airscale_configs -maxdepth 1 -type d -exec du -sm {} \;
| awk '$1 > 90 {print $2 " is at " $1 "MB (approaching 100MB
limit)"}'
```

□□□□□□□□

□□□□□□

Web UI□ □□□ Nokia → □□□□

URL： `https://<ran-monitor-ip>:9443/nokia/config-archive`

□□□

□□□□

□□□□□□□□□□□□□□□□

1. □□□□□

- □□□□ - □□□□□□□□ AirScale □□
- □□□□ - □□□□□□□□□□□□□□□
- □□ - □□□□□□□□□□□□
- □□□□□ - □□□□□□□□□□□□

2. □□□□□

□□□□□□□□□□□□□□□□

□	□□
□□□	□□□□□□□□□UTC□
□□□	□□□□□□□□□□□`config_20251230_143522.xml`□
□□	□□□□□KB □ MB□
□□	□□□□□□□□□□□□□“2□□□”□“3□□”□
□□	□□□□□□□□

□□□ □□□□□□□□□□□□□□□□□□□□

□□□□□□ `current.xml` □□□□□□□□□□□□□□□

3. □□□□

□□□□□□□□

- □□□ - □□□□□□□□□□
- □□□ - □□□□□□□□□
- □□□□ - □□□□□□□□□□□□

□□□

□□□□

□□□ □□□□□□□□□□□□□□□□□□□□□□□□

□□□

1. □□□□□□□□□□
2. □□□□□□□□
3. □□□□□□□□□□□□

4. □□ □□ □□
5. □□□□□□□□□□ `<AirScaleName>_config_YYYYMMDD_HHMMSS.xml` □□□□□□□□□□□□□

□□□

- □□□□□□□
- □□□□□□□□□□□
- □□□□□□□□□□□□□
- □□□□□□□□□□□□□

□□□□□

□□□ □□□□□□□□□□□□□□□□□□□□

□□□

1. □□□□□□□□□□
2. □□□□□
3. □□□□□□□□□
4. □□ □□ □□
5. □□□□□□□□□□□□
6. □□□□□□□□□

□□□□□

- □□□□ `current.xml` □□□□□□□□□
- □□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□

□□□□

□□□ □□□□□□□□□□□□□□□□

□□□□□

1. □□□□□□□□□□□□
2. □□ XML □□□□□□□□□ `xmldiff` □ `Beyond Compare` □ `WinMerge` □

3. □□□□□□□□□□

□□□□□□□□□□

```
# □□□□□□□
wget https://<server>:9443/download/config/ONS-Lab-Airscale/ONS-
Lab-Airscale_config_20251230_143522.xml
wget https://<server>:9443/download/config/ONS-Lab-Airscale/ONS-
Lab-Airscale_config_20251229_120000.xml

# □□ diff □□□□
diff ONS-Lab-Airscale_config_20251229_120000.xml ONS-Lab-
Airscale_config_20251230_143522.xml

# □□□ xmldiff □□□□□□□□□
xmldiff ONS-Lab-Airscale_config_20251229_120000.xml ONS-Lab-
Airscale_config_20251230_143522.xml
```

□□□□□□□□

□□□□□□

□□□ □□□□□□□□□□

□□□

1. □□□□□□□
2. □□□□□□□□□
3. □□□□□□□□
4. □□□□□□□
5. □□□□□□□□□□
6. □□□□□□□□□□□

□□□

```
□□□□□□□
- ONS-Lab-Airscale_config_20251230_143522.xml (143KB) - □□
- ONS-Lab-Airscale_config_20251228_091045.xml (142KB) - 2 □□
- ONS-Lab-Airscale_config_20251225_180000.xml (142KB) - 5 □□

□□□
- □□□ 142KB □□□ 143KB □ 12 □ 30 □
- □□ 12 □ 28 □□ 12 □ 30 □□□□□□□□□□
- □□□□□□□□□□□□□□□□
```

□□□□

□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□

1. □□□□□□□□□□□□□
2. □□□□□□□□□□□□
3. □□□□□□□□□□□□Web UI□
4. □□□□□□□□ → □□□□ ID
5. □□□□ → □□□□
6. □□□□□□□□□□□□
7. □□□□□□□□□
8. □□□□□□□□□□□□□□□□□□□□□

□□□□□□□□

- ✓ □□□□□□□□□□□□
- ✓ □□□□□□□□□□
- ✓ □□□□□□□□
- ✓ □□□□□□□□□□
- ✓ □□□□□□□□□□□□

□□□□□□

□□□ □□“□□□□”□□□□□□□

最佳实践：

1. 创建并验证基线配置
2. 应用到参考设备
3. 在下次轮询后从配置归档下载
4. 作为模板外部存储
5. 用于部署新设备
6. 定期审查和更新基线

技术细节

变更检测算法

系统使用智能内容比较来避免误报：

规范化过程：

1. 删除前导/尾随空白
2. 在 XML 标签之间折叠空白
3. 规范化内部空白
4. 比较结果规范化的内容

好处：

格式更改不会触发新版本
仅实际配置更改会创建版本
减少存储需求
提供有意义的变更历史

示例：

```
<!-- □□□□□□□□ -->

<!-- □□ 1□□□□□□□ -->
<parameter>
    <name>cellId</name>
    <value>1</value>
</parameter>

<!-- □□ 2□□□□ -->
<parameter><name>cellId</name><value>1</value></parameter>
```

□□□□

□□□□□□□ ~145 KB □□□□□□□□□ AirScale □□□

□□□□□

□□□□	□□□□□□□□	□□□□□□□□ **145KB□**	□□□□□
10	100 MB	~690	1 GB
50	100 MB	~690	5 GB
100	100 MB	~690	10 GB
500	100 MB	~690	50 GB
1000	100 MB	~690	100 GB

□□□□□

- □□□□□□□□□ 100 MB□□□□□
- □□□□□□□ ~690□□□ 145KB□
- □□□□□□□□ □□□□□□ current.xml □ 145KB□
- □□□□□□□□ □□□ 100 MB □□□□□
- □□□ □□□□□□□□□□□□□□□□□□□□

□□□□□

- □□□□□□□□□□□□□□□□
- □□□□□□□
- □□□□□□□□□□□□□□□□
- □□□□□□□□□□□□

□□□□

□□□□□□

- □□□□□□□ **100 MB** □□
- □□□□□□□□□□□□□□□□
- □□□□ `current.xml`□□□□□□□
- □□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□

□□□□□□□

□□□□□ ConfigStorage □□□□□□□

```
# □ lib/ran_monitor/nokia/airscale/config_storage.ex □
# □□□□□□□□□□□
@max_storage_bytes 100 * 1024 * 1024  # □□ 100 MB

# □□□□□□□□□□□
@max_storage_bytes 50 * 1024 * 1024   # 50 MB□□□ ~345 □□□□
@max_storage_bytes 200 * 1024 * 1024  # 200 MB□□□ ~1380 □□□□

# □□□□□□□□□□□□
def cleanup_old_versions(airscale_name, max_size_bytes \
@max_storage_bytes)
```

□□□□□□□□□□

```
mix compile
# □□ RAN Monitor □□□□□
```

□□□□

□□□□□ 1 □□□3,600,000 □□□

□□□□□□□□□

□□ `lib/ran_monitor/nokia/airscale/manager.ex`□

```
defp schedule_get_airscale_config do
  # □ 1 □□□□□□□□3,600,000 ms□
  Process.send_after(self(), :get_airscale_config, 3_600_000)
end
```

□□□□□

- 30 □□□`1_800_000`
- 1 □□□`3_600_000`□□□□
- 2 □□□`7_200_000`
- 4 □□□`14_400_000`
- 24 □□□`86_400_000`

□□□□□□□□□□□□ RAN Monitor□

□□□

□□□□□□□□

□□□

- □□□□□□□□□“0 □□□”
- □□□□□□□□□

□□□□□

1. □□□□□

- □□□□□□□
- □□□□□□□“□□□”□□
- □□□□□□□□□□□□□□□

2. □□□□□□

- □□□□□□□□□□
- □□□□□□□□□“□□”
- □□□□□□□□□

3. □□□□□□□

- □□□□□□□□□□□□□□□
- □□□□□□□□ `Kernel.send(Process.whereis(RanMonitor.Nokia.Airscale.Manager), :get_airscale_config)`

4. □□□□□□□

- □□ `priv/airscale_configs/` □□□□□□□
- □□ RAN Monitor □□□□□□□□
- □□□□□□□□□□□□□□□□□□

□□□□ 404 □□

□□□

- □□□□□□□“□□□□□□□□□”
- □□□□□□ 404 □□

□□□□□□

1. □□□□□□□□□

- □□□□□□□□□□□□□□□□□□□□□□□□□□□
- □□ `priv/airscale_configs/` □□□□□□□□□□

2. □□□□□□

- □□□□□□□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□□□

3. □□□□

- □□ Web □□□□□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□

□□□□□□

```
# □□□□□□□□□□
ls -la priv/airscale_configs/

# □□□□□□□□□□
ls -la priv/airscale_configs/<device-name>/

# □□□□□□□□□□□
chmod 755 priv/airscale_configs/
chmod 644 priv/airscale_configs/*/*.xml
```

□□□□□

□□□

- □□□ `current.xml`□□□□□□
- □□□□□□□□□□□□□□□ 1

□□□□□□

1. □□□□□

- □□□□□□□□□□□□□□□□
- □□□□□“□□□□□□□□□□□□□□□□”

2. □□□□□

- □□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□

3. □□□□□□□□□

    - □□□□□□□□□□□□□□□□
    - □□□□□□□□□□□□□

□□□

```
# □□□□□□□□□□□□□□□□□
grep "process_configuration" <log-file>

# □□□□□□□□□□
# □ IEx □□□□□□
Kernel.send(Process.whereis(RanMonitor.Nokia.Airscale.Manager),
:get_airscale_config)
```

□□□□

□□□□

□□□ □□□□□□□□□□□□□

□□□□□□□□□□

```
#!/bin/bash
# backup-configs.sh - □□□□□□□□□□□□

BACKUP_DIR="/backup/ran-monitor/configs"
CONFIG_DIR="priv/airscale_configs"
DATE=$(date +%Y%m%d)

# □□□□□□□□□□□
mkdir -p "$BACKUP_DIR/$DATE"

# □□□□□□□
rsync -av "$CONFIG_DIR/" "$BACKUP_DIR/$DATE/"

# □□□□ 30 □
find "$BACKUP_DIR" -type d -mtime +30 -exec rm -rf {} +

echo "□□□□□$BACKUP_DIR/$DATE"
```

□□ cron □□□

```
0 2 * * * /path/to/backup-configs.sh
```

□□□□

□□□□□ □□□□□□□□□□

□□□□□

1. □□□□□□□□□□□□

```
# config_changes.log

2025-12-30 14:35:22 - ONS-Lab-Airscale
□□□□John Smith
□□□□□□□□□□□□□□ 1 □□□
□□□txPower □ 40dBm □□□□ 43dBm
□□□□□□
□□□□□□2025-12-30 14:40:00
□□□□□□□□□□□□□□□□□

2025-12-28 09:10:45 - ONS-Lab-Airscale
□□□□Jane Doe
□□□□□□□□□□□□□□□□□□□□□□□
□□□□□□□□□□□ 10□11□12
□□□□□□
□□□□□□2025-12-28 09:15:00
□□□□□□□□□□
```

□□□□

□□□ □□□□□□□□□□□

□□□□□□□□□□

```
# □□□□□□□□□
du -sh priv/airscale_configs/

# □□□□□□□□
du -sh priv/airscale_configs/*/

# □□□□□□□□□□
find priv/airscale_configs/ -name "*.xml" | \
  sed 's|/[^/]*\.xml||' | uniq -c
```

□□□□□

- □□□□□□□□□□□□□□□□500MB□□□□
- □□□□□□□□□□□□□□□□□□□□
- □□□□□□□□□ 10% □□□□□

□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□

□□□□□□

□□□□□□□□

- □□□□□□□□□ `current.xml`
- □□□□□□□□□“□□”□□□□□□□□□□

□□□□□□□□□□

- □□□□□□□□□
- □□ → □□ → □□□□□□
- □□□□□□□□□□□□□□□□□

□□□□□

- □□□□□□□□□
- □□□□□□□□□
- □□□□ → □□□□□□□□

数据流



API 访问

虽然配置归档主要通过 Web UI 访问，但也可以通过直接 HTTP 请求下载配置。

□□□□

□□□□□

```
curl -k "https://<server>:9443/download/config/<airscale-
name>/current.xml" \
  -o current_config.xml
```

□□□□□

```
curl -k "https://<server>:9443/download/config/<airscale-
name>/ONS-Lab-Airscale_config_20251230_143522.xml" \
  -o ONS-Lab-Airscale_config_20251230_143522.xml
```

□□□ URL □□ AirScale □□

□□□□□

□□□□□□ **IEx** □□□□□

```
# □□□□□□□□□□
RanMonitor.Nokia.Airscale.ConfigStorage.list_config_versions("ONS-
Lab-Airscale")

# □□□□□□□□□
{:ok, xml} =
RanMonitor.Nokia.Airscale.ConfigStorage.get_current_config("ONS-
Lab-Airscale")

# □□□□□□
RanMonitor.Nokia.Airscale.ConfigStorage.count_versions("ONS-Lab-
Airscale")
# □□□655

# □□□□□□□□□□□
RanMonitor.Nokia.Airscale.ConfigStorage.max_storage_bytes()
# □□□104857600□100 MB □□□□□□□

# □□□□□□□□□□□
RanMonitor.Nokia.Airscale.ConfigStorage.get_storage_usage("ONS-
Lab-Airscale")
# □□□99614055□□□□

# □□□□□□□□□□□
RanMonitor.Nokia.Airscale.ConfigStorage.get_storage_stats("ONS-
Lab-Airscale")
# □□□%{version_count: 655, total_size_bytes: 99614055, ...}

# □□□□□□□□□ 50 MB □□□
RanMonitor.Nokia.Airscale.ConfigStorage.cleanup_old_versions("ONS-
Lab-Airscale", 50 * 1024 * 1024)
# □□□{:ok, 345, 50000000} - □□ 345 □□□□□□ 50MB

# □□□□□□□□□100 MB□
RanMonitor.Nokia.Airscale.ConfigStorage.cleanup_old_versions("ONS-
Lab-Airscale")
# □□□{:ok, 0, 0} - □□□□□□□□□□□□□□□
```

□□

- **Web UI □□** - □□□□□□□□□
- **AirScale □□□□** - □□□□
- **□□□□□□** - □□□□□□
- **□□□□□□□□** - □□□□

□□□□□□□□

□□

RAN Monitor □□□□□□□□□□□□□□ □□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□ InfluxDB □□□□ □□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□

□ □□□□

□□□□□□□□□

1. □□□ □□□□: `https://localhost:9443`
2. □□□□□□□□ □□□□
3. □□□□□□□□□□ eNodeB □□□□□

□□□□□□□□□

1. □□□□□□ eNodeB
2. □□“□□□□”□□□□□□□□□□
3. □□□□□□□
4. □□□□□□□□□□□□□□□

□□□□

1. □□ □□□□□ □□□□□□□□□□□□□□□
2. □□□ □□□□□□ □□□□ eNodeB □□□□□□□□□□□□□

□□

□□□□□□□□□□□ eNodeB □□□□□□□□□□□

□ □□

□□□□□□

- □□□□□□□: 720 □□□30 □□
- □□□: □ `config/config.exs` □□□
- □□: □□□□□□□□□□□□□□□ eNodeB

□□ eNodeB □□□

- □□□□: □□□ eNodeB □□□□□□□□
- □□□□□: □□□□ `airscales` □□
- □□: □□□□

自动清理

定期: 每小时自动运行
后台工作者: RanMonitor.Data.RetentionCleanupWorker
每个 eNodeB: 尊重各自的保留设置
记录: 所有清理操作都有日志记录以供审计

数据可见性

记录计数: 查看每种测量类型的记录数量：
性能指标
配置
警报
总摘要: 查看每个 eNodeB 的总记录
实时: 在页面刷新时更新

□ □□□□

□□□□□

□□□□□□□□□□□□□□□□□ eNodeB □□□□□□□□□□

□□□□□



□□□□□

- □□ **(✓)**: eNodeB □□□□□□□□□□□□
- □□ **(✗)**: eNodeB □□□□□□□□
- □□: □□□□□□□□ eNodeB □□□

□□□□

□□	□□	□□
□□□□□	□□□□□	□□□□□□□□□□□□
□□□□□□	□□□□	□□□ eNodeB □□□□□ (⚠ □□□□□□)
□□	□□□□	□□□□□□□□□□□

⚙ □□

□□□□□□

□□ `config/config.exs`:

```
config :ran_monitor,
  ecto_repos: [RanMonitor.Repo],
  generators: [context_app: :ran_monitor],
  data_retention_hours: 720  # 30 □□□□□□□□
```

□□□□□□

□□	□□	□	□□□□
1 □□	1	0.04	□□□□□
1 □	24	1	□□□□
7 □	168	7	□□□□
14 □	336	14	□□□□
30 □	720	30	□□□□□□□□
90 □	2160	90	□□□□
180 □	4320	180	□□□□
1 □	8760	365	□□□□

□□□□

□□□□□□□□□

```
export DATA_RETENTION_HOURS=1440  # 60 □
mix phx.server
```

□ □□□□

□□□□□□

```
1. □□□□
   ├─ □□□□ → InfluxDB
   ├─ □□□□ → InfluxDB
   └─ □□ → InfluxDB

2. □□□□□□□□□
   ├─ RetentionCleanupWorker □□
   ├─ □□□ eNodeB□
   │  ├─ □□□□□□□□□ eNodeB □□□□
   │  ├─ □□□□□□□
   │  └─ □□□□□□□□□□□
   └─ □□□□

3. □□□□□□□□
   ├─ □□□ UI □□□□□
   ├─ □□□□□□
   ├─ □□□□□□
   └─ □□□□/□□□□

4. □□
   └─ □ UI □□□□□□□
```

□□□□

□□ eNodeB □□□□□□

```
effective_retention = case airscale.retention_hours do
  nil -> Config.data_retention_hours()      # □□□□□720h□
  hours -> hours                             # □□□□ eNodeB □□□□□
end
```

□□□

- □□□□□720 □□□30 □□

- eNodeB "SITE-01" □□□□168 □□□7 □□
- eNodeB "SITE-02" □□□□nil → □□□□ 720 □□

□□□□

```
□□□□□□ = □□ - (retention_hours * 3600 □)

□ 30 □□□□□□□
├─ □□: 2025-12-11 10:00:00
├─ □□: 720 □□□30 □□
├─ □□: 2025-11-11 10:00:00
└─ □□□□□□□□ < □□□□□□
```

□ □□□□□□□□

□□□□

□□□□□□□□□□□□□□□□□

```
[RetentionCleanupWorker] □□□□□□□□□□
[RetentionCleanupWorker] □□□□ SITE-01 □□□□□□□□720h□
[RetentionCleanupWorker] □□□ SITE-01 □ 15,000 □□□
[RetentionCleanupWorker] □□□□□□□□5 □□□0 □□□75,000 □□□□
```

□□□□□□

□□□□□□

1. □□□□□□□□□
2. □□□□ eNodeB □□□□□□□□□□□
3. □□“□□”□□□□

□□□□

- □□□□□□□□□□□□□□

- □□□□□ InfluxDB □□□□□□
- □□□□□□□□□□□□

□ □□□□

□□□□

□□□□□□□□□□□□□□

```
alias RanMonitor.Data.RetentionPolicy
alias RanMonitor.Database.Nokia

# □□ eNodeB □□□□□
airscale = Nokia.get_airscale!(1)
hours = RetentionPolicy.get_retention_hours(airscale)
# => 720□□□□□□□□□□□

# □□ eNodeB □□□□□
counts = RetentionPolicy.get_record_counts("SITE-01")
# => %{"PerformanceMetrics" => 250000, "Configuration" => 5000,
"Alarms" => 15000}

# □□□□□
total = RetentionPolicy.get_total_record_count("SITE-01")
# => 270000

# □□□□□□□
{:ok, deleted_count} = RetentionPolicy.delete_old_records("SITE-
01", 720)
# => {:ok, 50000}  (□□□ 50k □□□)

# □□ eNodeB □□□□□
{:ok, deleted_count} = RetentionPolicy.clear_all_records("SITE-
01")
# => {:ok, 270000}  (□□ 270k □□□□□)
```

□□□□□□

□□ `lib/ran_monitor/data/retention_cleanup_worker.ex`:

```
# □ 1 □□□3600000ms□□□□ 30 □□□1800000ms□
@cleanup_interval_ms 1800000  # 30 □□
```

□□□□□□□

```
mix compile
```

□□□□□□

□□□□□□□□□

```
SELECT name, retention_hours FROM airscales;
```

□□□□□□□□□□

```
UPDATE airscales
SET retention_hours = 168
WHERE name = 'SITE-01';
```

□ □□□□

□□□□□□

□□□**< 7** □□

- □□□□□□□□□□
- □□□□□□□□
- □□□□□□□□□□□□□□□

□□□**7-30** □□

- □□□□□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□
- □□□□□□□□□□□□□□□□□□□□□□□□□□

□□□**> 30** □□

- □□□□□□□□□□□□□□□□
- □□□□□□□□□□□□
- □□□□□□□□□□□□

□□□□□

□□	□□	□□
□□□□	7-14 □	□□□□□□□
□□□□	30-60 □	□□□□
□□□□	90 □	□□□□
□□□□	180-365 □	□□□□
□□	□□	□□/□□

□□□□

□□□□□□□□

- 1000 □□□ ≈ 1-5 KB□□□□□□□□□□
- 100 □□□□ ≈ 1-5 GB
- □□□□ × □□□□ = □□□

□□□□□□□□□□□□

```
# □□ InfluxDB □□□□□□
influx bucket list

# □□□□□□□□□□□
df -h /path/to/influxdb/data
```

□ □□□□□

□□□□

- □□□□□□□□□ □□
- □□□□ □□ InfluxDB □□□□
- □□□□ □□□□□□□□□□

□□

- □□□□: □□□□□□□□□□□□□□□
- □□□□□: □□□□□□□□□□□□□□
- □□□□: □□□□□□□/□□□□□

□□

1. □□□□□ **InfluxDB** □□□□
2. □□□□□□□□□
3. □□□□□□ □□□□□□□□□
4. □□□□□□□□ □□□□
5. □□□□□□□□□□□□□□□□□□□

□ □□□□

□□□□□□□□□

□□□

- □□□□□□□□□□□□□□□□
- □□□□□□□□□

□□□□□

1. □□□□□□□□□□□`ps aux | grep mix`
2. □□ `RetentionCleanupWorker` □□□□□□
   - □□□□□□ `[RetentionCleanupWorker] □□`
3. □□ InfluxDB □□□
   - □□ InfluxDB □□□□□`https://localhost:9443/nokia/influx`
4. □□□□□□□□□□□□□
   - □□ `config/config.exs` □□ `data_retention_hours`

□□□□□□□□□

□□□

- □□“□□□□□”□□□□□□□
- □□□□

□□□□□

1. □□ InfluxDB □□□□□□
   - □□□□□□□□□
2. □□□□□□□□□□□
   - □□“□□”□□□
3. □□□□□□□□□□□
   - □□ `[RetentionPolicy]` □□□
4. □□ eNodeB □□□□□□
   - □□ eNodeB □□□

□□□□□□□□□□□□□

□□□

- □□□□□□□□
- □□□□□□□□

□□□□□

1. □□□□□□□□□□□□□□
2. □□ 5-10 □□□□□□□□
3. □□□□□□□□□□
   - □□ `@cleanup_interval_ms`□□□ 1 □□□
4. □□□□□□ eNodeB □□□□□

□��□□□□□□□□

□□□

- □□□□□ InfluxDB UI □□□
- “□□□□□”□□□□□□

□□□□□

1. □□“□□”□□□□□
2. □□ InfluxDB □□□
   - □□□□□□□□□□□□□□□□□
3. □□□□□□□□□
   - InfluxDB □□□□□□□□□□
4. □□ eNodeB □□□□□□□□□
   - □□□□□□□□

□ □□□□

- □□□□ - □□□□□□□

- **Web UI □□** - □□□□□□□□□□
- □□□□ - □□□□□□□
- □□□□□□□ - □□□□□□□
- **Grafana □□□□** - □□□□□□□

□ □□□

- □□□□□□□□: `https://localhost:9443/nokia/retention`
- **eNodeB □□**: `https://localhost:9443/nokia/status`
- **InfluxDB □□**: `https://localhost:9443/nokia/influx`
- □□□□: `https://localhost:9443/nokia/logs`

□ □□□□

□□□□□□□□□□□□□□

□□ □□

□□□□□□□□□□ eNodeB □□□□□□□□□□

□□ □□□□□□ eNodeB □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□

□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ `@cleanup_interval_ms`□

□□□□□□□□□□□□□□□□□□

□□ □□□

问：清理会影响数据收集吗？

答：不。清理和数据收集是独立的。新数据将在旧数据被删除时继续写入。

问：清理需要多长时间？

答：取决于记录计数：
小（< 100k）：< 1 秒
中（100k-1M）：1-10 秒
大（> 1M）：10-60+ 秒

问：我可以手动删除特定记录吗？
答：不能通过 UI。仅提供完整清理或完全清除。要进行细粒度删除，请直接使用 InfluxDB CLI 或 API。

问：如果 InfluxDB 不可用怎么办？

答：清理将静默失败并在下小时重试。数据收集继续不受影响。

问：清理会影响性能吗？

答：清理期间会有轻微影响（几秒到几分钟，具体取决于数据大小）。选择每小时间隔以最小化影响。

□ □□□□

□□□□□

□□	□□
`lib/ran_monitor/database/nokia/airscale.ex`	□□ `retention_hours` □□
`lib/ran_monitor/config/config.ex`	□□ `data_retention_hours()` □□□
`config/config.exs`	□□□□□□□□□□□□□□□
`lib/ran_monitor/application.ex`	□□□□□□□□□□□□□□

□□□□□

□□
`lib/ran_monitor/data/retention_policy.ex`
`lib/ran_monitor/data/retention_cleanup_worker.ex`
`lib/ran_monitor/web/live/retention_policy_live.ex`
`priv/repo/migrations/20251211065257_add_retention_hours_to_airscales.`

□□□□

RetentionPolicy □□□

- `get_retention_hours(airscale)` - □□□□□□
- `get_record_counts(airscale_name)` - □□□□□□

- `get_total_record_count(airscale_name)` - □□
- `delete_old_records(name, hours)` - □□□□□
- `clear_all_records(name)` - □□□□

RetentionCleanupWorker GenServer□

- `start_link(opts)` - □□□□□□□
- `init(:ok)` - □□□□□□
- `handle_info(:cleanup, state)` - □□□□□□

□ □□

□□□□□□□

1. □□□□□

```
mix ecto.migrate
```

2. □□□□□□□

```
mix phx.server
```

3. □□□□□

   - □□□ `https://localhost:9443/nokia/retention`
   - □□□□□□□□□□□□

□□□□

1. □□□□□□□□

    - □□□□□□□□□□□□720 □□□
    - □□□□ eNodeB □□□□□

2. □□□□□□□□□□□□

    - □ `config/config.exs` □□□□□□□□
    - □□□ UI □□□□ eNodeB

3. □□□□□

    - □□□□□□ `[RetentionCleanupWorker]` □□
    - □□□□□□□□□□□□

□ □□

□□□□□

1. □□□□□ □□ `[RetentionPolicy]` □ `[RetentionCleanupWorker]` □□
2. □□□□□□ □□□□□□□□□□□□□□□□□□
3. □□□□□□□ □□□□□□□□□□□
4. □□□□□ □□□□□□□□□□□□□□

□□□□

□□□

- UI □□□□□□□□□
- □□□ eNodeB □□
- □□□□□□
- □□□□□□□□□
- □□□□

□ □□□

□□□□

- **InfluxDB v2.x**: □□□□□□□□□□□□□□□
- □□□□: □□□□□□□
- □□: □□□□□□□
- □□□□: □□□□□□□□□□

□□□□□

- InfluxDB □□
- Elixir GenServer □□
- Phoenix LiveView

□□□□

□□□ **AirScale** □□□□□

□□□□□□□□□□□□□□□□

□□

□□□□□□□□□□□□□□□□□□ AirScale □□□□□□□□□□ RAN Monitor □□□□□□□ HTTP □□□□□□ □□□□ WebEM □“□□□□□”□□□□□ RAN Monitor □□□□□□□

□□□□

- □□□□□ - □□□□□ AirScale .zip □□□
- **HTTP** □□□□ - □□□□□□ HTTP URL □□□□
- **MD5** □□□ - □□□□□□□□□□□□□
- **URL** □□ - □□□□ WebEM □□□□□ URL
- □□□□ - □□□□□□□□□□□□

□□□□□□



□□□□

URL: `https://<ran-monitor-ip>:9443/nokia/firmware`

□□: □□□□□□□□ > □□

□□□□□□□□□□□□□□□□□□□□□□□□

□□□□

□□□□□□□

□□□□□□□□ RAN Monitor □□□□□□□□□□

```
/var/firmware/nokia/
├── SBTS25R1_ENB_0000_001046_000000_release_BTSSM_downloadable_A54.zi
├── SBTS25R1_ENB_0000_001046_000000_release_BTSSM_downloadable_A54.zi
├──
SBTS25R1_ENB_0000_001046_000000_release_BTSSM_downloadable_A54.zip.me
├── SBTS24R1_ENB_0000_001093_000000_release_BTSSM_downloadable_A52.zi
├── SBTS24R1_ENB_0000_001093_000000_release_BTSSM_downloadable_A52.zi
├──
SBTS24R1_ENB_0000_001093_000000_release_BTSSM_downloadable_A52.zip.me
└── ...
```

□□□□□□□□□□□□□□□□□

- `.zip` - □□□
- `.md5` - □□□ MD5 □□□
- `.metadata.json` - □□□□□□□□□□□□

□□□□□□□

□ `config/runtime.exs` □□□□□□□□□□

```
config :ran_monitor,
  firmware_storage_path: "/data/firmware/nokia"
```

□□	□□	□□	□□	��□
`firmware_storage_path`	□□□	□	`/var/firmware/nokia`	□□□□

□□□□□□□ □□ `.zip` □□□□□□□□□□□□

□□□□□□□□ 15 GB

□□□□□□□□

- □□□□□□□□□□□15.37 MB/s□
- □□□□□□
- □□□□ / □□□
- □□□□□□□□ETA□

□□□□□□□ □□□□□□□□□□□□□□□□

```
SBTS<release>_ENB_<build>_<variant>_release_BTSSM_downloadable_<suffi
```

□□□ `SBTS25R1_ENB_0000_001046_000000_release_BTSSM_downloadable_A54.zip`

□□□□

□□□□□□□□□□□□□□□

□	□□
□□□	□□□□□□□□□□
□□	□□□□□□□□□□□□SBTS25R1□
□□□□	□□□□□□□□□□□□□□□□□□
□□	□□□□□□□□□□□□□
□□	□□□□□□□□□□□□
MD5	MD5 □□□□□□□□□
□□□□	□□□□□□□□
□□	□□ URL□□□□□□□□

□□□□□

□□□□□□□□ □□ □□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□

□□	□□
□□□	□□□□□□□□
□□	□□□□□□□□□□□□SBTS25R1□
□□□□	□□□□□□□□□□
□□	□□□□
□□□□	□□□□□ RAN Monitor □□□
□□□□	□□□□□□□□□□□□□□□□FTM_SBTS25R1_2025.05.27_0097□
PS □□	□□□□□□□□□□
□□□□	Linux □□□□
LTE □□	LTE □□□□□□□□□FL19A□
WCDMA □□	WCDMA □□□□□□□□□WBTSFP20C□
□□□□□□□	□□□□□□□□□□ASCE□ASCF□FCTJ □□
MD5 □□□	□□□□□□□□□
□□ **URL**	□□□□□□□□ URL

□□□□□□□□□□□□□□□

□□□□

□□	□□
□□	□□□□□□□□□□□□□□□□
□□ **URL**	□□□□□□ URL □□□□□□□
□□	□□□□□□□□□
□□	□□□□□□□□□□□

□□ URL □

□□□□□□□□□□□□□□□□□□ URL□

```
http://<ran-monitor-ip>:4000/firmware/nokia/<filename>.zip
```

□ URL □□□ WebEM □“□□□□□”URL □□□□

MD5 □□□

□□□□

□□□□□□□□□□MD5 □□□□□□□□□□□□□□□□□□□□□□□□□□□ `.md5` □□□□□□□□□□□□□□

□□□□□

□□□□□□□□□□□□□□□ `.md5` □□□

```
/var/firmware/nokia/
├── SBTS25R1_ENB_0000_001046_000000_release_BTSSM_downloadable_A54.zi
└──
SBTS25R1_ENB_0000_001046_000000_release_BTSSM_downloadable_A54.zip.mc
```

`.md5` □□□□□□□□□□□□□□□□

```
a1b2c3d4e5f6789012345678abcdef01
```

□□

□□ MD5 □□□□□□□□□□□□□□□□

Linux/macOS:

```
md5sum
SBTS25R1_ENB_0000_001046_000000_release_BTSSM_downloadable_A54.zip
```

Windows□PowerShell□□

```
Get-FileHash -Algorithm MD5
SBTS25R1_ENB_0000_001046_000000_release_BTSSM_downloadable_A54.zip
```

□□□□□□□□□□

□□□□

- □□□□□□□□ RAN Monitor
- □□□ RAN Monitor □□□□□□□□
- □□□□ WebEM □□

□□□□


□□□
RAN Monitor
□□ WebEM
□□□□□□
□□□□□□□□□ MD5
□□□□□ URL
□□□□□□□□
□□“□□□□□□”
□□ URL
□□□□□□
□□□□□□□□
□□□□□□□□
□□ SW □□□□□□
□□□□□□
□□□□□
HTTP GET □□
□□□□□□□□□□
□□□□□□
□□□
RAN Monitor
□□ WebEM

□□□□

1. □□□□□ RAN Monitor

□□□□□□□□□□□□□□□□□□

- □□ `https://<ran-monitor-ip>:9443/nokia/firmware`
- □□ `.zip` □□□
- □□□□□□□□□□□□□□□□□□□□ MD5

2. □□□□ URL

□□□□□□□ □□ **URL**□URL □□□□

```
http://<ran-monitor-ip>:4000/firmware/nokia/<filename>.zip
```

3. □□ WebEM □□□□

□□□□□ WebEM □□□

- □□□ □□□□ > □□□□
- □□□□ BTS □□□□□□□□□□□

4. □□□□□□□

□ WebEM □“□□□□□□□□□□□□□□”□□□

1. □□ □□□□□
2. □□□□ URL □□□ **URL** □□
3. □□ □□□□□

WebEM □□□ RAN Monitor □□□□□□□□

5. □□□□□□□□□

1. □ □□□□ □□□□□□□□□□□
2. □□□□□ □□ **SW** □□□□□ □□□□□□
3. □□□□□□□□□□□□ □□□□□□□

4. □□ □□ □□□□□□□□

□□□□□

□□□□□□□

1. □□□□□□□□□ WebEM □□□□ □□
2. □□ RAN Monitor □□□□□□□□□□□□
3. □□ KPI □□□□□□□□□

□□□□□□□□□□□□□□□□□

□□□□□ RAN Monitor □□□□□□□□□□□□□□□□□

□□□□


□□□
RAN Monitor
□□ WebEM
OmniCharge
OmniRAN
Downloads
□□□□
Omnitouch Website
□□□□□□□□ MD5
□□□□ URL
□□□□□□□
□□“□□□□□”
□□ URL
□□□□□
□□□□□□□
□□□□□□□
□□ SW □□□□□
□□□□□
□□□□
HTTP GET □□
□□□□□□□□□
□□□□□
□□□
RAN Monitor
□□ WebEM

□□□□

□□□□□□□□□□□□□□ XML □□□□□□□□□□□□□□□□□□□□ URL □□□□□□

□□□`sw_update.xml`

```
<?xml version="1.0" encoding="UTF-8"?>
<raml xmlns="raml21.xsd" version="2.1">
<cmData type="plan" scope="changes">
<managedObject class="com.nokia.srbts.btsswm:BTSSWM" distName="MRBTS-
operation="update">
  <p name="swPkgUrl">http://{ran-monitor-
ip}:4000/firmware/nokia/SBTS25R1_ENB_0000_001046_000000_release_BTSSM
  <p name="swPkgActivate">true</p>
</managedObject>
</cmData>
</raml>
```

□□□

- `{site_id}` - □□□□□ MRBTS ID□□□□`256`□`2057`□
- `{ran-monitor-ip}` - □□□□□□□ RAN Monitor □ IP □□□□□□

□□□□

1. □□□ RAN Monitor □□□□□□□□
2. □□ □□□□ □□□□□□□
3. □□ `sw_update.xml` □□
4. □□ □□ □□□□□
5. □□ □□ □□□□□

□□□□□□□□□□□□□

□□□□

□□□□□□□□□□□□□□□□□□□□ XML □□□□□□□□ MRBTS ID□□□□□ RAN Monitor □□□□□□□□ API □□□□□□□

□□□□

□□	□□
`swPkgUrl`	□□□□□□□□□ HTTP URL
`swPkgActivate`	□□□ `true` □□□□□□□□□□

□□□□

RAN Monitor □□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□

□□□□□□□□□□□□□□□□

□□	□□
IP □□	□□□□□□□ IP □□
□□□	□□□□□□□□□□□ AirScale □□
□□□	□□□□□□□□□

□□□□□□

□□□□□□□ □□ □□□□□□□□□□□□□□□□□□□□

API □□

□□□□□□

□□ REST API □□□□□□□

□□□ `GET /api/firmware/nokia`

□□□


```
{
  "firmware": [
    {
      "filename": "SBTS25R1_ENB_0000_001046_000000_release_BTSSM_dowr
      "size": 1073741824,
      "size_formatted": "1.0 GB",
      "modified": "2025-01-15T10:30:00Z",
      "download_url": "http://ran-
monitor:4000/firmware/nokia/SBTS25R1_ENB_0000_001046_000000_release_E
      "metadata": {
        "release": "SBTS25R1",
        "build": "0000_001046_000000",
        "variant": "release",
        "suffix": "A54",
        "type": "BTS □□"
      }
    }
  ],
  "stats": {
    "file_count": 3,
    "total_size": 3221225472,
    "total_size_formatted": "3.0 GB",
    "storage_path": "/var/firmware/nokia"
  }
}
```


□□□□□□

□□□ `GET /firmware/nokia/<filename>`

□□□ □□□□□□□□□`Content-Type: application/zip`

□□□□

□□ URL □□

□□□□□□□□□□□□□□□ URL□

```
config :ran_monitor,
  firmware_base_url: "http://ran-monitor.example.com:4000"
```

□□	□□	□□	□□	□□
`firmware_base_url`	□□□	□	`http://localhost:4000`	□□□□ URL □□□□□□ URL□□□□□□ RAN Monitor □□□ □□□□□□□□□/IP□

□□□□□□□ Web UI □□□□ URL □ API □□□ URL□□□□□□□□□□□□□□□□□ HTTP □□□

□□□□

□□□□

□□□ □□□□□□□□□□□□□□□

□□□□□

- □□□□ 15 GB □□□□
- □□□□ `.zip` □□
- □□□□□□□□□□

- □□□□□□□□□□

□□□□□

1. □□□□□□□ 15 GB □□
2. □□□□□□□□ `.zip`
3. □□□□□□□□□ `df -h /var/firmware/nokia`
4. □□□□□□□ `ls -la /var/firmware`

□□□□□

□□ WebEM “□□□□”□□□□□□□

□□□□□

- □□ RAN Monitor □□□□□□□□
- □□□□ HTTP □□ 4000
- URL □□□□□□□ IP □□□□

□□□□□

1. □□□□□□□□□□□□ ping RAN Monitor
2. □□□□□□□□ 4000 □□
3. □□ URL □□□□ IP/□□□□□□□□
4. □□□□□□□□□□□□ URL

MD5 □□“□□□...”

□□ MD5 □□“□□...”□□□□

□□□□□

- □□□□□□□□□□□
- □□□□□□□□□□ `.md5` □□□

□□□□□

1. □□□□□□□□□□□□□□□□□□

2. 点击 刷新 以重新加载页面
3. 检查存储目录权限，允许文件创建

文件已存在错误

症状：上传失败，显示“已存在”错误

解决方案：

1. 如果打算替换，请删除现有文件
2. 如果需要两个版本，请重命名新文件
3. 验证您没有意外重新上传相同的文件

□□□□ RAN Monitor

RAN Monitor □□□□□□□□□□□□

□□□□□□□□□□□□□□□ RAN Monitor

□□

1. □□
2. □□□□
3. □□□□□□□
4. □□
5. □□□□

□□

□□□□□□□□□□ RAN Monitor □□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□□□□

□□□□□□□□□□

- ✓ □□□□□□□□□□□□MySQL□InfluxDB□
- ✓ □□□□□□□□□□□□□□ RAN Monitor
- ✓ □□ RAN Monitor □□□□
- ✓ □□□□□□□□ Nokia AirScale □□
- ✓ □□□□□□□□ InfluxDB
- ✓ □□ Web UI □□□

□□□□□ □□□□□□□□ 30-60 □□

先决条件

在部署 RAN Monitor 之前，请确保您具备以下条件：

基础设施要求

MySQL 数据库服务器

版本：MySQL 5.7+ 或 MariaDB 10.3+
访问：来自 RAN Monitor 服务器的网络连接权限：CREATE、SELECT、INSERT、UPDATE、DELETE 权限
数据库：为 RAN Monitor 创建的空数据库
推荐：专用数据库实例或模式

InfluxDB 时间序列数据库

版本：InfluxDB 1.8+ 或 2.0+
访问：来自 RAN Monitor 服务器的网络连接
Bucket/数据库：已创建并准备好用于存储指标
API 令牌：具有写入权限的令牌（InfluxDB 2.x）
存储：足够的磁盘空间以满足您的保留策略

RAN Monitor 服务器

操作系统：Linux（Ubuntu 20.04+，CentOS 8+ 或类似） RAM：最低 4GB，推荐 8GB
CPU：最低 2 核心，推荐 4+ 核心
磁盘：应用程序和日志最低 20GB
网络：与基站、MySQL 和 InfluxDB 的连接

网络要求

网络连接

RAN Monitor → Nokia AirScale 基站（端口 8080）
Nokia 基站 → RAN Monitor（端口 9076 用于 Webhook）

RAN Monitor → MySQL（端口 3306）
RAN Monitor → InfluxDB（端口 8086）
操作员 → RAN Monitor Web UI（端口 9443）

防火墙规则

允许端口 8080 的入站（基站通信）
允许端口 9076 的入站（Webhook 接收器）
允许端口 9443 的入站（HTTPS Web UI）
允许出站到 MySQL 和 InfluxDB

Nokia 基站要求

对于每个基站：

IP 地址 - 基站可访问的网络地址
端口 - 管理接口端口（通常为 8080）
凭据 - 用于 WebLM 身份验证的用户名和密码
网络路由 - 验证连接性（ping 应成功）
管理接口 - 已启用并可访问

管理者身份验证密钥

私钥 - 用于管理者身份验证（PEM 格式）
公钥证书 - 管理者身份证书（DER 格式）
由 Nokia 提供或使用 OpenSSL 生成

Grafana（可选但推荐）

版本：Grafana 8.0+
访问：与 InfluxDB 的网络连接
目的：分析仪表板和警报

□□□□□□

□ 1 □□□□□□□□

1.1 □□ MySQL □□□

□ RAN Monitor □□□□□□

```
CREATE DATABASE ran_monitor CHARACTER SET utf8mb4 COLLATE
utf8mb4_unicode_ci;
```

□□□□□□□□□□□□□□□

```
CREATE USER 'ran_monitor_user'@'%' IDENTIFIED BY
'secure_password';
GRANT CREATE, SELECT, INSERT, UPDATE, DELETE ON ran_monitor.* TO
'ran_monitor_user'@'%';
FLUSH PRIVILEGES;
```

□□□□ RAN Monitor □□□□□□□□

```
mysql -h <mysql-host> -u ran_monitor_user -p ran_monitor
```

1.2 □□ InfluxDB

□□ InfluxDB 1.x□□□□□□

```
influx -execute 'CREATE DATABASE "nokia-monitor"'
```

□□ InfluxDB 2.x□□□□ bucket□

```
influx bucket create -n nokia-monitor -o your-org
```

□□□□□□□□□□ API □□□InfluxDB 2.x□□

```
influx auth create --org your-org --write-buckets
```

□□□□□□□□□□□□

1.3 □□□□□□

□□□□□□□□□□□□□□□

```
# □□□□□□□□□□□□
ping 10.7.15.66

# □□□□□□□□□□□□□
telnet 10.7.15.66 8080
```

□□ MySQL □ InfluxDB □□□□□□

```
# □□ MySQL □□□
telnet <mysql-host> 3306

# □□ InfluxDB □□□
curl http://<influxdb-host>:8086/ping
```

□ 2 □□□□ RAN Monitor

□□□□□□ `config/runtime.exs` □□□□□□

2.1 □□□□□

□□ `config/runtime.exs` □□□ MySQL □□□

```
config :ran_monitor, RanMonitor.Repo,
  username: "ran_monitor_user",
  password: "secure_password",
  hostname: "mysql-host",
  database: "ran_monitor",
  stacktrace: true,
  show_sensitive_data_on_connection_error: true,
  pool_size: 10
```

2.2 InfluxDB □□

□□ InfluxDB □□□

```
config :ran_monitor, RanMonitor.InfluxDbConnection,
  auth: [
    username: "monitor",
    password: "influx_password"  # □ InfluxDB 2.x □ API □□
  ],
  database: "nokia-monitor",
  host: "influxdb-host"
```

2.3 Web □□□

□□ Web □□□

```
# □□□□□□ SOAP/API □□
config :ran_monitor, RanMonitor.Web.Endpoint,
  http: [ip: {0, 0, 0, 0}, port: 8080],
  check_origin: false,
  secret_key_base: "generate_with_mix_phx_gen_secret",
  server: true

# □□□□□ Web UI□HTTPS□
config :control_panel, ControlPanelWeb.Endpoint,
  url: [host: "0.0.0.0", port: 9443, scheme: "https"],
  https: [
    ip: {0, 0, 0, 0},
    port: 9443,
    keyfile: "priv/cert/omnitouch.pem",
    certfile: "priv/cert/omnitouch.crt"
  ]

# □□□□□□ Webhook □□
config :ran_monitor, RanMonitor.Web.Nokia.Airscale.Endpoint,
  url: [host: "0.0.0.0"],
  http: [ip: {0, 0, 0, 0}, port: 9076],
  server: true
```

2.4 Nokia □□

□□□□□□□□□□□□□□□□

```
config :ran_monitor,
  general: %{
    mcc: "001",  # □□□□□□□□□
    mnc: "001"   # □□□□□□□□□
  },
  nokia: %{
    ne3s: %{
      webhook_url: "http://<ran-monitor-ip>:9076/webhook",
      private_key: Path.join(Application.app_dir(:ran_monitor,
"priv"), "external/nokia/ne.key.pem"),
      public_key: Path.join(Application.app_dir(:ran_monitor,
"priv"), "external/nokia/ne.cert.der"),
      reregister_interval: 30
    },
    airscales: [
      %{
        address: "10.7.15.66",
        name: "Site-A-BS1",
        port: "8080",
        web_username: "admin",
        web_password: "password"
      }
    ]
  }
```

2.5 □□ SSL □□□□□□□□

□□ HTTPS Web UI□□□ SSL □□□

```
# □□□□□□□□□□/□□
openssl req -newkey rsa:2048 -nodes -keyout
priv/cert/omnitouch.pem \
  -x509 -days 365 -out priv/cert/omnitouch.crt
```

□□□□□□□□□□ CA □□□□□□

□□□□□□□□□□□□□ □□□□□□□□

□ 3 □□□□□□

□□□□□□□□ RAN Monitor□

3.1 □□□□□□□

□□□□□□□□□

```
mix ecto.migrate
```

□□□□□□□□□□□□□□□□□□□□

3.2 □□ RAN Monitor

□□□□□□□

```
mix phx.server
```

□□□□□□□□

```
MIX_ENV=prod mix release
_build/prod/rel/ran_monitor/bin/ran_monitor start
```

3.3 □□□□□□

□□□□□□□□□□□□□

```
[info] Running RanMonitor.Web.Endpoint with cowboy
[info] Running ControlPanelWeb.Endpoint with cowboy
[info] Running RanMonitor.Web.Nokia.Airscale.Endpoint with cowboy
[info] Starting RAN Monitor Manager
[info] Connecting to InfluxDB...
[info] InfluxDB connection established
[info] Attempting registration with device: Site-A-BS1
[info] Successfully registered with Site-A-BS1
```

□□□

- Web □□□□□
- □□□□□□□□□
- InfluxDB □□□□□
- □□□□□□

□□

□ 4 □□□□□□

□□□□□□□□□□□□

4.1 □□ Web UI □□□

□□□□□□□□□□□

```
https://<ran-monitor-ip>:9443
```

□□□□□ RAN Monitor □□□□□

4.2 □□□□□□

□ Web UI □□

1. □□□ □□ □□
2. □□□□□□□□□□□□□□□□
3. □□□□□□“□□□”□□□□
4. □□□□□□“□□□”
5. □□□□□□□□□□□□□□□□□

□□□□□□□/□□□□□□□

- □□□□□□□□
- □□□□□□
- □□□□□□□□□□
- □□□□□□□□□□

4.3 □□□□□□□□ InfluxDB

□ Web UI □□

1. □□□ **InfluxDB** □□ □□
2. □□□□□□□□□
3. □□□□□□□□□
4. □□“□□□□”□“□□”□“□□”□□

□□□□□□□ InfluxDB□

```
# InfluxDB 1.x
influx -database 'nokia-monitor' -execute 'SELECT COUNT(*) FROM
PerformanceMetrics'

# InfluxDB 2.x
influx query 'from(bucket:"nokia-monitor")
  |> range(start: -1h)
  |> filter(fn: (r) => r._measurement == "PerformanceMetrics")
  |> count()'
```

4.4 □□□□□□

□□□□□□□□□□□□□□□□

□ Web UI □□

1. □□□ □□□□ □□
2. □□“□□”□□
3. □□□□□□□□□

□□□□□□□ `mix phx.server` □□□□□□□□□□□□□

4.5 □□□□□□□□

□ Web UI □□

1. □□□□□□□□□□□□
2. □□□
    - □□□□□□□□□□

- □□□□□□□□□□□□□
- □□□□□□□□□□
- □□□□□□□□□

□□□□

□□ RAN Monitor □□□□□□□□□□□□□□□□□□□□

□□□□

1. □□□□□□□

   - □ `config/runtime.exs` □□□□□□□□
   - □□□□□□□□□□□□□□□□
   - □□□ □□□□□□□

2. □□ **Grafana** □□□

   - □□□□□□□□□□□ Grafana
   - □□ InfluxDB □□□
   - □□□□□□□□□
   - □□□ Grafana □□□□

3. □□□□□□□

   - □□□□□□□□□□
   - □□□□□□□□□□□□□
   - □□□ □□□□□□□□□

4. □□□□□□□□

   - □ Web UI □□□□□□□□
   - □□ Grafana □□□□
   - □□□□□□□
   - □□□ □□□□□□□

操作准备

文档审查：

阅读 Web UI 指南 以了解日常操作
审查 常见操作指南 以了解例行任务
学习 故障排除指南 以解决问题

团队培训：

与操作团队一起浏览 Web UI
练习常见工作流程（每日健康检查、警报调查）
审查关键警报的升级程序

监控设置：

在 Grafana 中创建操作仪表板
为关键指标设置警报规则
配置通知渠道（Slack、电子邮件、PagerDuty）

安全加固：

用 CA 签名的证书替换自签名证书
将凭据移至环境变量
限制 config/runtime.exs 的文件权限
配置防火墙规则

生产部署

生产前：

首先在暂存环境中测试
验证所有基站成功连接
确认指标准确
测试警报通知
记录任何自定义配置

生产启动：

在维护窗口期间部署
在前 24 小时内密切监控
准备回滚计划
保持支持联系可用

持续操作：

通过 Web UI 进行每日健康检查
每周审查警报趋势
每月使用 Grafana 进行容量规划
定期备份配置

获取帮助

故障排除资源

故障排除指南 - 常见问题和解决方案
Web UI 指南 - 控制面板参考
应用日志页面 - 实时系统日志

文档

操作指南 - 完整的操作参考
运行时配置指南 - 配置详细信息
AirScale 配置 - 基站设置

常见首次问题

基站未注册：

验证网络连接（ping）
检查凭据是否正确

- □□□□ 8080 □□□□□
- □□□□□□□□□□

InfluxDB □□□□□

- □□ InfluxDB □□□□□□
- □□□□□□□□□
- □□ API □□□□□□□□
- □□□□□□ `curl http://<influxdb-host>:8086/ping`

Web UI □□□□

- □□ HTTPS □□ 9443 □□□□
- □□ SSL □□□□□□
- □□□□□□□ Web □□
- □□□□□□□□□□

□□□

- □□□ - □□□□□□□
- **Web UI □□** - □□□□□□□□
- □□□□□□ - □□□
- □□□□□□□ - □□□
- **AirScale □□** - □□□
- **Grafana □□□** - □□□□□
- □□□□□ - □□□
- □□□□□□□ - □□□
- □□□□□□ - □□□

Grafana □□□□□□□

□□□□ **RAN** □□□□□□□□□□□□

Grafana □□□□□□□□□□ KPI □□□□□□□□□

□□

1. □□
2. Grafana □ InfluxDB □□
3. □□□□□
4. □□□□□□□□
5. □□□□
6. □□□□□□□□
7. □□□□□
8. □□□□

□□

Grafana □□□□□□□□□□□□□□□ RAN □□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□


□□
Slack
□□□□
PagerDuty
□□□□
□□□□□□
□□
□□
□□
□□
Grafana
□□□□□□□
□□□□
□□
□□□□
Nokia AirScale
□□
NE3S
RAN Monitor
□□□
□□□□
□□
InfluxDB
□□□□□□□□

Grafana □□□

- □□□□□ - □□□□□□□□□□□□□□□□
- □□□□ - □□□□/□□/□□□□□□□□
- □□ - □□□□□□□□□□□□□
- □□□□□ - □□□□□□□□□□□□□□□□□□□□□□
- □□ - □□□□□□□□□

仪表板定制

重要：本指南中描述的仪表板和可视化是 示例和模板。运营/NOC (ONS) 团队 将根据其特定的操作要求、KPI 和监控工作流程设计和构建 Grafana 仪表板。

本指南提供：

查询示例和可供构建的模式
仪表板组织的最佳实践
警报配置模板
计数器参考映射（请参见 Nokia 计数器参考）

ONS 团队应定制：

面板布局和可视化
警报阈值和升级策略
其数据量的保留策略（请参见 数据保留政策）
基于监控需求的聚合窗口
通知渠道和路由

有关运行时配置选项和数据收集设置，请参阅 运行时配置指南。

Grafana 和 InfluxDB 设置

安装

先决条件：

InfluxDB 2.0+，为 RAN Monitor 创建了存储桶
具有读取权限的 InfluxDB API 令牌
Grafana 和 InfluxDB 之间的网络连接

Docker Compose 示例：

```yaml
version: '3.8'
services:
  influxdb:
    image: influxdb:2.7
    environment:
      INFLUXDB_DB: ran_metrics
      INFLUXDB_ADMIN_USER: admin
      INFLUXDB_ADMIN_PASSWORD: change_me
    ports:
      - "8086:8086"
    volumes:
      - influxdb_data:/var/lib/influxdb2

  grafana:
    image: grafana/grafana:latest
    environment:
      GF_SECURITY_ADMIN_PASSWORD: change_me
    ports:
      - "3000:3000"
    depends_on:
      - influxdb
    volumes:
      - grafana_data:/var/lib/grafana
      - ./provisioning:/etc/grafana/provisioning

volumes:
  influxdb_data:
  grafana_data:
```

□□ InfluxDB API □□

1. □□ InfluxDB UI□□□ 8086□
2. □□□ API □□
3. □□□□

□□□□□

□ Grafana □□□ InfluxDB □□□□□

1. □□□□□
   - Grafana → □□ → □□□
2. □□□□□□
   - □□“□□□□□”
   - □□“InfluxDB”
3. □□□□

□□	□	□□
□□	RAN Monitor	Grafana □□□□□□
URL	`http://influxdb:8086`	□□□□□ Grafana □□
□□	□□□□□□□	Grafana □□□□□□□
□□	omnitouch	□□ InfluxDB □□
□□	□API □□□	□□ API □□□□
□□□□	ran_metrics	RAN Monitor □□□□□
□□□□□	10s	□□□□□□

4. □□□□
   - □□“□□”□□
   - □□□“□□□□□□□”

□□□ InfluxDB □□□□□URL□□□□□□□□□□□□□ RAN Monitor □□□□□□□ InfluxDB □□□□□□□□ □□□ □□□□□□□ □ AirScale □□ □□□□□□□□□□

Flux □□□□

Grafana □□ Flux □□ InfluxDB□□□□□□

```
from(bucket:"ran_metrics")
  |> range(start: -7d, stop: now())
  |> filter(fn: (r) => r._measurement == "PerformanceMetrics")
  |> filter(fn: (r) => r.device == "SITE_A_BS1")
  |> group(by: ["_field"])
  |> aggregateWindow(every: 1h, fn: mean)
```

□□□□□

- `from()` - □□□□□
- `range()` - □□□□
- `filter()` - □□□□
- `group()` - □□□□
- `aggregateWindow()` - □□□□□

□□□□□□□□

□□□□□□□□


□□□□
(CEO/□□)
□□
□□□□□□
(NOC □□)
□□
□□
□□□□□□□
(□□□□□□)
□□□□□□□□□
(□□□□□)

□□□□□□□□



□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□

```
┌──────────────────────────────────────────────────────┐
│ □□□□□□□□                                  │
├──────────────┬──────────────┬────────────────────────┤
│ □□□□□      │ □□□□□      │ □□□□□□□□□   │
│ 48/50 (96%)  │ 3 □□□□□□ │ 98.5%            │
├──────────────┴──────────────┴────────────────────────┤
│ □□□□□□ [2□□□] □□□                        │
└──────────────────────────────────────────────────────┘
```

□□□

- □□□□□□□□□< 10 □□□□
- □□/□□□□□□□□□□□□□□

- □□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□□

```
┌──────────────────────────────────────────────────────┐
│ □□□□□□7 □□                                  |
│ [□□□□□□□□□□/□□□□□]                  |
│ □□□250 Gbps□□□□□□□ 2 □□                |
│ □□□80 Gbps□□□□□□□ 3 □□                 |
└──────────────────────────────────────────────────────┘
```

□□□

- □□□□□□□
- □□□□□□□
- □□□□□□□
- □□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□□□□

```
┌──────────────────────────────────────────────────────┐
│ □□□□□□□□□□□□□□□□                        |
├──────┬──────────────┬──────────┬──────────────┤
│ □□ | □□         | □□       | □□□□   |
├──────┼──────────────┼──────────┼──────────────┤
│ □    | SITE_A_BS1   | □□□□   | 45 □□   |
│ □    | SITE_B_BS2   | □□       | 2 □□    |
└──────┴──────────────┴──────────┴──────────────┘
```

□□□

- □□□□□□□
- □□□□□□□
- □□□□□□□□□□□□□□□□

□□□□

□□□ □□□□□□□□ Nokia □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ Nokia □□□□□□□□□□□□□□□□□□□□

- □□□□□□□□□□□□□
- □□□□□□□□□□□□

□□□□□□□□□□□□□

```
from(bucket:"ran_metrics")
  |> range(start: -1h)
  |> filter(fn: (r) => r._measurement == "PerformanceMetrics")
  |> filter(fn: (r) => r._field == "DLResourceUtilization")
  |> filter(fn: (r) => r.device == "SITE_A_BS1")
  |> aggregateWindow(every: 10s, fn: last)
  |> yield(name: "dl_resource")
```

□□□

- □□□□□□□□
- □□□ 80% □□□□□□□95% □□□□□□□
- □□□□□□□□□□

□□□□

□□□□□□□□□□□□□□□□ **24** □□□

```
from(bucket:"ran_metrics")
  |> range(start: -24h)
  |> filter(fn: (r) => r._measurement == "Alarms")
  |> filter(fn: (r) => r.status == "active")
  |> group(by: ["severity"])
  |> count()
  |> yield(name: "alarm_count")
```

□□□

- □□□□□□□□□□□□□
- □□□□□□□
- □□□□□□□□□□□

□□□□□□□□□□□□□

```
from(bucket:"ran_metrics")
  |> range(start: -7d)
  |> filter(fn: (r) => r._measurement == "Alarms")
  |> group(by: ["severity"])
  |> aggregateWindow(every: 1h, fn: count)
  |> yield(name: "alarm_rate")
```

□□□

- □□□□□□□□□□□□□□□□
- □□□□□□□□□□
- □□□□□□□□□

□□□□□□□

```
from(bucket:"ran_metrics")
  |> range(start: -7d)
  |> filter(fn: (r) => r._measurement == "Alarms")
  |> group(by: ["alarm_description"])
  |> count()
  |> sort(columns: ["_value"], desc: true)
  |> limit(n: 10)
  |> yield(name: "top_alarms")
```

□□□

- □□□□□□□□□
- □□□□□□□□□
- □□□□□□□□□

□□□□

□□□□□□□□□□□□□□□

```
from(bucket:"ran_metrics")
  |> range(start: -30d)
  |> filter(fn: (r) => r._measurement == "PerformanceMetrics")
  |> filter(fn: (r) => r._field == "CellAvailability")
  |> filter(fn: (r) => r.device == "SITE_A_BS1")
  |> aggregateWindow(every: 1h, fn: mean)
  |> statefulWindow(every: 1h, period: 24h)
    |> map(fn: (r) => ({r with _value: float(v: r._value)}))
    |> reduce(fn: (r, acc) => ({
        x: acc.x + [float(v: r._time)],
        y: acc.y + [r._value]
      }),
      initial: {x: [], y: []})
    |> yield(name: "availability_forecast")
```

□□□

- □□ SLA □□□□□□□□□
- □□□□□□□
- □□□□□

□□□□□□□□□□□□□□□

```
from(bucket:"ran_metrics")
  |> range(start: -7d)
  |> filter(fn: (r) => r._measurement == "PerformanceMetrics")
  |> filter(fn: (r) => r._field =~ /HandoverSuccess|Traffic/)
  |> group(by: ["device", "_field"])
  |> aggregateWindow(every: 1h, fn: mean)
  |> pivot(rowKey: ["_time"], columnKey: ["_field"], valueColumn:
"_value")
  |> map(fn: (r) => ({r with correlation: float(v:
r.HandoverSuccess) * float(v: r.Traffic)}))
  |> yield(name: "ho_traffic_correlation")
```

□□□

- □□□□□□□□□□□□□□□
- □□□□□□□□□

- □□□□□□□

□□□□□□□□

□□□□□□□



□ Grafana □□□□□□□□

□ **1** □□□□□□□□□

1. □□□□□
2. □□□□□□□□
3. □□ → □□□□
4. □□□□ → □□□□ → □□□□□□□

□ **2** □□□□□□□□□

□□ **1**□□□□□□□□

```
□□□CellAvailability < 95%
□□□□□□15 □□
□□□□□□□ 1 □□
□□□□□□ 15 □□
```

□□□

- □ 95% □□□□□□□ SLA □□□99.5%□□□□□□□□
- 15 □□□□□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□

□□ **2**□□□□□□□

```
□□□count(active_alarms) > 10
□□□□□□5 □□
□□□□□□□ 2 □□
□□□□□□ 5 □□
```

□□□

- 10 □□□□□□□□□□□□□□□
- □□ 5 □□□□□□□□□□□□
- □□□□□□□□□□

□□ **3**□□□□□□□

```
□□□DLResourceUtilization > 90%
□□□□□□30 □□
□□□□□□□ 5 □□
□□□□□□ 30 □□
```

□□□

- □□□□□□□□□□□□□
- 30 □□□□□□□□□□□□□□□□□□□□□□
- □ 5 □□□□□□□□□□□□□

□ **3** □□□□□□□□□

1. □□“□□□□”
2. □□□□□□□□□Slack□□□□□□□PagerDuty □□
3. □□□□□□□

□□□□□□□□

```
□□□{{ .AlertRuleName }}
□□□□{{ .Severity }}
□□□{{ .Labels.device }}
□□{{ .EvalMatches[0].Value }}
□□□□□{{ .StartsAt }}

{{ .RuleUrl }}
```

□□□□

□ **1** □□□□□□□□□

- □□□ □□□□□□□□□□□SLA □□□□□□□□
- □□□□□ □□□1-5 □□□
- □□□ □□ + □□ + Slack + PagerDuty
- □□□□ □□□□□
- **SLA**□ < 15 □□□□□

□ **2** □□□□□□□□□

- □□□ □□□□□□□□□□□□□□□□□□
- □□□□□ 15-30 □□
- □□□ Slack + □□□□ + PagerDuty
- □□□□ NOC □□ + □□□□□
- **SLA**□ < 30 □□□□□

□ **3** □□□□□□□□□

- □□□ □□□□□□□□□□□□□
- □□□□□ 1+ □□

- □□□ Slack + □□□
- □□□□ □□□□ / □□
- **SLA□ □□□□**

□□□□

Slack □□

```
1. □□□□□□□□ Slack □□
2. □□□□□□□ URL
3. □ Grafana □□ → □□□□
4. □□"Slack"□□
5. □□□□□□□ URL
6. □□□□
```

Slack □□□□□

```
□ □□□□□□□□ - SITE_A_BS1_Cell1
□□□□□45 □□
□□□~2000 □□□
□□□□□□□□□□ 2:15

[□□] [□□] [□□□]
```

PagerDuty □□

```
1. □ PagerDuty □□□□□□□□
2. □ Grafana □□ → □□□□
3. □□"PagerDuty"□□
4. □□□□□□
5. □□□□□□□□
   - □□ → □□□□
   - □□ → □□□□□□□□
   - □□ → □□□□□□□
```

□□□□□□

```
1. □ Grafana □□□□□□ SMTP
2. □□□ → □□□□
3. □□“□□□□”□□
4. □□□□□□□□
5. □□□□□□□□ CSV □□□□□□□□
```

□□□□

□□□ 1□□□□□□□□

□□□ □□□□□□□
□□□□□ 5 □□
□□□ □□□□□□□

□□□

1. □□□□□**4** □□□□□□□
    - □□□□ / □□
    - □□□□□□□□□□□□□□
    - □□□□□□□□□%□
    - □□□□□□□□Gbps□
2. □□□□□□□□□□□
    - □□□□□□□□□7 □□
    - □□□□□□7 □□
    - □□□□□□□
3. □□□□□□□□
    - □□□□□□□□□□□□□□□□□□
    - □□ 7 □□□□□□□□
4. □□□□□□□□□□

- □□□□□□□□□□□□□□
- □□□□□□□→ □□□□□□□→ □□□□□□□

□□□□□□□

□□PRB □□□□□□□□□□□□

□□□ 2□NOC □□□□□

□□□□ □□□□□□□□□□
□□□□□□ 10 □
□□□□□ □□□□□□□

□□□□

1. □□□□□□□□□□

   - □□□□□□□□□□□□□□□□□□□□□□□□
   - □□□□□□□□□□□□□□□□□□

2. □□□□□□□□□□□

   - □□□□□ %□□□□□□
   - □□□□□ %□□□□□□

设备的 CPU %

3. 流量概述（面积图）

下行/上行吞吐量（过去 24 小时）
当前与 24 小时平均值
峰值小时指示

4. 警报趋势（条形图）

按严重性计数（过去一小时，滚动）
堆叠条形图显示分布

5. 设备状态（快速查看）

设备名称、IP、状态（绿色/红色）
最近指标更新时间戳
链接到设备特定仪表板

6. 最近事件（时间序列）

警报出现/清除
配置更改
会话状态变化

示例仪表板：

示例显示 4G 状态概览，包括地理地图、按严重性级别的警报表和性能统计。

仪表板 3：工程深度分析

受众：网络工程师
刷新频率： 1 分钟
目的：详细技术分析

面板：

1. 流量模式分析（多系列）

下行/上行按站点比较
基线 + 当前叠加
每日时段季节性

2. 小区质量指标（多系列）

SINR 分布（直方图）
RSRP 分布（直方图）
切换成功率趋势

3. 无线性能（时间序列）

- RLC □□□□□□□□□
- RRC □□□□□
- □□□□□

4. □□□□□□□□□

- □□□□□□□□□□□□□□□
- □□□□□□□□□□

5. □□□□□□□□□□□

- □□□□□□□□
- □□□□□□□□
- □□□□□□□□□

□□□ 4□□□□□□□□

□□□ □□□□□□□□□□□
□□□□□ 5 □
□□□ □□□□□□□□□

□□□

1. □□□□□□□□□

- □□□□□□□□□
- □□□□□□□□□□□□/□□□□□□□

2. □□□□□□□□□□□□

- □□□□□□□□□□
- □□□□□□□□□□□□□

3. □□□□□□□□□□

- □□□□□□□□
- □□□□□□□□□□
- □□□□□□□□□

4. 最近更改（表格）

最近 4 小时内的配置更改
软件版本
参数修改

5. 类似问题（表格）

最近 30 天内的相同问题类型
解决时间
确定的根本原因

6. 升级路径（文本面板）

下一级升级联系人
维护窗口信息
相关票据/事件编号

仪表板 5：Nokia AirScale 详细性能

受众： RF 工程师、性能分析师
刷新频率： 30 秒
目的：深入了解 Nokia 特定指标和 KPI

该仪表板使用 Nokia 特定的性能计数器提供 AirScale 基站性能的全面可见性。有关详细计数器定义，请参见 Nokia 计数器参考。

面板 1：资源利用率概述（仪表）

显示当前 PRB（物理资源块）使用情况：

```
// □□ PRB □□
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8011C37")
  |> filter(fn: (r) => r._field == "counterValue")
  |> group()
  |> mean()
  |> map(fn: (r) => ({ r with _value: r._value / 10.0}))  // □□□□□
□
  |> rename(columns: {_value: "□□ PRB □□"})

// □□ PRB □□
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8011C24")
  |> filter(fn: (r) => r._field == "counterValue")
  |> group()
  |> mean()
  |> map(fn: (r) => ({ r with _value: r._value / 10.0}))  // □□□□□
□
  |> rename(columns: {_value: "□□ PRB □□"})
```

□□□□ □□□□□□□□□□

- □□□0-70%
- □□□70-85%
- □□□85-100%

□□ **2**□□□□□□□□□□□□□

□□ PDCP □□□□□□□□□□□□

```
// □□□□□
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8012C26")
  |> filter(fn: (r) => r._field == "counterValue")
  |> map(fn: (r) => ({ r with _value: r._value / 1000.0}))  // □□□
Mbps
  |> rename(columns: {_value: "□□ Mbps"})

// □□□□□
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8012C23")
  |> filter(fn: (r) => r._field == "counterValue")
  |> map(fn: (r) => ({ r with _value: r._value / 1000.0}))  // □□□
Mbps
  |> rename(columns: {_value: "□□ Mbps"})
```

□□□□□□□□

- **M8012C26** - PDCP □□□□□□□□□□□□□/□□
- **M8012C23** - PDCP □□□□□□□□□□□□□/□□

□□ 3□□□ **UE** □□□□□□□□□

□□□□□□□□□□□

```
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8018C1")
  |> filter(fn: (r) => r._field == "counterValue")
  |> rename(columns: {_value: "□□□ UE"})
```

□□□□□□□□

- **M8018C1** - □□ eNB □□□ UE □□□□□□

□□ **4**□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□

```
import "strings"

from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8020C3" or
                       r["metricCounter"] == "M8020C6" or
                       r["metricCounter"] == "M8020C4")
  |> filter(fn: (r) => r._field == "counterValue")
  |> filter(fn: (r) => strings.containsStr(v: r["DN"], substr:
"${CellKey}"))
  |> group()
  |> pivot(rowKey:["_time"], columnKey: ["metricCounter"],
valueColumn: "_value")
  |> map(fn: (r) => ({
      _time: r._time,
      "□□□□□": 100.0 * r.M8020C3 / (r.M8020C6 - r.M8020C4)
    }))
```

□□□□□□□

- **M8020C3** - □□□□□□□□□
- **M8020C6** - □□□□□□□
- **M8020C4** - □□□□□□□□□□□

□□□□ □□□□□ < 99%

□□ **5**□□□ **PRB** □□□□□□□□□□□□

□□□□□□□□□□□□□□□□□□□

```
import "strings"

// □□ PRB □□□
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8011C24")
  |> filter(fn: (r) => r._field == "counterValue")
  |> filter(fn: (r) => strings.containsStr(v: r["DN"], substr:
"${CellKey}"))
  |> group()
  |> map(fn: (r) => ({ r with _value: r._value / 10.0}))
  |> rename(columns: {"_value": "□□□□ PRB □□"})

// □��□ PRB □□□
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8011C37")
  |> filter(fn: (r) => r._field == "counterValue")
  |> filter(fn: (r) => strings.containsStr(v: r["DN"], substr:
"${CellKey}"))
  |> group()
  |> map(fn: (r) => ({ r with _value: r._value / 10.0 }))
  |> rename(columns: {"_value": "□□□□ PRB □□"})
```

□□ 6□□□□□□□□□□□□□□□□□□□□

PDCP □□□□□□□□□□

```
import "strings"

// □□ PDCP □□□□□□
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8012C26")
  |> filter(fn: (r) => r._field == "counterValue")
  |> filter(fn: (r) => strings.containsStr(v: r["DN"], substr:
"${CellKey}"))
  |> group()
  |> rename(columns: {"_value": "□□ PDCP □□□"})

// □□ PDCP □□□□□□
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8012C23")
  |> filter(fn: (r) => r._field == "counterValue")
  |> group()
  |> rename(columns: {"_value": "□□ PDCP □□□"})
```

**□□ 7□RSSI□□□□□

```
import "strings"

// □□ RSSI
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8005C0")
  |> filter(fn: (r) => r._field == "counterValue")
  |> filter(fn: (r) => strings.containsStr(v: r["DN"], substr:
"${CellKey}"))
  |> group()
  |> rename(columns: {"_value": "□□ RSSI"})

// □□ RSSI
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8005C2")
  |> filter(fn: (r) => r._field == "counterValue")
  |> filter(fn: (r) => strings.containsStr(v: r["DN"], substr:
"${CellKey}"))
  |> group()
  |> rename(columns: {"_value": "□□ RSSI"})

// □□ RSSI
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8005C1")
  |> filter(fn: (r) => r._field == "counterValue")
  |> filter(fn: (r) => strings.containsStr(v: r["DN"], substr:
"${CellKey}"))
  |> group()
  |> rename(columns: {"_value": "□□ RSSI"})
```

□□□□□□□

- **M8005C0** - PUCCH □□ RSSI□dBm□
- **M8005C1** - PUCCH □□ RSSI□dBm□

- **M8005C2** - PUCCH □□ RSSI□dBm□

□□ **8**□□□□□□□□□□

PDCP SDU □□□□□

```
import "strings"

from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8001C2")
  |> filter(fn: (r) => r._field == "counterValue")
  |> filter(fn: (r) => strings.containsStr(v: r["DN"], substr:
"${CellKey}"))
  |> group()
  |> rename(columns: {"_value": "□□"})
```

□□□□□□□□

- **M8001C2** - PDCP SDU □□□□ DTCH □□□□□□

□□ **9**□**RRC** □□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□

```
import "strings"

from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M8013C5" or
                       r["metricCounter"] == "M8013C17" or
                       r["metricCounter"] == "M8013C18" or
                       r["metricCounter"] == "M8013C19" or
                       r["metricCounter"] == "M8013C34" or
                       r["metricCounter"] == "M8013C31" or
                       r["metricCounter"] == "M8013C21" or
                       r["metricCounter"] == "M8013C93" or
                       r["metricCounter"] == "M8013C91")
  |> filter(fn: (r) => r._field == "counterValue")
  |> filter(fn: (r) => strings.containsStr(v: r["DN"], substr:
"${CellKey}"))
  |> group()
  |> pivot(rowKey:["_time"], columnKey: ["metricCounter"],
valueColumn: "_value")
  |> map(fn: (r) => ({
      _time: r._time,
      "□□□□□": 100.0 * r.M8013C5 / (r.M8013C17 + r.M8013C18 +
r.M8013C19 + r.M8013C34 + r.M8013C31 + r.M8013C21 + r.M8013C93 +
r.M8013C91)
    }))
```

□□□□□□□

- **M8013C5** - □□□□□□□□
- **M8013C17-M8013C93** - □□□□□□□□

□□□□ □□□□ < 95%

□□ **10**□□□ **VSWR**□□□□□□□□□□□□□

□□□□□□□□□□□□□

```
import "strings"

from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M40001C0")
  |> filter(fn: (r) => r._field == "counterValue")
  |> filter(fn: (r) => strings.containsStr(v: r["DN"], substr:
"${RadioKey}"))
  |> map(fn: (r) => ({
      r with
      "DN": strings.split(v: r["DN"], t: "/")[5],
      "VSWR": r._value / 10.0
    }))
  |> group()
  |> pivot(rowKey: ["_time"], columnKey: ["DN"], valueColumn:
"VSWR")
```

□□□□□□□□

- **M40001C0** - □□□□□□□□ VSWR□0.1 □□□

□□□□□ VSWR > 2.0

□□ **11**□□□□□□□□□□

□□□□□□□□

```
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["recordType"] == "performanceMetric")
  |> filter(fn: (r) => r["basebandName"] == "${Airscale}")
  |> filter(fn: (r) => r["metricCounter"] == "M40002C2")
  |> filter(fn: (r) => r._field == "counterValue")
  |> group()
  |> map(fn: (r) => ({ r with _value: r._value / 100000.0 }))
  |> rename(columns: {"_value": "□□"})
```

□□□□□□□□

M40002C2 - 功耗（因子为 100000）

仪表板变量：

该仪表板使用 Grafana 模板变量进行动态过滤：

${Airscale} - 基站选择器（下拉菜单）
${CellKey} - 多小区站点的单元选择器（下拉菜单） ${RadioKey} - VSWR 的无线单元选择器（下拉菜单）

此仪表板的警报规则：

1. 高 PRB 利用率 - 当 DL 或 UL PRB > 85% 持续 5 分钟时触发
2. 低小区可用性 - 当可用性 < 99% 持续 10 分钟时触发
3. 低设置成功率 - 当 RRC 设置成功率 < 95% 持续 5 分钟时触发
4. 高 VSWR - 当任何天线的 VSWR > 2.0 持续 15 分钟时触发
5. 异常功耗 - 当功耗偏离基线 > 20% 时触发

使用此仪表板：

1. 容量分析 - 监控 PRB 利用率以识别接近容量的小区
2. 性能故障排除 - 使用 RSSI、延迟和设置成功率诊断问题
3. 硬件健康 - 跟踪 VSWR 和功耗以进行主动维护
4. 质量保证 - 监控可用性和吞吐量以确保 SLA 合规

请参见 Nokia 计数器参考 以获取完整的计数器定义和使用指南。

示例仪表板 - 详细视图：

Nokia Monitor □□□□□□□ S1 □□□□□□□□□□□□□□□□□□□□ PRB □□□□□□□□□□□□□□□□□

□□□□□ - □□□□□□□PRB □□□□□□□

□□□□□□□□□ LNCEL□□LTE PRB □□□□ TTI□□□/□□□□□ PDCP □□□□□□□□□□□□□□□

□□□□□ - RSSI□□□□□□□ RRC□

RSSI □□□□□/□□/□□□□□□□□□□□□□□□RRC □□□□□□□□□□□ VSWR□RMOD□□□□

□□□□□ - □□□□□□□□

□□□□□□□□ RRC □□□□□□□□□□□□□□□VSWR RMOD □□□□□□□□□□□□□□□□

□□□□□ - □□□□□□ **VSWR** □□□□□

□□□ VSWR RMOD-2 □□□□□□□□□□ANTL-1□ANTL-2□ANTL-3□ANTL-4□□□□□□□□□□□□□□□□□□□□□□□

□□□□

□□□□□□□□□□

□□□

- □□□□□□□□□□□□“□□□”
- □□□□□□□□□

□□□

```
1. □□ InfluxDB □□□□□□□
2. □□□□□□□□ InfluxDB □□□□□□
3. □□□□□□□□□□□□□□□□
4. □□□□□□□□□□□□□□□□□
```

□□□□□

- □ InfluxDB UI □□□□□□□□
- □□□□□□□□□□□□ 24 □□□

- □□□□□□□□□□ RAN Monitor □□□□
- □□□□□□□□□□□□□□□□

□□□□□□□

□□□

- □□□□□□□□ > 5 □
- □□□□□□□□□

□□□

```
1. □□□□□□□□> 8□
2. □□□□□□□/□□□□□□□
3. InfluxDB □□□□
4. □□□□
```

□□□□□

- □□□□□□□
- □□□□□□□□24 □□ vs. 1 □□
- □ InfluxDB □□□□□□□
- □□ InfluxDB CPU/□□
- □□□□□□□

□□□□□

□□□

- □□□□□□□□
- □□□□□
- □□□□□

□□□

```
1. □□□□□□□□□□□□□□□
2. □□□□□□□□□□□□□□□
3. □□□□□□□□□□
4. □□□□□□□□□□
```

□□□□□

- □□□□□□□□□□□□□□□□ → □□□
- □□□□□□□□□□□□□□ → □□□□□
- □□□□□□□□□□□□□□□□ URL/□□
- □□ Grafana □□□□□□□□□□
- □□□□□□□□□□□□□□□□

□□□□□□□□□□

□□□

- □□□□□□□□□□
- □□□□□□□□□□□□
- □□□□□□□

□□□

```
1. □□□□□□□
2. □□□□□□□
3. □□□□/□□□□□
4. □□□□□□□□□□□□
```

□□□□□

- □□□□□□□□□□□ InfluxDB □□
- □□ aggregateWindow □□□□□/□□/□□□
- □ InfluxDB □□□□□□□□□
- □□□□□□□□□□

□□□□□□

□□□

- □□□□□□□□□□□
- □□□□□□□□□□□□
- □□□□□□□□□□□□□□

□□□□□

- □□ □□□□□□□ □□□□□□□□□
- □□□□□□□□□□□□□□□□□□□□□□□□
- □□□□□□□□□□ eNodeB □□□□□

□□□□

□□□

- InfluxDB □□□□
- □□□□□ eNodeB □□
- □□□□□□□□□□

□□□□□

- □□ □□□□□□□□ □□□□□□□□□
- □□ AirScale □□ □□□□
- □□ eNodeB □□□□

□□□□

- **Nokia □□□□□** - □□□□□□□□□□□
- □□□□□□□ - □□□□□□□□□□□□
- □□□□□□□□ - □□□□□□□□
- **AirScale □□** - □□□□□□□□

□□□□□□

□□ **RAN** □□□□□□

□□□□□□□□□□□□□□□□□

□□

1. □□
2. □□□□□
3. □□□□
4. □□□□□□
5. □□□□□□
6. □□□□□□
7. □□□□□□
8. □□□□
9. □□□□□
10. □□□□

□□

□□□□□□□□□□□□□□□□ RAN □□□□□□□□□□□□□□□ NOC □□□□□□□□□□□□□□□□□□□□

□□□□

- RAN □□□□□□□□
- □□□□□□□□□
- □□□□□ RAN □□□□□□
- □□□□□□□□□

□□□□□□□□□ □□□□□□

□□□□□

□□□□□ Nokia AirScale □□□□□□□□□□□□□□□□□□□□□□□□

□□ 1□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

```
# □□□□□□□
ping <base-station-ip>

# □□□□□□□□□□□□□
telnet <base-station-ip> 8080
```

□□□□□ □□□ ping □□□ telnet □□

□□□□□

- □□□□□□
- □□□□□□□□□□□
- □□□□□□□□□□□□

□□ 2□□□□□□□

□□□□□□□

□□	□□	□□□□
IP □□	10.7.15.67	□□□□□□□□□□
□□	8080	□□□ Nokia AirScale □ 8080
□□□□	Site-B-Tower-1	□□□□□□□□□
□□□	admin	□□□□□□
□□	password123	□□□□□□

□□□□□□□□□□

- □□□□□□□□□□□□□
- □□□□□□□□
- □□□□□□□□□□□□□□□□□□□□□□□□
- □□□`NYC-SiteA-BS1`□`LAX-Tower-Main`□`CHI-Indoor-DAS`

□□ 3□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□□

1. □□ Web UI: `https://<ran-monitor-ip>:9443`
2. □□□ □□□□ **eNodeBs** □□
3. □□□□□□□ IP □□□□□ ID
4. □□□□□□□□□□ ID

□□□□□□□□□□□□□□□ RAN □□□

□□ 4□□□□□□□□□

□□ `config/runtime.exs` □□□□□□□□ `airscales` □□□

```
config :ran_monitor,
  nokia: %{
    ne3s: %{
      # ... □□ ne3s □□ ...
    },
    airscales: [
      # □□□□
      %{
        address: "10.7.15.66",
        name: "Site-A-BS1",
        port: "8080",
        web_username: "admin",
        web_password: "password1"
      },

      # □□□
      %{
        address: "10.7.15.67",          # □□□□ IP □□
        name: "Site-B-Tower-1",          # □□□□□
        port: "8080",                    # □□□□
        web_username: "admin",           # WebLM □□□
        web_password: "password123"      # WebLM □□
      }
    ]
  }
```

□□□ □□ Elixir □□□□ - □□□□□□□□□□□□□□□□□

□□ 5□□□□□

□□□□□□□□□□□□□□□

```
elixir -c config/runtime.exs
```

□□□□□ □□□

□□□□□□

- □□□□□□□□□

- □□□□□□□□□□□ `{` □□□□ `[` □□□□
- □□□□□□□□□□□□□
- □□□□□□□□□

□□ 6：□□□ RAN □□

□□□□□□□□□□□□□□□

```
# □□□□□□□□□
# □ Ctrl+C □□□□□□
mix phx.server

# □□□□□□□□□
systemctl restart ran_monitor

# □□□□□□□□□
/path/to/ran_monitor/bin/ran_monitor restart
```

□□ 7：□□□□□□□

□□□□□□□□□□□□□□□□□

1. □□□□□□□□□

   ```
   [info] □□□□□□□□□□□Site-B-Tower-1
   [info] □□□□ Site-B-Tower-1
   ```

2. □□ **Web UI**□

   - □□□ □□ □□
   - □□□□□□□□□□□□
   - □□□□ "□□□"□□□□
   - □□□□□□ "□□□"

3. □□□□□□□□□

   - □□□□

- □□□□□□□□□□□□□□
- □□ "□□□□" □□□□□□□□

4. □□ **InfluxDB** □□□

- □□□ **InfluxDB** □□ □□
- □□□□□□□□□
- □□□□□□□□□□□□□□□□

□□ 8□□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□

1. □□□ □□□□ □□
2. □□□□□□□□□□□
3. □□ "□□□□" □□□□□□□□□□
4. □□□□□□□

□□□□□□□□□□ □□□□□□□□□□

□□ 9□□□□ Grafana □□□

□□ Grafana □□□□□□□□□□

1. □□□□□□□□□
2. □□□□□□□□□□□□□
3. □□□□□□□□□□□□□□□□

□□□□□□□□□□□□ Grafana □□□□□

□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□ 1□□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□

□□ **A**□□□□□

- □□□□□□□□□□□□
- □□□□□□□□□□□□□□□□□

□□ **B**□□□□□

- □□□□□□□□□□□□
- □□ InfluxDB □□
- □□□ - □□□□□□

□□ 2□□□□□□□□□□□

□□□□□□□□□□□□□□□

□□ `config/runtime.exs` □□ `airscales` □□□□□□□□□□□□□□□□□□□□

```
airscales: [
  %{
    address: "10.7.15.66",
    name: "Site-A-BS1",
    port: "8080",
    web_username: "admin",
    web_password: "password1"
  },

  # □□□□ - □□□□□□□□□
  # %{
  #   address: "10.7.15.67",
  #   name: "Site-B-Tower-1",
  #   port: "8080",
  #   web_username: "admin",
  #   web_password: "password123"
  # }
]
```

□□ 3□□□□□□□□□□

□□□□□□□□□□□□□□□

1. □ Web UI □□□□ □□□□ □□
2. □□□□□□□□□
3. □□ □□□□□□□ □□
4. □□□□

□□□ □□□□□□□□□□□□□□

□□ 4□□□ RAN □□

□□□□□□□□□□□□□□□□

```
systemctl restart ran_monitor
# □
mix phx.server
```

□□ 5□□□□□

□□□□

1. □□□□□□□□
    - □□□□□□□□□□□□□□□
    - □□□□□□□□□□□□□□□□□□□□□□□□□□□□
2. □□□□□□□□□□
    - □□□□□□□□□□□□□□□
    - □□□□□□□□□□□□
3. □□ **InfluxDB**□
    - □□□□□□□□□□□□□□□□□
    - □□□□□□□□□□□□

□□ 6□□□ Grafana □□□

□ Grafana □□□□□□□□

1. □□□□□□□□□
2. □□□□□□□□□□□□
3. □□□□□□□□□□□□□□□

□□□□□□

□□□□□□□□□□□ RAN □□□□□

□□ 1□□□□□□□

□□□□□□□□

1. □□□□□□□□□□□□□□□□
2. □□□□□□□□
3. □□□□□□□□□□□□□

□□ 2□□□□□

□□ `config/runtime.exs` □□□□□□

```
airscales: [
  %{
    address: "10.7.15.66",
    name: "Site-A-BS1",
    port: "8080",
    web_username: "admin",
    web_password: "new_password_here"  # □□□□□□
  }
]
```

□□ 3□□□ RAN □□

□□□□□□□□

```
systemctl restart ran_monitor
```

□□ 4□□□□□□□

□□□□

1. □□□□□□□□□□

   ```
   [info] □□□□□□□□□□□Site-A-BS1
   [info] □□□□ Site-A-BS1
   ```

2. □□ **Web UI**□

   - □□□□□□ "□□□"□□□□
   - □□□□□□
   - "□□□□" □□□□

□□□□□□□□□

- □□□□□□□□□
- □□□□□□□□□□
- □□□□□□□□□□□□
- □□□□□□□□□□□□□□□□□□□□

□□□□□

□□ RAN □□□□□□□□□□□□□□

□□□□□□

RAN □□□□□□□□□□□□□□□□□□□□

□□□□	□□□□	□□□	□□□□□□
□□□□	10 □	□	□□□□□□□□□□□□□□□/□□□□
□□	10 □	□	□□□□□□□□□□□□□□
□□	60 □	□	□□□□□□□□□□□□□□□
□□□□	30 □	□	□□□□□□□□

□□□□□□

□□□□□□□□□□□

- □□□□□□□□□□
- □□□□□□□□□□
- □□□□□□ SLA □□
- □□□□□□□

□□□□□□□□□□□□

- □□□□□□
- □□ InfluxDB □□□□
- □□□□□□□□□□
- □□□□□□□

□□ 1□□□□□

□□□□□□□□□□□□□□□□□□□□ runtime.exs □□□□□□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□

- □□□□□`lib/ran_monitor/nokia/airscale/manager.ex`

- □□□`lib/ran_monitor/nokia/airscale/manager.ex`
- □□□`lib/ran_monitor/nokia/airscale/manager.ex`

□□□ □□ Omnitouch □□

□□ 2□□□□□

□□□□□□□□□

□□□□□

- □□□□□ × □□□ × □□ = □□□□□
- □□□ = □□□□□□
- □□□□□□□□□□□□□□□

□□□□□

- □□□□□□□□□ × □□□ = □□□
- □□□10 □□□ = □□□□□□□ 8,640 □□□
- □□ InfluxDB □□□□□□□□

□□□□□

- □□□□□□ = RAN □□□ CPU □□□□□
- □□□□□□□□□

□□ 3□□□□□□

□□□□□□

1. □□□□□□□□ □□□□□
2. □□□□□□□
   - RAN □□□□□□ CPU □□□
   - □□□□□□□
   - InfluxDB □□ I/O □□□□□
3. □□□□□□□
   - □□ InfluxDB □□□□□□□□□□□

    - □□□□□□□□□□
4. □□□□□□□□□□
    - □□□□□□□□□□□□
    - □□□□□□□□□□□□□

□□□□□□

□□□□ RAN □□□□□□□□□□□□

□□□□□□

□□□□□□□□□□□□□□□□□□ Web UI □□ - □□□□□

□□□□□

1. □□ □□□□□□□□□
2. □□ □□□□
3. □□ □□□ - □□□□ ID
4. □□ □□□□ ID □□□□
5. ���□ □□□□□□
6. □□ □□□□□

□□□

□□□□□□

- □□□□□□□□□
- □□□□□□□□□
- □□□□□□□□□

□□□□□□

- □□□□□□□□□□□□□
- □□□□□□□□□□
- □□□□□□

□□□□□□□

- □□□□□□□□□□□□
- □□□□□□□□□
- □□□□□□□

□□□□□

- □□□□□□□□□□□□
- □□□□ ID □□□□
- □□□□□□□
- □□□□□□□□□

□□□□□□□

- □□□□
- □□□□□□□□
- □□□□□□□□ 15-30 □□
- □□□□□□□□□□□□

□□□□□□

□□□□□□□□ RAN □□□□□□□□

□□□□□□

□□□□□□□□□□□□□□□□□□

1. □□ Web UI □□□

```
https://<ran-monitor-ip>:9443
```

2. □□□□□□

- □□□□□□□□□□□□□□□□□□□□□□

- □□□□□□□□□□□□□□□□□□□□□□
- □□□□□□□□□□

3. □□□□□□

- □□□□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□
- □□□□□□□□□□□□□□□□□□□□

4. □□□□□□

- □□□ InfluxDB □□□□
- □���□□□□□□□□
- □□□□□□□□□□□□□□

5. □□□□□□□

- □□□□□□□□□□□□
- □□ "□□" □□
- □□□□□□□□□□□

□□□□□□□□□□□□□□□□□ Web UI □□ - Web UI □□□□□

□□□Grafana □□□□□

*□□□□□□□□□□□ LNMME □ S1 □□□□□□□□□□□□□□□□□□□ UEs□□□ PRB □□□□□□□□□□□□□□□□□□□

□□□□

□□□□□□

□□□□□□□□□□□□□□ □□□□□□□□□□□

□□□□□

□□□□□□□□

- □□□□□□□□□□
- □□□□□□□□□□□□□□

□□□□□□□□

- □□□□□□□□□□□□□□
- □□ `config/config.exs` □□□□□□□□□

□□□□□□□

- □□□□□□□□ "□□□□□□" □□
- □□□□□□□□□□

□□□□□

- □□□□ InfluxDB □□□□□□□
- □□□□□□□□□□
- □□□□□□□□□□□□□□□□□□

□□□□

□□□□□□□□

1. □□□□□□□□□□□□□
2. □□ "□□□□"
3. □ XML □□□□□□□□□□

4. □□□□□□□□□□□

□□□□□□□ **InfluxDB**□□

```
# □□□□□□□□□□
influx -database 'nokia-monitor' -execute '
  SELECT * FROM PerformanceMetrics
  WHERE basebandName='''Site-A-BS1'''
  AND time > now() - 7d
' -format csv > export.csv
```

□□ **Grafana** □□□

- □□□□□
- □□□□□□
- □□ "□□" - "□□" - "CSV"

□□□□

□□□

□□□□□

1. □□□

```
# □□□□□□□
cp config/runtime.exs backups/runtime.exs.$(date +%Y%m%d)

# □□□□□□□□
tar -czf backups/config-$(date +%Y%m%d).tar.gz config/
```

2. □□□

- □□ Web UI □□□□□□□□□
- □□□□□□□□□□□□
- □□□□□□□□□/□□□

3. MySQL □□□

```
# □□□□□□□□□□
mysqldump -u ran_monitor_user -p ran_monitor >
backups/ran_monitor-$(date +%Y%m%d).sql
```

4. InfluxDB □□

```
# InfluxDB 1.x □□
influxd backup -portable -database nokia-monitor
/backups/influx-$(date +%Y%m%d)

# InfluxDB 2.x □□
influx backup /backups/influx-$(date +%Y%m%d)
```

5. SSL □□

```
cp priv/cert/* backups/certificates-$(date +%Y%m%d)/
```

□□□□

□□□

- MySQL □□□□□□□□□□
- □□□□□□□□□□□□

□□□

- InfluxDB □□□□□□□□□□□□
- □□□□□□□□□□□□

□□□□□□

- □□□□
- □□□□
- □□□□□

□□□□

□□□□□□□□□

1. □□ RAN □□

```
systemctl stop ran_monitor
```

2. □□□□□□

```
cp backups/runtime.exs.20251230 config/runtime.exs
```

3. □□□□

```
elixir -c config/runtime.exs
```

4. □□ RAN □□

```
systemctl start ran_monitor
```

5. □□□□□□□□

□□□□□□□□□

1. □□ RAN □□

```
systemctl stop ran_monitor
```

2. □□ MySQL □□□

```
mysql -u ran_monitor_user -p ran_monitor < backups/ran_monitor-
20251230.sql
```

3. □□ RAN □□

```
systemctl start ran_monitor
```

4. □□□□□□□□□□

5. □□□□□□□□□

6. □□□□□□□□ InfluxDB □

□□□□□□□□□□□

1. □□□□□□□□□□□ RAN □□
2. □□□□□□□
3. □□ MySQL □□□
4. □□ InfluxDB □□
5. □□ SSL □□
6. □□ RAN □□
7. □□□□□□□□□□□
8. □□□□□□□□□□

□□□

□□□□□

□□□

1. □□□□

- □□□□□□□□□□□
- □□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□

2. □□□□

- □□□□□□□□□
- □□□□□□□□□□□□□□□□

- □□□□□□□□□□

3. □□□□

- □□□□□□□□□□□
- □□□□□□□□□□□□□
- □□□□□□□□□□□

4. □□□□

- □□□□□□□□□
- □□□□□□□□□
- ���□□□□□□□□□□

□□□□

1. □□□□□□

- □□□□□□□□
- □□□□□□□□
- □□□□□□□□

2. □□□□

- □□□□□□
- □□□□□□
- □□□□□□□□□ SSL □□

3. □□□□

- □□□□□□□□
- □□□□□□□□□
- □□□□□□□□□□□

□□□

1. SSL □□□□

- □□□□□□□ SSL □□

在到期前测试新证书

2. 密码轮换

更新所有基站凭据
更新数据库密码
更新 API 令牌

3. 系统升级

计划 RAN 监控版本升级
在暂存环境中测试
安排生产升级

维护窗口

规划维护窗口：

1. 在低流量期间安排：

通常夜间或周末最佳
避免在 Grafana 中识别的繁忙时段

2. 通知利益相关者：

通知运营团队
更新状态页面
设置停机期望

3. 准备回滚计划：

备份当前状态
记录回滚步骤
如果升级，准备好以前的版本

4. 执行维护：

按照文档程序进行
密切监控进度

    - □□□□□□□
5. □□□□□□□□
    - □□□□□□□□□
    - □□□□□□□
    - □□□□□□□□
    - □□□□□□□□□
6. □□□□□
    - □□□□□□□□
    - □□□□□□□□□□
    - □□□□□□□□□□

□□□□

- □□□□ - □□□□□□□
- **Web UI □□** - □□□□□□□□□
- □□□□□□□□ - □□□□
- **AirScale □□** - □□□□
- □□□□ - □□□□□□□□
- **Grafana □□□□** - □□□□□□
- □□□□□□□ - □□□□□□□
- □□□□□□□□□ - □□□□□□□□□
- □□□□□□□ - □□□□
- □□□□ - □□□□□□□□

□□□ LTE □□□□□□□

□□□ **AirScale/FlexiRadio** □□□□□□□□□□□□

□□

1. □□
2. □□□□□□□
3. □□□□□
4. □□□□□□□□
5. □□□□□□
6. UE □□□□□
7. □□□□□□□□
8. □□□□□□□□
9. □□□□□□□
10. □□□ QoS □□□
11. □□□□□□□□□□□
12. □ Grafana □□□□□□
13. □□□□

□□

□□□ LTE □□□AirScale□FlexiRadio□□□□□□□□□□□

连接的用户数量（负载）
服务是否可用（可用性）
信号质量和无线电条件

测量组

计数器被组织成测量组，每个组涵盖特定的功能领域。完整的诺基亚 LTE 计数器集包括以下测量组：

□□□□□□□ (M8xxx)

□□	□□	□□□□□□	□□□□□□
M8000	S1 □□	33	□□□□□□□□□S1 □□/□□□UE □□□
M8001	□□□□	336	PDCP □□□RACH□□□□□□MCS □□
M8004	X2 □□	4	X2 □□□□eNB □□□□□□
M8005	□□□□□□	237	RSSI□SINR□□□□□□□□AMC
M8006	EPS □□	54	□□□□/□□/□□
M8007	□□□□□□□□	14	DRB □□□□□
M8008	RRC □□□□	14	□□□□□□□□□□
M8009	□□□□	8	HO □□□□
M8010	CQI □□	27	□□□□□□□□□□
M8011	□□□□□	55	PRB □□□□□□□
M8012	□□□	121	PDCP □□□□□□□□□
M8013	□□□□	21	RRC □□□□□□/□□
M8014	eNB □□□□□	14	□□ X2 □□□□□
M8015	eNB □□□□	13	□□□□□□
M8016	CS □□	18	□□□□□□□□
M8017	□□□ HO	10	□□□□□ RAT□3G/2G□
M8018	eNB □□	8	□□ UE □□□□□□□

□□	□□	□□□□□□	□□□□□□
M8019	NACC	4	□□□□□□□□□
M8020	□□□□□	7	□□□□□□□□□□□
M8021	□□□ HO	17	□□□□□□□
M8022	X2 □□	2	X2 □□□□
M8023	□□□	36	PDCP SDU □□□□□□□□□

□□□□□□ (M5xxx)

□□	□□	□□□□□□	□□□□□□
M5112	IP □□□□	112	□□□□□□□□□□□□□
M5113	□□□ RX	21	□□□□□□□□□□□□

□□□□ (M4xxxx)

□□	□□	□□□□□□	□□□□□□
M40001	□□□□□	□□	VSWR□□□□□□RF □□
M40002	□□	□□	□□□□

□□□□□□□

□□□□□□□□□□□□□□□□□

```
M<measurement><type>C<counter>
```

□□□**M8011C24**

- **M** - □□□□□□□□“□□”
- **8011** - □□□□□□□□□□
- **C** - □□□□□□□□□“□□□”
- **24** - □□□□□□□□□□□□ PRB □□□□□□□

□□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

- □□ - □□□□□□□□
- □□ - □□□□□□□□□
- □□ - □□□□□□□□
- □□ - □□□□□□□□
- □□ - □□□□□□
- □□ - □□□□□□□

□□□□□

□□□□□□□□

□□□□□□

- M8011Cxx - PRB □□□
- M8018Cxx - □□ UE □□
- M8012Cxx - □□□□□□

□□□□□□

- M8001Cxx - □□□□□□
- M8005Cxx - RSSI□SINR

- M8013Cxx - □□□□□

□□□□□□

- M8020Cxx - □□□□□
- M8049Cxx - □□□□

□□□□□

- M8005Cxx - □□□□□□□
- M8001Cxx - □□□□
- M8013Cxx - □□□□

□□□□□□□□

M8011 - □□□□□□

□□□□□□□□□□□□□□□PRB□□□□□□□□□□□□□□□□□□□□□□□□

□□□	□□	□□	□□	□□	□□
M8011C24	□□ PRB □□□□□ TTI □□	□□□□□□□□□□□□□□□□□ PRB □□	0.1%	□□	□□ 10 □□ □□□
M8011C37	□□ PRB □□□□□ TTI □□	□□□□□□□□□□□□□□□□□ PRB □□	0.1%	□□	□□ 10 □□ □□□

□□ **PRB** □□□□

- □□□□□□□**PRB**□ □ LTE □□□□□□□□□□□□□□
- **TTI**□□□□□□□□□ = LTE □□ 1 □□
- □□□□□□□ = □□□□□□□□□□□□□□□
- 100% □□□□□□□□□□□□□□□

□□□□

- 0-1000□□□ 0.0% □ 100.0%□
- □□□□□□□□ 10 □□□□□□
- □□□□□□□□ 453 = 45.3% PRB □□□

□□□□□□□□□□□□

- < 50% - □□□□□□□□
- 50-70% - □□□□□□□
- 70-85% - □□□□□□□□□
- > 85% - □□□□□□□□□□□□□□/□□

Grafana □□□□□

```
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["metricCounter"] == "M8011C37")
  |> filter(fn: (r) => r._field == "counterValue")
  |> map(fn: (r) => ({ r with _value: r._value / 10.0}))  // □□□□□
□
```

□□□□□□

M8012 - □□□□□□□□

□□□□□□□□ PDCP□□□□□□□□□□□□□

□□□	□□	□□	□□	□□	□□□□
M8012C23	PDCP □□□□□□□□	□□□□ PDCP □□□	kbit/s	□□	□□ UE □□□ PDCP SDU □
M8012C26	PDCP □□□□□□□□	□□□□ PDCP □□□	kbit/s	□□	□□ UE □□ PDCP SDU □

□□ **PDCP** □□□□

- **PDCP** □□□□□□□□□□□□□□□□
- □□□□□□□□□□□□kbit/s□□□□□□□□
- □□□□□□□□□□□□□□□□□□□□
- □□□□□□□

□□□□□□

- □ 1 □□□□□□□□□□□□□□
- □□□□□□□□□□□□□□
- □□ VoLTE □□□□□□

□□□□□

□□□**M8012C26**□□

- < 10 Mbps - □□□/□□□
- 10-50 Mbps - □□□□
- 50-100 Mbps - □□□/□□□□□
- > 100 Mbps - □□□□□□□□□□□□□□□

□□□**M8012C23**□□

- < 5 Mbps - □□□
- 5-20 Mbps - □□□□
- 20-40 Mbps - □□□
- > 40 Mbps - □□□□

Grafana □□□□□

```
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["metricCounter"] == "M8012C26")
  |> filter(fn: (r) => r._field == "counterValue")
  |> map(fn: (r) => ({ r with _value: r._value / 1000.0}))  // □□□
Mbps
```

UE □□□□□

M8018 - eNB □□□□

□□□□□□□□□□□□□□□□□□□□□□□□□UE□□□□

□□□	□□	□□	□□	□□	□□□□
M8018C1	□□ eNB □□□ UE □□□	□□ eNodeB □□□□□ UE □□	□□	□□	1 □

□□ **UE** □□□

- □□ **UE** = □□□□□□□□□□□□□□□SRB□□□□□□□□□□□□□□DRB□□□□
- □ 1 □□□□□□□□□□□□□□□
- □□□□□□□□□□□

□□□□□

□□ UE □□	□□□□	□□
0-50	□	□□□□
50-100	□□	□□□□
100-150	□	□□□□□□
> 150	□□□	□□□□□□

□□□

- □□□□□□□□□□□□□□□
- □□□ AirScale □□□□□□□□□□ 150-250 □□□□□ UE
- □ UE □□□□□□□□□□□□□□

□□□□□□□□

M8020 - □□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□	□□	□□	□□	□□	□□□□
M8020C3	□□□□□□	□□□□□□□□□□	□□	□□	~10 □
M8020C4	□□□□□□□□□	□□□□□□□□□□□□	□□	□□	~10 □
M8020C6	□□□□□□□	□□□□□□□□□	□□	□□	~10 □

□□□□□□□□

```
□□□□□ % = 100.0 × M8020C3 / (M8020C6 - M8020C4)
```

□□□□□

- **M8020C3** - □□□□□□□□□□
- **M8020C6** - □□□□□□
- **M8020C4** - □□□□□□□□□□□□□□

□□□□□□

□□□	□□	□□
> 99.9%	□□	□□□□□□ SLA
99.0-99.9%	□□	□□□□
95.0-99.0%	□□	□□□□
< 95.0%	□	□□ - □□□□□□□□

Grafana □□□□□

```
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["metricCounter"] == "M8020C3" or
                       r["metricCounter"] == "M8020C6" or
                       r["metricCounter"] == "M8020C4")
  |> pivot(rowKey:["_time"], columnKey: ["metricCounter"],
valueColumn: "_value")
  |> map(fn: (r) => ({
      _time: r._time,
      "□□□□□": 100.0 * r.M8020C3 / (r.M8020C6 - r.M8020C4)
    }))
```

□□□□□□□□□

M8005 - □□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□RSSI□□□□□□□□□□□□□□SINR□□□□□□□□□□□□□□□□□□

RSSI □□

□□□	□□	□□	□□	□□
M8005C0	PUCCH □□ RSSI	□□□□□□□□□□□□□□ RSSI	dBm	□□
M8005C1	PUCCH □□ RSSI	□□□□□□□□□□□□□□ RSSI	dBm	□□
M8005C2	PUCCH □□ RSSI	□□□□□□□□□□□□□□ RSSI	dBm	□□

□□ **RSSI**□

- **RSSI** = □□□□□□□□□□□□□□□□□□□□□
- **PUCCH** = □□□□□□□□□□□□□□□□□□□□□
- □ dBm□□□□□□□□□□□□□
- □□□□ UE □□□ RSSI □□□□

RSSI □□□□

RSSI □□	□□	□□
> -70 dBm	□□	□□□□□
-70 □ -85 dBm	□□	□□□□□□□□
-85 □ -100 dBm	□□	□□□□
-100 □ -110 dBm	□□	□□□□□□□□□□
< -110 dBm	□□□	□□□□□□□□□□□□□

用例：
覆盖分析 - 低 RSSI 表示覆盖缺口
干扰故障排除 - 意外的 RSSI 模式
RF 规划 - 验证信号强度预测

连接管理计数器

M8013 - 信令连接建立

这些计数器跟踪 RRC（无线资源控制）连接设置尝试和成功，这是网络可访问性的关键指标。

计数器 名称 描述 单位 类型

M8013C5 信令连接建立完成 成功的 RRC 连接设置 整数 总和

M8013C17 信令连接建立尝试 MO-S 连接尝试 - 移动发起信令 整数 总和

M8013C18 信令连接建立尝试 MT 连接尝试 - 移动终止 整数 总和

M8013C19 信令连接建立尝试 MO-D 连接尝试 - 移动发起数据 整数 总和

M8013C21 信令连接建立尝试紧急 紧急呼叫连接尝试 整数 总和

M8013C31 信令连接建立尝试高优先级 高优先级连接尝试 整数 总和

M8013C34 信令连接建立尝试延迟容忍 延迟容忍连接尝试 整数 总和

M8013C91 信令连接建立尝试 MO-V 连接尝试 - 移动发起语音 整数 总和

M8013C93 信令连接建立尝试 MT-接入 连接尝试 - MT 接入 整数 总和

计算设置成功率：

```
□□□□□ % = 100.0 × M8013C5 / (M8013C17 + M8013C18 + M8013C19 +
M8013C34 + M8013C31 + M8013C21 + M8013C93 + M8013C91)
```

□□□□□

- **M8013C5** - □□□□□□□□□ RRC □□□□□□□□
- □□□□□□□□□ - □□□□□□□□□□□□

□□□□□

- **MO-S (M8013C17)** - □□□□□□□□□□□□□□□□□□
- **MT (M8013C18)** - □□□□□□□□/□□□
- **MO-D (M8013C19)** - □□□□□□□□□□□□□□
- **MO-V (M8013C91)** - □□□□□□□□VoLTE □□□
- □□ **(M8013C21)** - □□□□□□911□112□

□□□□□

□□□	□□	□□
> 99%	□□	□□□□
95-99%	□□	□□□□□□
90-95%	□□	□□□□
< 90%	□	□□□□ - □□□□

□□□□□□□

- □□□□□□□□□□
- □□□□□□□□□□□□
- □□□□
- □□□□
- □□

□□□ QoS □□□

M8001 - □□□□□□□

□□□	□□	□□	□□	□□
M8001C2	PDCP SDU □□□□□□□	eNB □□□ PDCP SDU □□□□□□□□	□□	□□

□□□□□□

- **PDCP SDU** = □□□□□□□□□□□□□□□□□□□□□□□□□□□□
- □□ = □□□□□□□□□□□□□□□□□
- □□ **DTCH** = □□□□□□□□□□□□□□□□□□□□
- □□□□ = □□□□□□□□

□□□□□□

□□	□□	□□□□
< 10 □□	□□	□□ VoLTE□□□□□□□□
10-20 □□	□□	□□□□□□□□
20-50 □□	□□	□□□□□□□□□□
> 50 □□	□	□□□□□□

□□□□□□□□

- □□□□□□□□□□□
- □□□□□□□□
- □□□□□□□□□□□□□□
- □□□□

S1 □□□□□

M8000 - S1 □□□□

□□□□□□□□ eNodeB □ MME□□□□□□□□□□□□ S1 □□□□□□□□□□□□□S1 □□□□□□□□□□□□

□□□	□□	□□	□□	□□
M8000C0	□□□□□□□□□□	□□□□□□□□□□□□□□	□□	□□
M8000C1	□□□□□□□□□□	□□□□□□□□□□	□□	□□
M8000C2	□□□□ - □□□□	□□□□□□□□□□□□□□	□□	□□
M8000C3	□□□□ - □□	□□□□□□□□□□□□□□	□□	□□
M8000C6	S1 □□□□	S1 □□□□□□	□□	□□
M8000C7	S1 □□□□	□□□ S1 □□	□□	□□
M8000C11	S1 □□□□	□□ MME □□□□□	□□	□□
M8000C12	UE □□ S1 □□□□	□□□□ UE □□□ S1 □□	□□	□□
M8000C29	□□ NAS □□	□□□ MME □ NAS □□	□□	□□
M8000C30	□□ NAS □□	□ MME □□□ NAS □□	□□	□□

□□ **S1** □□□

- **S1** □□□□ eNodeB □ EPC□□□□□□□□
- □□□□□□□□ □□□ UE □□□□□□□□
- **S1** □□ □ eNodeB □ MME □□□□□□□
- **NAS**□□□□□□□ □□□□□□□□□□□□

□□□□□□

```
S1 □□□□□□ = 100 × M8000C7 / M8000C6
□□□□□□□□□□ = 100 × M8000C1 / M8000C0
```

□□□□□□

- S1 □□□□□□□> 99%
- □□□□□□□□□□□> 95%

EPS □□□□□

M8006 - EPS □□□□

□□□□□□□□ E-UTRAN □□□□□□□□E-RAB□□ EPS □□□□□□□□□□□□□□□□□

□□□□□□□

□□□	□□	□□	□□	□□
M8006C0	EPS □□□□□□□	□□□□□□□	□□	□□
M8006C1	EPS □□□□□□□	□□□□□□□□	□□	□□□
M8006C2-C5	□□□□□□□□□□□	□□□□□□□□□	□□	□□

□□ **EPS** □□□

- □□ = UE □□□□□□□□□□□□□□□□
- □□□□ = □□□□□□□□□□□□□□□□□
- □□□□ = □□□□ QoS □□□VoLTE□□□□□□□□□□

□□□

- □□□□□□□□□□
- □□□□□□□□□□

- □□□□□□□□□□□□□

□□□□□

M8009 - □□□□□□

M8014 - eNB □□□□□□□

M8015 - eNB □□□□□□

M8021 - □□□□□□□

□□□□□□□□□□□□□——□ UE □□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□

□□	□□	□□□
□□ **eNB**	□□□□□□□□□□□	M8015
eNB □□	□□□□□□□□□□□□□X2□	M8014
□□□	□□□□□□□□□□	M8021
□□□	□□□□□□□□□LTE→3G/2G□	M8017

□□□□□

□□□□	□□□	□□□□□
M8009	□□□□□□	□□□□□□□□□□□□□□□
M8014	□□ X2 □ HO	□□□□□□□□□□
M8015	□□□□ HO	□□□□□□□□□□
M8021	□□□ HO	□□□□□□□□

□□□□□□□□

```
□□□□□ = 100 × (□□□□) / (□□□□□□)
```

□□□□

- □□ eNB HO □□□□> 99%
- eNB □□ HO □□□□> 98%
- □□□ HO □□□□> 95%

□□□□□□□□□

- □□□□□□□□□□□□□□□
- □□□□□□□□□□□
- □□□□□□UE □□□□□□□
- □□□□□□□□□□□□□□

□□□□□

M8010 - CQI□□□□□□□□□□

□□□□□□□□□ UE □ CQI □□□□□□□□□□□□□□□□□□□□

□□ **CQI**□

- **CQI** = UE □ eNodeB □□□□□□□□□□
- □□□ CQI 0□□□□□ CQI 15□□□□
- □□□ □□□□□□□□□□ MCS□□□□□□□□□
- □□□□□ □□□□□□□□□□□□□□□

CQI □□□□□□□□

CQI □□	□□□□	□□□□□□	□□
0-3	□□□	< 1 Mbps	QPSK
4-6	□□	1-5 Mbps	QPSK
7-9	□□	5-15 Mbps	16-QAM
10-12	□□	15-40 Mbps	64-QAM
13-15	□□	40-150 Mbps	64-QAM

M8010 □□□□

- M8010C0 - M8010C15□□□□□□□0-15□□ CQI □□□□

□□□□□

```
□□ CQI = Σ(CQI_level × M8010C[level]) / Σ(M8010C[level])
```

□□ **CQI** □□□

- □ **CQI**□**10-15**□□ □□□□□□□□□□□□
- □□ **CQI**□**7-9**□□ □□□□□□□□□□
- □ **CQI**□**0-6**□□ □□□□□□□□□□□

CS □□□□□

M8016 - CS □□□□

□□□□□□□□□□□□□□□□CSFB□□□□□□□ LTE UE □□□□□□□□□ 2G/3G □□□

□□ CSFB□

- □□□ □□□ VoLTE □□□□□□□□□□□
- □□□ UE □ LTE → □□□□ → □□□□□ 2G/3G → □□ LTE
- □□□ □□□□□□□□□□□□ LTE □□

□□□□□□

□□□	□□	□□
M8016C0	□□□□□ CSFB □□	□□□□□□□□ CSFB
M8016C1	□□□□ CSFB □□	□□□□□□□ CSFB

CSFB □□□

1. □□□□ UE □ LTE □□□□□□□ 2G/3G□□□□□□□□□□□
2. □□□ □ LTE □ 2G/3G □□□□□□□□□□□□

□□□□□

- CSFB □□□ = □□□□ / □ CSFB □□
- □□□> 98%

□□□□□

M8023 - PDCP SDU □□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□

关键指标：

总数据量（上行和下行）
按 QCI（服务质量类别标识符）划分的体积
按承载类型划分的体积

用例：

网络容量规划
收入估算（数据使用跟踪）
每用户数据消费分析
QoS 类流量分析

与 M8012（吞吐量）的关系：

M8012：瞬时数据速率（kbit/s）
M8023：累计数据量（字节）

X2 接口计数器

M8004 - X2 数据量测量

M8022 - X2 设置测量

这些计数器跟踪 eNodeB 之间的 X2 接口，用于 eNB 之间的切换和负载平衡。

M8004 - X2 数据量：

测量在切换期间在 eNodeB 之间转发的数据
跟踪进出 X2 流量的体积

M8022 - X2 设置：

M8022C0： X2 设置尝试
M8022C1： X2 设置成功

□□ **X2** □□□

- □□□ □□ eNodeB □□□□□□□□
- □□□ □□□□□□□□□□□□□□□□□
- □□□ □□□□□□□□□□□□□□□□□□

X2 □□□□□□□

```
X2 □□□□□□ = 100 × M8022C1 / M8022C0
```

□□□ > 95%

□□□□□

M8007 - □□□□□□□□□DRB□□□

□□□□□□□□□□□□□□□□□

M8019 - 网络辅助小区切换（NACC）

跟踪 NACC 程序，以优化从 LTE 到 GSM 的小区重新选择。

目的：在重新选择之前向 UE 提供 GSM 邻近小区系统信息，加快过渡。

网络接口测量

M5112 - IP 接口输入测量

M5113 - 以太网 RX 测量

这些测量组跟踪回程接口统计数据。

M5112 - IP 接口输入（112 个计数器）：

传入数据包计数
数据包大小分布
协议特定统计
接口利用率

M5113 - 以太网 RX（21 个计数器）：

接收的以太网帧计数
帧大小分布
错误统计（CRC 错误、帧错误）

用例：

回程容量监控
传输链路健康评估
故障排除连接问题
传输升级的容量规划

□□□□□□□□□□□□

M40001 - □□□□□□□

□□□	□□	□□	□□	□□	□□
M40001C0	□□□□□□□□ VSWR	□□□□□□	0.1	□□	□□ 10

□□ VSWR□

- **VSWR** = □□□□□
- □□□□□□□□□
- □□□□□□□□□□□□□□□□/□□□□
- □□□□ = □□

VSWR □□□

VSWR	□□	□□
1.0-1.5	□□	□□□□
1.5-2.0	□□	□□□
2.0-3.0	□□	□□
> 3.0	□	□□/□□□□ - □□□□

□ VSWR □□□□□□

- □□□□□□□□
- □□□□□□
- □□□□
- □□□□
- □□□□□

Grafana □□□□□

```
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["metricCounter"] == "M40001C0")
  |> filter(fn: (r) => r._field == "counterValue")
  |> map(fn: (r) => ({ r with "VSWR": r._value / 10.0}))
```

M40002 - □□□□

□□□	□□	□□	□□	□□	□□
M40002C2	□□	□□□□	100000 □□	□□	□□ 100000

□□□□□

- □□□□□□□□□
- □ OPEX □□□□□□□□□
- □□□□□/□□□□□□□□□□

Grafana □□□□□

```
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["metricCounter"] == "M40002C2")
  |> filter(fn: (r) => r._field == "counterValue")
  |> map(fn: (r) => ({ r with "Power": r._value / 100000.0}))
```

□ Grafana □□□□□

□□□□□□□□

1. □□□□□□□□

□□ M8011C24 □ M8011C37 □□□□/□□ PRB □□□

```
// □□ PRB □□
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["metricCounter"] == "M8011C24")
  |> map(fn: (r) => ({ r with _value: r._value / 10.0}))
  |> rename(columns: {"_value": "□□ PRB %"})

// □□ PRB □□
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["metricCounter"] == "M8011C37")
  |> map(fn: (r) => ({ r with _value: r._value / 10.0}))
  |> rename(columns: {"_value": "□□ PRB %"})
```

2. □□□□□□

□□□□□□□□□□

```
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["metricCounter"] == "M8012C23" or
r["metricCounter"] == "M8012C26")
  |> map(fn: (r) => ({ r with _value: r._value / 1000.0}))  // □□□
Mbps
  |> pivot(rowKey: ["_time"], columnKey: ["metricCounter"],
valueColumn: "_value")
  |> map(fn: (r) => ({
      _time: r._time,
      "□□ Mbps": r.M8012C23,
      "□□ Mbps": r.M8012C26
    }))
```

3. □□□□□□

□□□□□□□□□□□□

```
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["metricCounter"] =~ /M8020C(3|4|6)/)
  |> pivot(rowKey: ["_time"], columnKey: ["metricCounter"],
valueColumn: "_value")
  |> map(fn: (r) => ({
      _time: r._time,
      "□□□ %": 100.0 * r.M8020C3 / (r.M8020C6 - r.M8020C4)
    }))
```

4. □□□□□□□□

□□ RRC □□□□□

```
from(bucket: "nokia-monitor")
  |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
  |> filter(fn: (r) => r["metricCounter"] =~
/M8013C(5|17|18|19|21|31|34|91|93)/)
  |> pivot(rowKey: ["_time"], columnKey: ["metricCounter"],
valueColumn: "_value")
  |> map(fn: (r) => ({
      _time: r._time,
      "□□□□ %": 100.0 * r.M8013C5 / (r.M8013C17 + r.M8013C18 +
r.M8013C19 + r.M8013C34 + r.M8013C31 + r.M8013C21 + r.M8013C93 +
r.M8013C91)
    }))
```

□□□□□□□

□□□□□□□□□□□□

- □□□□□ - □□□□□□□□□□PRB □□□
- □□ - □□□□□□□□□□□□
- □□□□□□ - □□□□□□□□ UE□
- □□□ - □□□□□RSSI □□□

□□□□□□□□□

- □□□□□□□

- □□□□□□□□□□
- □□□□□□□□□□□□

□□□□□□□

- PRB □□□□□□ < 70%□□□ 70-85%□□□ > 85%
- □□□□□□ > 99%□□□ 95-99%□□□ < 95%
- □□□□□□□ > 99%□□□ 95-99%□□□ < 95%

□□□□□□□

- □□□□□□□□□□□□□□□□□□□□
- □□□□□□□□□□/□□□□
- □□□□□□□□□□□□

□□□

- □□□□ - RAN □□□□□□□□□
- Grafana □□□□ - □□ Grafana □□□
- □□□□□□□ - □□ RAN □□
- AirScale □□□□ - □□□□
- □□□□ - InfluxDB □□□□

□□□□□

□□□□□□□□

□□□	□□	□□	□□
M8011C24	□□ PRB □□□□	□□□□	0.1%
M8011C37	□□ PRB □□□□	□□□□	0.1%
M8012C23	PDCP □□□□□	□□□□	kbit/s
M8012C26	PDCP □□□□□	□□□□	kbit/s
M8018C1	□□□□ UE	□□□□	□□
M8020C3	□□□□□□	□□□□□	□□
M8020C6	□□□□□	□□□□□	□□
M8013C5	□□□□	□□□□□	□□
M8005C0	RSSI □□□	□□□□	dBm
M8005C2	RSSI □□	□□□□	dBm
M8001C2	PDCP □□□□	□□□□	□□
M40001C0	VSWR	□□□□	0.1 □□

□□□

- □□□ FlexiRadio LTE □□□□
- □□□ AirScale □□□□□□□
- 3GPP LTE □□□□□□

附录：完整计数器列表

以下是从诺基亚 KPI 规格中提取的所有 1,186 个诺基亚 LTE 性能计数器的完整参考列表。

```
================================================================================
□□□ LTE □□□□□□□□□□
================================================================================

--------------------------------------------------------------------------------
□□□□M8000
--------------------------------------------------------------------------------
M8000C0         | □□□□□□□□□□                                    | □□
M8000C1         | □□□□□□□□□□                                  | □□        |
M8000C2         | □□□□□□□□□□□□                              | □□        | □□
M8000C3         | □□□□□□□□□□□□                              | □□        | □□
M8000C4         | □□□□□□□□□□□□                              | □□        | □□
M8000C5         | □□□□□□□□□□□□                              | □□        | □□
M8000C6         | S1 □□□□
M8000C7         | S1 □□□□                                                | □
M8000C8         | S1 □□□□□□□□□□□□                           | □□        | □□
M8000C9         | S1 □□□□□□ MME □□                              | □□
M8000C11        | S1 □□□□                                                |
M8000C12        | UE □□□□□ S1-                                | □□        |
M8000C13        | □ eNB □□□□□ S1 □□                                | □□
M8000C14        | □ MME □□□□□□ S1 □□                                 | □□
M8000C15        | □ eNB □□□□□ S1 □□                                | □□
M8000C16        | □ MME □□□□□ S1 □□                                | □□
M8000C23        | UE □□□□□□□□                                   | □□
M8000C24        | UE □□□□□□□□□□                                | □□        |
M8000C25        | UE □□□□□□□□                                   | □□
M8000C29        | □□ NAS □□□□□                                       | □□
M8000C30        | □□ NAS □□□□□                                     | □□
M8000C31        | UE □□□□□□□□□□                                | □□        |
M8000C32        | IMS □ E-RAB □□□□                                                |
M8000C33        | IMS □ E-RAB □□□□                                             | □□
M8000C34        | IMS □ E-RAB □□□□                                                |
M8000C35        | □□□□□□□□□□                                 | □□        | □□
M8000C36        | □□□□□□□□□□                                   | □□        | □
M8000C37        | □□□ X2 IP □□□□□                                    | □□
M8000C38        | □□□ X2 IP □□□□□                                     | □□
M8000C39        | WRITE-REPLACE □□□
M8000C40        | WRITE-REPLACE □□□
M8000C41        | KILL □□□□□□□□                                      | □□
M8000C42        | KILL □□□□□                                                | □

--------------------------------------------------------------------------------
□□□□M8001
```

```
-------------------------------------------------------------------------
M8001C0         | PDCP SDU □□□ DL DTCH □□
M8001C1         | PDCP SDU □□□ DL DTCH □□
M8001C2         | PDCP SDU □□□ DL DTCH □□
M8001C3         | PDCP SDU □□□ UL DTCH □□
M8001C4         | PDCP SDU □□□ UL DTCH □□
M8001C5         | PDCP SDU □□□ UL DTCH □□
M8001C6         | □□ RACH □□□□                              | □□
M8001C7         | □□ RACH □□□□                              | □□
M8001C8         | RACH □□□□                                       | □
M8001C9         | □ PCH □□□□ TB □
M8001C10        | □ BCH □□□□ TB □
M8001C11        | □ DL-SCH □□□□ TB □
M8001C12        | DL-SCH □□ HARQ □□
M8001C13        | □□□□□□ UL-SCH TB
M8001C14        | □□□ UL-SCH TB □□□□
M8001C15        | □□□ UL-SCH TB □□
M8001C16        | □□ MCS0 □ PUSCH □□
M8001C17        | □□ MCS1 □ PUSCH □□
M8001C18        | □□ MCS2 □ PUSCH □□
M8001C19        | □□ MCS3 □ PUSCH □□
M8001C20        | □□ MCS4 □ PUSCH □□
M8001C21        | □□ MCS5 □ PUSCH □□
M8001C22        | □□ MCS6 □ PUSCH □□
M8001C23        | □□ MCS7 □ PUSCH □□
M8001C24        | □□ MCS8 □ PUSCH □□
M8001C25        | □□ MCS9 □ PUSCH □□
M8001C26        | □□ MCS10 □ PUSCH □□
M8001C27        | □□ MCS11 □ PUSCH □□
M8001C28        | □□ MCS12 □ PUSCH □□
M8001C29        | □□ MCS13 □ PUSCH □□
M8001C30        | □□ MCS14 □ PUSCH □□
M8001C31        | □□ MCS15 □ PUSCH □□
M8001C32        | □□ MCS16 □ PUSCH □□
M8001C33        | □□ MCS17 □ PUSCH □□
M8001C34        | □□ MCS18 □ PUSCH □□
M8001C35        | □□ MCS19 □ PUSCH □□
M8001C36        | □□ MCS20 □ PUSCH □□
M8001C37        | □□ MCS21 □ PUSCH □□
M8001C38        | □□ MCS22 □ PUSCH □□
M8001C39        | □□ MCS23 □ PUSCH □□
M8001C40        | □□ MCS24 □ PUSCH □□
M8001C41        | □□ MCS25 □ PUSCH □□
M8001C42        | □□ MCS26 □ PUSCH □□
```

```
M8001C43        | □□ MCS27 □ PUSCH □□
M8001C44        | □□ MCS28 □ PUSCH □□
M8001C45        | □□ MCS29 □ PUSCH □□
M8001C46        | □□ MCS30 □ PUSCH □□
M8001C47        | □□ MCS31 □ PUSCH □□
M8001C48        | □□ MCS32 □ PUSCH □□
M8001C49        | □□ MCS33 □ PUSCH □□
M8001C50        | □□ MCS34 □ PUSCH □□
M8001C51        | □□ MCS35 □ PUSCH □□
M8001C52        | □□ MCS36 □ PUSCH □□
M8001C53        | □□ MCS37 □ PUSCH □□
M8001C54        | □□ MCS38 □ PUSCH □□
M8001C55        | □□ MCS39 □ PUSCH □□
M8001C56        | □□ MCS40 □ PUSCH □□
M8001C57        | □□ MCS41 □ PUSCH □□
M8001C58        | □□ MCS42 □ PUSCH □□
M8001C59        | □□ MCS43 □ PUSCH □□
M8001C60        | □□ MCS44 □ PUSCH □□
M8001C61        | □□ MCS45 □ PUSCH □□
M8001C62        | □□ MCS46 □ PUSCH □□
M8001C63        | □□ MCS47 □ PUSCH □□
M8001C64        | □□ MCS48 □ PUSCH □□
M8001C65        | □□ MCS49 □ PUSCH □□
M8001C66        | □□ MCS50 □ PUSCH □□
M8001C67        | □□ MCS51 □ PUSCH □□
M8001C68        | □□ MCS52 □ PUSCH □□
M8001C69        | □□ MCS53 □ PUSCH □□
M8001C70        | □□ MCS54 □ PUSCH □□
M8001C71        | □□ MCS55 □ PUSCH □□
M8001C72        | □□ MCS56 □ PUSCH □□
M8001C73        | □□ MCS57 □ PUSCH □□
M8001C74        | □□ MCS58 □ PUSCH □□
M8001C75        | □□ MCS59 □ PUSCH □□
M8001C76        | □□ MCS60 □ PUSCH □□
M8001C77        | □□ MCS61 □ PUSCH □□
M8001C78        | □□ MCS62 □ PUSCH □□
M8001C79        | □□ MCS63 □ PUSCH □□
M8001C80        | □□ MCS64 □ PUSCH □□
M8001C81        | □□ MCS65 □ PUSCH □□
M8001C82        | □□ MCS66 □ PUSCH □□
M8001C83        | □□ MCS67 □ PUSCH □□
M8001C84        | □□ MCS68 □ PUSCH □□
M8001C85        | □□ MCS69 □ PUSCH □□
M8001C86        | □□ MCS70 □ PUSCH □□
```

M8001C87 | □□ MCS71 □ PUSCH □□
M8001C88 | □□ MCS72 □ PUSCH □□
M8001C89 | □□ MCS73 □ PUSCH □□
M8001C90 | □□ MCS74 □ PUSCH □□
M8001C91 | □□ MCS75 □ PUSCH □□
M8001C92 | □□ MCS76 □ PUSCH □□
M8001C93 | □□ MCS77 ��□ PUSCH □□
M8001C94 | □□ MCS78 □ PUSCH □□
M8001C95 | □□ MCS79 □ PUSCH □□
M8001C96 | □□ MCS80 □ PUSCH □□
M8001C97 | □□ MCS81 □ PUSCH □□
M8001C98 | □□ MCS82 □ PUSCH □□
M8001C99 | □□ MCS83 □ PUSCH □□
M8001C100 | □□ MCS84 □ PUSCH □□
M8001C101 | □□ MCS85 □ PUSCH □□
M8001C102 | □□ MCS86 □ PUSCH □□
M8001C103 | □□ MCS87 □ PUSCH □□
M8001C104 | □□ MCS88 □ PUSCH □□
M8001C105 | □□ MCS89 □ PUSCH □□
M8001C106 | □□ MCS90 □ PUSCH □□
M8001C107 | □□ MCS91 □ PUSCH □□
M8001C108 | □□ MCS92 □ PUSCH □□
M8001C109 | □□ MCS93 □ PUSCH □□
M8001C110 | □□ MCS94 □ PUSCH □□
M8001C111 | □□ MCS95 □ PUSCH □□
M8001C112 | □□ MCS96 □ PUSCH □□
M8001C113 | □□ MCS97 □ PUSCH □□
M8001C114 | □□ MCS98 □ PUSCH □□
M8001C115 | □□ MCS99 □ PUSCH □□
M8001C116 | □□ MCS100 □ PUSCH □□
M8001C117 | □□ MCS101 □ PUSCH □□
M8001C118 | □□ MCS102 □ PUSCH □□
M8001C119 | □□ MCS103 □ PUSCH □□
M8001C120 | □□ MCS104 □ PUSCH □□
M8001C121 | □□ MCS105 □ PUSCH □□
M8001C122 | □□ MCS106 □ PUSCH □□
M8001C123 | □□ MCS107 □ PUSCH □□
M8001C124 | □□ MCS108 □ PUSCH □□
M8001C125 | □□ MCS109 □ PUSCH □□
M8001C126 | □□ MCS110 □ PUSCH □□
M8001C127 | □□ MCS111 □ PUSCH □□
M8001C128 | □□ MCS112 □ PUSCH □□
M8001C129 | □□ MCS113 □ PUSCH □□
M8001C130 | □□ MCS114 □ PUSCH □□

```
M8001C131       | □□ MCS115 □ PUSCH □□
M8001C132       | DL DTCH □□ RLC SDUs
M8001C133       | DL DCCH □□ RLC SDUs
M8001C135       | UL DTCH □□ RLC SDUs
M8001C136       | UL DCCH □□ RLC SDUs
M8001C137       | RLC PDU □□□□                                    | □□
M8001C138       | RLC PDU □□                                       | □□
M8001C139       | RLC PDU □□
M8001C140       | DL RLC C-PDUs □□□□□□□                            | □□
M8001C141       | DL RLC □□ PDUs □□□□□□□                             |
M8001C142       | UL RLC PDUs □□
M8001C143       | □□□ UL RLC PDU □□                                  |
M8001C144       | UL RLC PDU □□□□                              | □□
M8001C145       | UL RLC PDUs □□
M8001C146       | DL RLC SDU □□ PDCP
M8001C147       | □□□□□ UE □□                          | □□    | □□
M8001C148       | □□□□□ UE □□                          | □□       |
M8001C150       | □□□□□ UE □□                          | □□    | □□
M8001C151       | □□□□□ UE □□                          | □□       |
M8001C153       | □□ PDCP SDUs
M8001C154       | □□ PDCP SDUs
M8001C155       | □□□□□ PDCP SDUs                                 | □□
M8001C156       | □□□ PDSCH MCS0 □□                                  | □
M8001C157       | □□□ PDSCH MCS1 □□                                  | □
M8001C158       | □□□ PDSCH MCS2 □□                                  | □
M8001C159       | □□□ PDSCH MCS3 □□                                  | □
M8001C160       | □□□ PDSCH MCS4 □□                                  | □
M8001C161       | □□□ PDSCH MCS5 □□                                  | □
M8001C162       | □□□ PDSCH MCS6 □□                                  | □
M8001C163       | □□□ PDSCH MCS7 □□                                  | □
M8001C164       | □□□ PDSCH MCS8 □□                                  | □
M8001C165       | □□□ PDSCH MCS9 □□                                  | □
M8001C166       | □□□ PDSCH MCS10 □□                                 | □
M8001C167       | □□□ PDSCH MCS11 □□                                 | □
M8001C168       | □□□ PDSCH MCS12 □□                                 | □
M8001C169       | □□□ PDSCH MCS13 □□                                 | □
M8001C170       | □□□ PDSCH MCS14 □□                                 | □
M8001C171       | □□□ PDSCH MCS15 □□                                 | □
M8001C172       | □□□ PDSCH MCS16 □□                                 | □
M8001C173       | □□□ PDSCH MCS17 □□                                 | □
M8001C174       | □□□ PDSCH MCS18 □□                                 | □
M8001C175       | □□□ PDSCH MCS19 □□                                 | □
M8001C176       | □□□ PDSCH MCS20 □□                                 | □
M8001C177       | □□□ PDSCH MCS21 □□                                 | □
```

```
M8001C178       | □□□ PDSCH MCS22 □□                                    | □
M8001C179       | □□□ PDSCH MCS23 □□                                    | □
M8001C180       | □□□ PDSCH MCS24 □□                                    | □
M8001C181       | □□□ PDSCH MCS25 □□                                    | □
M8001C182       | □□□ PDSCH MCS26 □□                                    | □
M8001C183       | □□□ PDSCH MCS27 □□                                    | □
M8001C184       | □□□ PDSCH MCS28 □□                                    | □
M8001C185       | □□□ PDSCH MCS29 □□                                    | □
M8001C186       | □□□ PDSCH MCS30 □□                                    | □
M8001C187       | □□□ PDSCH MCS31 □□                                    | □
M8001C188       | □□□ PDSCH MCS32 □□                                    | □
M8001C189       | □□□ PDSCH MCS33 □□                                    | □
M8001C190       | □□□ PDSCH MCS34 □□                                    | □
M8001C191       | □□□ PDSCH MCS35 □□                                    | □
M8001C192       | □□□ PDSCH MCS36 □□                                    | □
M8001C193       | □□□ PDSCH MCS
```

PM 数据收集指南

概述

PM 数据收集页面允许您管理存储在 InfluxDB 中的性能指标（PM）计数器。诺基亚 AirScale 基站报告超过 22,000 个独特的 PM 计数器，但在大多数用例中，存储所有计数器既不实际也不必要。
本指南解释了如何根据您的监控需求选择要收集的计数器。

快速开始

访问 PM 数据收集页面
1. 导航到控制面板： https://localhost:9443
2. 在导航菜单中点击 数据过滤器
3. 查看和管理 PM 计数器收集设置

理解界面

该页面分为两个主要部分：

部分 描述
存储的 PM 数据（左侧） 当前正在收集并存储在 InfluxDB 中的计数器可用计数器（右侧） 所有 22,000+ 可添加到您的收集中计数器

计数器类别

PM 计数器按其代码前缀分类，前缀指示技术和功能：

□□	□□□□	□□	□□
LTE	M8xxx	~5,900	LTE L1/L2/L3 □□□□ERAB□RRC□□□□□
WCDMA	M5xxx	~885	3G WCDMA □□□□MAC □□CQI□HSDPA□
5G-NR	M55xxx	~14,500	5G NR □□□□□□□ MIMO□□□□□□□
5G-□□	M51xxx	~500	5G □□□□□□
5G-□□	M40xxx	~250	5G □□/□□□□

□□□□

□□□□□□□ `priv/pm_counters.csv` □□□□□□□□□□□□□□□□□□□□□□□□□□□□

- □□□□□□□
- □□□□□□□□
- □□□□□□□□□□□
- □□□□□RRC □□□□/□□
- **PRB**□□□□□□□□
- □□□□□□/□□□□□□□
- **RRC**□RRC □□□
- **ERAB**□E-RAB □□□□□□□
- **PDCP**□PDCP □□□
- □□□□□□□□□
- □□□□□□□□□

□□□□□

□□□□□

1. □□“□□□□□”□□□□ □□□ □ □□□□□
2. □□□□□□□□□□□□□□□□□□□□□□□□
3. □□ □□ □□□□□□□□□□
4. □□ □□□□ □□□□□□□□□□

□□□□□

1. □“□□□ PM □□”□□□□□□□□□□□□
2. □□ □□□□ □□□□□□□□□□

□□□□□

□□□□□□□□

- □□□□□□□□□□ ID □□□□□
- □□□□□□□□□□□□□□□□□□□□□□□□LTE□5G-NR □□

□□□□□□

□□ □□□□□□ □ `priv/pm_counters.csv` □□□□□□□□□□□□□□□□□□□□□□□□

□□

□ PM □□□□□□□□□□

1. □□□□□□ □ `priv/pm_filters.etf`
2. □□□□□□□□□□□□
3. □□□□□□□□□□

InfluxDB □□□□□□□□□□□□□□□□□□□□/□□□□□□□□□□□□

□□□□

□□□□□□□□□□□□□

□□□□ 22,000+ □□□□□□□□□

□□	□□
□□	□□□□ ~100-500 GB/□□□□□□□□□□
□□□□	□ InfluxDB □□□□□□□□
□□□□	□□□□□□□□□□□□□□□□□□□□
□□	□□□□□□□□□□□

□□□□

1. □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
2. □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
3. □□□□□□□□□□□□□□□□□□

□□□□□

□□□□□□□

“□□□□□”□□□□□□□□□□□□□□□□□□□

□□□□□□□

□□□	□□	□□
M8012C23	LTE	□□□□□□□□□□□□□□□
M8012C26	LTE	□□□□□□□□□□□□□□□
M8001C2	LTE	PDCP SDU □□ DL □□□
M8011C24	LTE	□□ PRB □□□
M8011C37	LTE	□□ PRB □□□
M8013C17	LTE	RRC □□□□□
M8020C3	LTE	□□□□
M40001C0	5G	□□□□

□□□□

pm_counters.csv

□□□□□□□□□□□□□□□□□

```
# □□□□□□□,□□,□□
M8012C23,□□□,□□□□□□□□
M8012C26,□□□,□□□□□□□□
M8001C2,□□□,□□□□□
...
```

□□□ `priv/pm_counters.csv`

pm_metrics.csv

□□□□□□□□□□□□□□□

```
# □□□PM_Code,□□,□□
M8000C6,LTE,S1_SETUP_ATT
M8000C7,LTE,S1_SETUP_SUCC
...
```

□□□ `priv/pm_metrics.csv`

□□□□

□□□□□□□

1. □□□□□□□□□“□□□ PM □□”□□□□
2. □□ eNodeB □□□□□□□ PM □□□□□□□ InfluxDB □□□□□
3. □□□□□ ID □□□□□□□□□□□□□□

□□□□□

1. □□□□□□□□□□□□□□□□□□□
2. □□□□□ **eNodeB** □□□□ **PM** □□□□□□□□□ 15 □□□□□
3. □□□□□□□□□□ `[PmFilterStore]` □□
4. □□□□□□□□□□□□□□□□□□

□□□□□□□

1. □□□□□□□ `priv/pm_metrics.csv`
2. □□□□□□□□□□□□□
3. □□ UTF-8 □□□□

相关文档

数据保留政策 - PM 数据保留多长时间
Grafana 集成 - 使用 PM 数据构建仪表板
InfluxDB 查询 - 查询 PM 数据

访问点

PM 数据收集： https://localhost:9443/nokia/pm-filters
数据保留： https://localhost:9443/nokia/retention InfluxDB 状态： https://localhost:9443/nokia/influx

RAN □□□□□□□□□

□□ **config/runtime.exs**

□□

1. □□
2. □□□□□
3. Web □□
4. □□□□□□
5. □□□□□
6. InfluxDB □□
7. □□□□□□

□□

`config/runtime.exs` □□□ RAN □□□□□□□□□

□□□□□□□□

□□□ □□ RAN □□□□□ **Omnitouch** □□□□□□□□□□□□□□□□□□□□□□□□□□□□□

- □□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□□□
- □□□□ □□□□□□□□□□
- □□□□□□□□□□□□

□□□□ **Omnitouch** □□□□□□□□□ **Omnitouch** □□□□□□□□□□□□

□□□□□□□□□□□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□ Grafana □□□

□□□□□

MySQL/MariaDB □□

```
config :ran_monitor, RanMonitor.Repo,
  username: "omnitouch",
  password: "omnitouch2024",
  hostname: "localhost",
  database: "ran_monitor",
  stacktrace: true,
  show_sensitive_data_on_connection_error: true,
  pool_size: 10
```

□□□ □□□□□□□□□□□□□□□□□□ MySQL □□□□□□□

□□□□

username (□□□)

- □□□□□□□□
- □□□□ `"omnitouch"`
- □□□ □□□□ CREATE□SELECT□INSERT□UPDATE□DELETE □□

- □□□□ □□□□□□□□□□□□□□□□□□□□

password (□□□)

- □□□□□□□□□□□□□□
- □□□□□`"omnitouch2024"`
- □□□□ □□□□□□□□□□□□□□□□□
- □□□ □□□□□□□□□□□

hostname (□□□)

- □□□□□□□□□
- □□□□□`"localhost"`
- □□□
  - `"localhost"` - □□□□□□□□□□□□
  - `"127.0.0.1"` - TCP □□□□□□□
  - `"10.179.2.135"` - □□□□□□□□□ IP
  - `"db.example.com"` - □□□□□□□□□

database (□□□)

- □□□□□□□□□□
- □□□□□`"ran_monitor"`
- □□□ □□□□□□□□□ RAN □□□□□□
- □□□ `CREATE DATABASE ran_monitor CHARACTER SET utf8mb4 COLLATE utf8mb4_unicode_ci;`

stacktrace (□□□)

- □□□□□□□□□□□□□
- □□□□□`true`
- □□□ `true` - □□□□□
- □□□ `false` - □□□□□□

show_sensitive_data_on_connection_error (□□□)

- □□□□□□□□□□□□□

- □□□□`true`
- □□□ `true` - □□□□□□□□
- □□□ `false` - □□□□□□□□□□□□

pool_size (□□)

- □□□□□□□□□□□□□
- □□□□`10`
- □□□□□□
  - 1-5 □□□□`pool_size: 5`
  - 6-20 □□□□`pool_size: 10`
  - 21-50 □□□□`pool_size: 15`
  - 50+ □□□□`pool_size: 20`
- □□□ □□□□□□□ 2 □□□ + 5 □□□ Web UI

Web □□

RAN □□□□□□□ Web □□□□□□□□□□□□□

□□ SOAP/API □□

```
config :ran_monitor, RanMonitor.Web.Endpoint,
  http: [ip: {0, 0, 0, 0}, port: 8080],
  check_origin: false,
  secret_key_base:
"v5tOS1/QRonjwOky7adGGfkBbrJmiJyXhpesJy/jvSZhqLZkREV+rlo1/pR8lkbu",
  server: true
```

□□□ □□□□□□□□□□□□□□□ NE3S □□□ SOAP □□□□

ip (□□)

- □□□□□□□
- □□□□`{0, 0, 0, 0}`□□□□□□□
- □□□

{0, 0, 0, 0} - 监听所有网络接口
{127, 0, 0, 1} - 仅在本地主机上监听
{10, 179, 2, 135} - 在特定 IP 地址上监听

port (整数)

TCP 端口号
当前值：8080
注意：基站必须配置为将数据发送到此端口
防火墙：确保端口对基站 IP 开放

check_origin (布尔值)

验证 WebSocket/HTTP 来源头
当前值：false
解释：对于 SOAP API 设置为 false（不是面向用户的 Web UI）

secret_key_base (字符串)

会话的加密签名密钥
当前值：64 字符随机字符串
生成： mix phx.gen.secret
安全性：保持此密钥的秘密，绝不要提交到公共存储库
影响：更改此项会使所有现有会话失效

server (布尔值)

应用程序启动时启动端点
当前值：true
始终：在 runtime.exs 中应为 true

□□□□ Web UI

```
# □□□□□□□□ HTTPS □□□□□□□ 9443
https_port =
String.to_integer(System.get_env("CONTROL_PANEL_HTTPS_PORT") ||
"9443")

config :control_panel, ControlPanelWeb.Endpoint,
  url: [host: "0.0.0.0", port: https_port, scheme: "https"],
  https: [
    ip: {0, 0, 0, 0},
    port: https_port,
    keyfile: "priv/cert/omnitouch.pem",
    certfile: "priv/cert/omnitouch.crt"
  ]
```

□□□ □□□□ Web □□□□□ UI □ HTTPS □□□

□□□□□

- **CONTROL_PANEL_HTTPS_PORT** - HTTPS □□□□□□□9443□
  - □□□□□□□□□□□□□□ HTTPS □□
  - □□□`export CONTROL_PANEL_HTTPS_PORT=8443`

url (□□□□□)

- □□ URL □□
- **host:** `"0.0.0.0"` - □□□□□□□□□□□
- **port:** □□ `https_port` □□□□□□ CONTROL_PANEL_HTTPS_PORT □□□
- **scheme:** `"https"` - □□ HTTPS □□

https (□□□□□)

- HTTPS □□□□□
- **ip:** `{0, 0, 0, 0}` - □□□□□□□
- **port:** □□ `https_port` □□□□□□ url □□□□□
- **keyfile:** SSL □□□
- **certfile:** SSL □□□

SSL □□□□□

- □□□□□□ SSL/TLS □□
- □□□□□□□□□□□□□□
- □□□□□□□ CA □□□□□
- □□□□□□□□

```
openssl req -newkey rsa:2048 -nodes -keyout omnitouch.pem -x509
-days 365 -out omnitouch.crt
```

□□□ AirScale Webhook □□

```
config :ran_monitor, RanMonitor.Web.Nokia.Airscale.Endpoint,
  url: [host: "0.0.0.0"],
  http: [ip: {0, 0, 0, 0}, port: 9076],
  server: true
```

□□□ □□□□□□□ AirScale □□□□□□□□□

port (□□)

- □□□□`9076`
- □□□ □□□□□ PMCADM □□□□□□□rTpmCollEntityPortNum□□□
- □□□ □□□□□□□□□□□ WebLM □□□□□□□□□□□□□

□□□□□

```
config :logger,
  level: :info

config :logger, :console,
  format: "$time $metadata[$level] $message\n",
  metadata: [:request_id]
```

□□□□

level (□□)

- □□□□□□□□□□□□□
- □□□□□`:info`
- □□□
  - `:debug` - □□□□□□□□□□
  - `:info` - □□□□□□□□□□□□
  - `:warning` - □□□□□□□
  - `:error` - □□□

□□□□□□□□□□

- □□□ `:debug` - □□□□□□□□□
- □□□ `:info` - □□□□□□□□□□□□□□□
- □□□□□ □□□□□ `:debug`□□□□□
- □□□□□□ `:warning` - □□□□□□□□□□□□

□□□□□

format (□□□)

- □□□□□□□□□□
- □□□□`"$time $metadata[$level] $message\n"`
- □□□
  - `$time` - □□□
  - `$metadata` - □□□□□
  - `$level` - □□□□□info□error □□
  - `$message` - □□□□□□

metadata (□□□□)

- □□□□□□□□□□
- □□□□`[:request_id]`
- **request_id:** □□□□□□□□ HTTP □□

□□□□□

□□□□ RAN □□□□□□□□□□□□□□□

```
config :ran_monitor,
  general: %{
    mcc: "505",
    mnc: "57"
  },
  nokia: %{
    ne3s: %{
      webhook_url: "http://10.5.198.200:9076/webhook",
      private_key: Path.join(Application.app_dir(:ran_monitor,
"priv"), "external/nokia/ne.key.pem"),
      public_key: Path.join(Application.app_dir(:ran_monitor,
"priv"), "external/nokia/ne.cert.der"),
      reregister_interval: 30
    },
    airscales: [
      %{
        address: "10.7.15.67",
        name: "ONS-Lab-Airscale",
        port: "8080",
        web_username: "Nemuadmin",
        web_password: "nemuuser"
      }
    ]
  }
```

□□□□

mcc (□□□)

- □□□□□□□
- □□□□ `"505"`
- □□□ □□ 3GPP □□□□□
- □□□ 3 □□□

- □□□ ITU-T E.212

mnc (□□□)

- □□□□□□□
- □□□□："57"
- □□□ □□□□□□□□□□□
- □□□ 2 □ 3 □□□

NE3S ◆◆□□□□□ NE3S □□□

webhook_url (□□□)

- □□□□□□□ URL
- □□□□："http://10.5.198.200:9076/webhook"
- □□□ `http://<ran-monitor-ip>:<port>/webhook`
- **IP** □□□ □□□ RAN □□□□□ IP □□
- □□□ □□□ `RanMonitor.Web.Nokia.Airscale.Endpoint` □□□9076□□□
- □□□ □□□ `/webhook`

private_key (□□□ - □□□□)

- □□□□□□□□□□
- □□□□：`priv/external/nokia/ne.key.pem`
- □□□ PEM □□□□□
- □□□□ □□□□□□□□□□□□□
- □□□ □□□□□□□□□ OpenSSL □□

public_key (□□□ - □□□□)

- □□□□□□□□□□
- □□□□：`priv/external/nokia/ne.cert.der`
- □□□ DER □□□□□
- □□□ □□□□□□□□□□
- □□□ □□□ private_key □□

reregister_interval (□□)

- □□□□□□□□□□□□□□□□
- □□□□□`30`
- □□□ □□□□□□□□□□□□□□□□□□□□□□
- □□□ 30-300 □
- □□□ 30 □□□□□□□□□

AirScale □□

airscales (□□□□□)

- □□□□□□□□ AirScale □□□□
- □□□□□□□□□□□□□

□□□□□□□□□□

address (□□□□)

- □□□ IP □□
- □□□□□`"10.7.15.66"`
- □□□ □□□□□□□ IPv4 □□
- □□□ □□□□□□ RAN □□□□□□□□
- □□□ `ping 10.7.15.66` □□□□

name (□□□)

- □□□□□□□□□□
- □□□□□`"ONS-Lab-Airscale"`
- □□□ □□□ Web UI□□□□ InfluxDB □□□
- □□□ □□□□□□□□□□□□□□□□□□□□
- □□□
  - `"NYC-Site-A-BS1"`
  - `"LAX-Tower-Main"`
  - `"TestLab-Airscale-01"`

port (□□□)

- □□□□□□□□□□

当前值："8080"
标准：诺基亚 AirScale 通常使用 8080
验证：检查基站文档
注意：值为字符串，而不是整数

web_username (字符串)

WebLM 身份验证的用户名
当前值："Nemuadmin"
用法：用于 API 调用以管理基站
权限：应具有配置读/写访问权限
注意：区分大小写

web_password (字符串)

WebLM 身份验证的密码
当前值："nemuuser"
安全性：应在生产环境中存储在环境变量中
轮换：根据安全策略定期更改

添加多个基站

要监控多个基站，请向 airscales 列表添加额外条目：

```
airscales: [
  %{
    address: "10.7.15.66",
    name: "ONS-Lab-Airscale",
    port: "8080",
    web_username: "Nemuadmin",
    web_password: "nemuuser"
  },
  %{
    address: "10.7.15.67",
    name: "Site-A-Tower-1",
    port: "8080",
    web_username: "admin",
    web_password: "password123"
  },
  %{
    address: "192.168.100.50",
    name: "Site-B-Indoor",
    port: "8080",
    web_username: "admin",
    web_password: "different_password"
  }
]
```

InfluxDB □□

```
config :ran_monitor, RanMonitor.InfluxDbConnection,
  auth: [
    username: "monitor",
    password: "sideunderTexasgalaxyview_61"
  ],
  database: "nokia-monitor",
  host: "10.179.2.135"
```

□□□ □□□ InfluxDB □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□

auth (□□□□□□)

- InfluxDB □□□□□□□□
- **username:** InfluxDB □□□□□`"monitor"`□
- **password:** InfluxDB □□□`"sideunderTexasgalaxyview_61"`□
- □□□ □□ InfluxDB 2.x□□□□□ API □□

database (□□□)

- InfluxDB □□□/□□□□□
- □□□□`"nokia-monitor"`
- **InfluxDB 1.x**□ □□□□□
- **InfluxDB 2.x**□ □□□
- □□□ □□□□□ RAN □□□□□□

```
# InfluxDB 1.x
influx -execute 'CREATE DATABASE "nokia-monitor"'

# InfluxDB 2.x
influx bucket create -n nokia-monitor -o your-org
```

host (□□□)

- InfluxDB □□□□□
- □□□□`"10.179.2.135"`
- □□□ IP □□□□□□
- □□□ □□ InfluxDB □□□8086□□□
- □□□
  - `"localhost"` - □ RAN □□□□□□□□
  - `"10.179.2.135"` - □□ InfluxDB □□□
  - `"influxdb.example.com"` - □□□

InfluxDB □□□□□□

□□□□□

RAN 监控必须能够在端口 8086 上访问 InfluxDB 服务器验证：curl http://10.179.2.135:8086/ping

保留策略：

通过 Web UI 数据保留页面设置
默认：30 天（720 小时）
可以根据基站自定义

写入性能：

InfluxDB 每个采集间隔（默认 60 秒）接收写入
每个基站每个间隔生成数百个数据点
定期监控 InfluxDB 磁盘空间

□□□□□□

□□□

1. □□□□□□

```
# □□□□□□□□□□
password: "omnitouch2024"

# □□□□□□□□
password: System.get_env("DB_PASSWORD") || "default_password"
```

2. □□□□□□

```
chmod 600 config/runtime.exs
chown ran_monitor:ran_monitor config/runtime.exs
```

3. □□□□□□□□

- □□ runtime.exs □□□□□□□□ `.gitignore`
- □□□□□□□□□□□□□□
- □□□□□□

□□

1. □□□□□□

- □□□□□□□□
- □□□□□□□□□□□□□□□ pool_size
- □□□□□□□□□□□□□□□ 2 □□□

2. □□□

- □□□□□□□□□□□□□□□□□
- 60 □□□□□□□□□□□□
- □□□□□□15 □□□□□□□□

3. InfluxDB □□

- □□□□□□□□□□□□□□□□
- □□ InfluxDB □□□□
- □□□□□□□□□□□□□ InfluxDB □□□

□□□

1. □□□□

- □□□□□□□□□□ IP □□
- □□ RAN □□□□□□□□□□□□□
- □□□□□□□□□□□□
- □□□□□□□□□□□

2. □□□□□□

- □□□ `□debug` □□□□□□□□□
- □□□ `□info` □□□□□□□□
- □□□□□□□□□□□□□□□

3. □□ RAN □□

- □□□□□□□□□□
- □□□□□□□□□□
- □□ InfluxDB □□□□□
- □□□□□□□□□□□□

□□

1. □□□□

- □□□□□□□□□□ runtime.exs
- □□□□□□□□□□□
- □□□□□□□□□
- □□□□□□□□□□□□ RAN □□

2. □□□□

```
# 1. □□ runtime.exs
vim config/runtime.exs

# 2. □□ Elixir □□
elixir -c config/runtime.exs

# 3. □□□□□□□□□
systemctl restart ran_monitor
```

3. □□□□

- □□□□□□□□□□CPU□□□□□□□□
- □□□□□□□□□□□□□□□□□□□□
- □ 50+ □□□□□□□□□□ InfluxDB □□
- □□ MySQL □ InfluxDB □□□□□

□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□

```
import Config

#
============================================================================
# □□□□□
#
============================================================================

config :ran_monitor, RanMonitor.Repo,
  username: System.get_env("DB_USERNAME") || "ran_monitor_user",
  password: System.get_env("DB_PASSWORD") || "change_this_password",
  hostname: System.get_env("DB_HOST") || "localhost",
  database: "ran_monitor",
  stacktrace: false,  # □□□□□□□□□□
  show_sensitive_data_on_connection_error: false,  # □□□□□□□
  pool_size: 15  # 6 □□□ * 2 + 3 □□□

#
============================================================================
# Web □□
#
============================================================================

config :ran_monitor, RanMonitor.Web.Endpoint,
  http: [ip: {0, 0, 0, 0}, port: 8080],
  check_origin: false,
  secret_key_base: System.get_env("SECRET_KEY_BASE") ||
"generate_with_mix_phx_gen_secret",
  server: true

config :control_panel, ControlPanelWeb.Endpoint,
  url: [host: "0.0.0.0", port: 9443, scheme: "https"],
  https: [
    ip: {0, 0, 0, 0},
    port: 9443,
    keyfile: "priv/cert/server.key",
    certfile: "priv/cert/server.crt"
  ]

config :ran_monitor, RanMonitor.Web.Nokia.Airscale.Endpoint,
  url: [host: "0.0.0.0"],
  http: [ip: {0, 0, 0, 0}, port: 9076],
  server: true
```

```
#
================================================================================
# □□□□□□
#
================================================================================

config :logger,
  level: :info  # □□□□

config :logger, :console,
  format: "$time $metadata[$level] $message\n",
  metadata: [:request_id]

#
================================================================================
# □□□□□
#
================================================================================

config :ran_monitor,
  general: %{
    mcc: "001",
    mnc: "001"
  },
  nokia: %{
    ne3s: %{
      webhook_url: "http://10.179.2.135:9076/webhook",
      private_key: Path.join(Application.app_dir(:ran_monitor, "priv"
"external/nokia/ne.key.pem"),
      public_key: Path.join(Application.app_dir(:ran_monitor, "priv")
"external/nokia/ne.cert.der"),
      reregister_interval: 30
    },
    airscales: [
      # □□ A - □□
      %{
        address: "10.7.15.66",
        name: "Site-A-Main-Tower",
        port: "8080",
        web_username: "admin",
        web_password: System.get_env("BS_SITE_A_PASSWORD") || "passwo
      },
```

```
    # □□ A - □□□
    %{
      address: "10.7.15.67",
      name: "Site-A-Backup-Tower",
      port: "8080",
      web_username: "admin",
      web_password: System.get_env("BS_SITE_A_PASSWORD") || "passwo
    },

    # □□ B - □□
    %{
      address: "10.7.16.10",
      name: "Site-B-Indoor-DAS",
      port: "8080",
      web_username: "admin",
      web_password: System.get_env("BS_SITE_B_PASSWORD") || "passwo
    },

    # □□ C - □□
    %{
      address: "192.168.100.50",
      name: "Site-C-Rooftop",
      port: "8080",
      web_username: "admin",
      web_password: System.get_env("BS_SITE_C_PASSWORD") || "passwo
    },

    # □□□ - □□□□
    %{
      address: "10.5.198.100",
      name: "Lab-Test-Airscale-01",
      port: "8080",
      web_username: "Nemuadmin",
      web_password: "nemuuser"
    },

    # □□□ - □□
    %{
      address: "10.5.198.101",
      name: "Lab-Dev-Airscale-02",
      port: "8080",
      web_username: "Nemuadmin",
      web_password: "nemuuser"
    }
```

```
    ]
  }

#
# InfluxDB □□
#

config :ran_monitor, RanMonitor.InfluxDbConnection,
  auth: [
    username: System.get_env("INFLUX_USERNAME") || "monitor",
    password: System.get_env("INFLUX_PASSWORD") || "change_this_passw
  ],
  database: "nokia-monitor",
  host: System.get_env("INFLUX_HOST") || "10.179.2.135"
```

□□□□

- □□□□ - □□□□
- AirScale □□□□ - □□□□
- □□□□□□□□□ - □□□□□□□□
- Grafana □□ - □□□□□□□□□
- API □□ - REST API □□
- □□□□□□□ - □□□□□□□□□

MDT □□□□□ TCE

□□□□□□□ (TCE)

RAN Monitor □□□□□□□□□□□□□□□□□□□□□□□□□□□□ LTE/5G □□□□□□□□□□□□□□□□□□□□□□□□□□□□ RF □□□□□ □□□□

□□□ TCE□

□□□□□□□□□□□ Nokia AirScale □□□□□□□□□□□□□

- **S1-AP** □□ - eNodeB □ EPC □□□□□□□□□□
- **RRC** □□ - □□□□□□□□□
- **NAS** □□ - □□□□□□□
- □□□□□□□ - PDCP □□□□□□□

TCE □□

□□	□□	□□	□□
NSNTI □□□	TCP	49151	□□□□□□□□□□□□□
TZSP □□□	UDP	37008	□□□□□□□ Wireshark □□□□□□□
□□□□□	ASN.1	-	□□ S1-AP □ RRC □□

□□□□



□□□□□□□□□□□□□□□NSNTI □□□□ (49151)□TZSP □□□□□□□□□

□□□□□□

1. □□ **TCE** □□□□□□□□

   ```
   ss -tlnp | grep 49151
   # □□□□LISTEN 0.0.0.0:49151
   ```

2. □□□□□□□□

   - □□□□□ IP □□□ RAN Monitor □□□
   - □□□□□□□□□□ 49151
   - □□□□□□□□□□ (S1-AP□RRC□NAS)
   - □□□□□□

3. □□ **Wireshark□**

   □□□□□

   - □□□ TZSP □□□□□□□□□□

- □□□□□□□□□`udp port 37008`

□□□□□□□□

RAN Monitor □□□□□ UDP □□□□□□□□□□□□□□ RRC □□□□□ Wireshark □“□□□”□□□□□□□□□□□□

□□ 1□□□ Wireshark GUI

i. □□ **Analyze → Decode As...**
ii. □□ **+** □□□□□□□□
iii. □□□□□□□□□□□

□□	□	□□	□□	□□□
udp.port	36412	□□	(none)	SCTP
sctp.port	36412	□□	(none)	S1AP
udp.port	37000	□□	(none)	TZSP
udp.port	37001	□□	(none)	LTE RRC (DL-CCCH)
udp.port	37002	□□	(none)	LTE RRC (DL-DCCH)
udp.port	37003	□□	(none)	LTE RRC (BCCH)
udp.port	37004	□□	(none)	LTE RRC (PCCH)
udp.port	37008	□□	(none)	TZSP
udp.port	37011	□□	(none)	LTE RRC (UL-CCCH)
udp.port	37012	□□	(none)	LTE RRC (UL-DCCH)
udp.port	38000	□□	(none)	MAC-LTE
udp.port	38001	□□	(none)	MAC-LTE (DL)
udp.port	38002	□□	(none)	MAC-LTE (BCH)
udp.port	38003	□□	(none)	MAC-LTE (PCH)
udp.port	38011	□□	(none)	MAC-LTE (UL)
udp.port	38012	□□	(none)	MAC-LTE (RACH)

□□ 2□□□ decode_as_entries □□

□□□□□ `~/.config/wireshark/decode_as_entries` (Linux/Mac) □ `%APPDATA%\Wireshark\decode_as_entries` (Windows)□

```
# RAN Monitor TZSP □□□□
decode_as_entry: udp.port,36412,(none),SCTP
decode_as_entry: sctp.port,36412,(none),S1AP
decode_as_entry: udp.port,37000,(none),TZSP
decode_as_entry: udp.port,37001,(none),LTE RRC
decode_as_entry: udp.port,37002,(none),LTE RRC
decode_as_entry: udp.port,37003,(none),LTE RRC
decode_as_entry: udp.port,37004,(none),LTE RRC
decode_as_entry: udp.port,37008,(none),TZSP
decode_as_entry: udp.port,37011,(none),LTE RRC
decode_as_entry: udp.port,37012,(none),LTE RRC
decode_as_entry: udp.port,38000,(none),MAC-LTE
decode_as_entry: udp.port,38001,(none),MAC-LTE
decode_as_entry: udp.port,38002,(none),MAC-LTE
decode_as_entry: udp.port,38003,(none),MAC-LTE
decode_as_entry: udp.port,38011,(none),MAC-LTE
decode_as_entry: udp.port,38012,(none),MAC-LTE
```

□□□□□□□

□□	□□	□□/□□	□□
36412	S1AP	-	□□ S1AP □□□□ (eNodeB ↔ EPC)
37000	RRC	□□	□□ RRC □□□□□□□
37001	RRC	DL-CCCH	□□□□□□□□
37002	RRC	DL-DCCH	□□□□□□□□
37003	RRC	BCCH-DL-SCH	□□□□□□ (□□□□□□)
37004	RRC	PCCH	Paging Control Channel
37008	TZSP	-	□□ TZSP □□□□
37011	RRC	UL-CCCH	□□□□□□□□ (RRC □□□□)
37012	RRC	UL-DCCH	□□□□□□□□ (□□□□)
38000	MAC-LTE	□□	□□ MAC □□□□□□□
38001	MAC-LTE	□□	□□□□□□
38002	MAC-LTE	BCH	□□□□
38003	MAC-LTE	PCH	Paging Channel
38011	MAC-LTE	□□	□□□□□□
38012	MAC-LTE	RACH	□□□□□□

□□□□□□□□□

```
# □□□□□ TZSP □□□
tzsp

# □□□□□□□
s1ap || rrc || mac-lte

# □□□□□□ RRC □□
udp.port == 37011 || udp.port == 37012

# □□□□□□ RRC □□
udp.port == 37001 || udp.port == 37002

# □□ RRC □□□□□
rrc.rrcConnectionRequest || rrc.rrcConnectionSetup

# □□□□□□□
s1ap.HandoverRequired || s1ap.HandoverCommand
```

□□

□□□□□□

- □□□□□□□ RF □□
- □□□□□□□
- □□□□□□□ (RSRP, RSRQ, SINR)
- □□□□□□□

□□□□□□

- □□□□□□□□□□
- □□□□□□□
- □□□□□□□
- □□□□□□□

RF □□□

- PCI □□□□
- □□□□□□□

- □□□□□□□
- □□□□□□□□

□□

□□□□□□□□ **(MDT)** □□□□□□□ UE □□□□□□□ (RSRP□RSRQ□□□□□)□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ Omnitouch RAN Monitor Web UI □ Nokia AirScale □□□□ MDT □□□□□ Wireshark □□□□

□□



TCE□□□□□□□□□□□□ Omnitouch RAN Monitor □□□□□ Nokia □□□ Ne3s □□□□□□□□□□ Wireshark □□□□□□□□□□

□□□□

□□□□□

Nokia Airscale □□□□□□□□□□ □□□□□□□□ □□□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ ONS□

□□□□

- Omnitouch RAN Monitor □ TCE □□□□
- □□□□□□□□□ Wireshark 3.0 □□□□□
- □ Wireshark □□□ TCE Lua □□ (□□□ TCE README)
- □ AirScale □□□□□

□□ MDT □□

□□□ RAN Monitor □ TCE □□□□ Nokia □□□□□□□□ Wireshark □□□□□□□□

□ 1 □□□□□□□□□□□□

□□ RAN Monitor Web UI □□□□□□□□□□□□□ TCE□

1. □□ Web UI: `https://<ran-monitor-ip>:9443`
2. □□□ □□ □□
3. □□□□□□□□□□□
4. □□ □□□□ □□
5. □□□□□□□□□□□
6. □□□□□□□□/□□ TCE □□□
   - □□□□□□□ **IP**: `<□□ RAN Monitor IP>`
   - □□□□□□□□□: `49151`
7. □□□□□□□□□
8. □□□□□□□□□□□□□
9. □□□□

□□□□□□□□□ **AirScale** □□□□□□□□□□□ **ONS**□

□ 2 □□□ AirScale □□□ MDT

□□□□□□□□ MDT □□□□□□□□□□

- □□□□□□□ MDT□□□□□□□ MDT□□□□□□
- □□□□□□□□□□□□□□□□ PLMN □□
- □□□□□UE □□□□□□□□□5000ms□
- □□□□□RSRP□RSRQ □□□
- □□□□□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□□ **ONS**□

□ 3 □□□□□□□□□

□□□□□□□□ AirScale □□□□□□□□□□□□□□□□ MDT □□□□□□ TCE□□□□□□□□□□□□□□□□□□

□ Wireshark □□□ MDT □□

□□ Wireshark □□

1. □□□□□□□□□ Wireshark
2. □ □□□□□ □□□□□Linux □□ `lo`□macOS □□ `lo0`□Windows □□ `Loopback`□
3. □□□□□□□□□`udp port 37008`
4. □□□□

□□ Wireshark □□□□□□ S1AP □□□□□□□ (InitialUEMessage, Attach request)□LTE RRC □ □ (RRCConnectionReject, RRCConnectionReestablishment) □□□ TCE □□□□□□□□□□

□□ MDT □□

□□□□□□□□□□□□□□□□□□□□

```
# □□□□□ RRC □□□□□
lte-rrc.measurementReport

# □□□□□□□ RRC □□
udp.dstport >= 37011 && udp.dstport <= 37012

# □□ RSRP □□ (< -100 dBm)
lte-rrc.rsrpResult < 40

# □□ RSRQ □□ (< -12 dB)
lte-rrc.rsrqResult < 22
```

□□□□

MDT □□□ **RRC MeasurementReport** □□□□□□□□□□□□

- □□□□□□□□□□□□□ RSRP □ RSRQ
- □□□□□□□□□□□□□ RSRP □ RSRQ
- □□ **ID**□□□□□□□□□□□ ID
- **GPS** □□□□□□□□□□ UE □□

□ Wireshark □□□ RRC □□□□□□□□□□

```
□□□□□□□ (RRC)
└─ UL-DCCH-Message
    └─ message: measurementReport
        └─ MeasurementReport
            └─ measResults
                ├─ measResultServCell (□□□□ RSRP/RSRQ)
                └─ measResultNeighCells (□□□□□)
```

□□□□□□□

□□□□□□□□

1. □□ → □□□□□□□ → □□ **CSV**
2. □□□□□ `lte-rrc.rsrpResult` □ `lte-rrc.rsrqResult` □ `lte-rrc.physCellId`

3. □ Excel□Python □□□□□□□□□

□□□□

□□□□□□□□ RSRP/RSRQ □□□□

```
lte-rrc.rsrpResult < 40 || lte-rrc.rsrqResult < 22
```

□□□□□□□□ UE □□□□□□□

```
lte-rrc.MeasResultListEUTRA
```

□□□□□□□□□ RSRP □□□ RSRQ □□□□

```
lte-rrc.rsrpResult > 50 && lte-rrc.rsrqResult < 20
```

□□□□

Wireshark □□□□□□

- □□ TCE □□□□□□□□`ps aux | grep beam`
- □□ Wireshark □□□□□□□□ `udp port 37008` □□□□
- □□ AirScale □□□□□□□□□□□□□□
- □□□□□□□□□ TCE IP/□□□□□□□

□□□□□□□

- □□□□□□□□□□ (MDT + □□□□□□)
- □□□□□□□□□□□□
- □□ UE □□ MDT (LTE Release 10+)

□□□□□□□□□□□□□□□ **AirScale** □□□□□□□□□ **ONS**□

快速启动检查表

验证 MDT 和每通话测量许可证是否有效
在 AirScale 上配置 TCE IP (RAN Monitor IP) 和端口 49151 在 RAN Monitor 服务器上启动 TCE
在基站上激活 MDT 跟踪会话
在回环上启动 Wireshark 捕获，过滤器为 udp port 37008 应用显示过滤器：lte-rrc.measurementReport
分析测量并根据需要导出

支持

Omnitouch 网络服务 (ONS)：有关 AirScale 配置、许可证和部署的帮助

□□□□□□

RAN □□□□□□□□

□□□□□□□□□□□□□□□

□□

1. □□
2. □□□□□□
3. □□□□□□
4. Web UI □□
5. □□□□□
6. □□□□
7. □□□□
8. □□□□
9. □□□□

□□

□□□□□□□□□□□□ RAN □□□□□□□□□□□□□□□□

- □□□□□□□□□
- □ Web UI □□□□□□□
- □□□□□□□
- □□□□□□□□□□

3. □□□□□□

- □□□□□□
- □□□□□□
- □□□□□□
- □□□

4. □□□□□□

- □□□□□□□□□□
- □□□□□□□□□□□□□□
- □□□□□□□□
- □□□

□□□

□□□□□□□

- RAN □□□□□□□□□□ (`ps aux | grep ran_monitor`)
- □□□□□□□□□□ (MySQL, InfluxDB)
- □□□□□□□□□
- □□□□□□□□

□□□□□

□□□□□□□

□□□

- □□□ Web UI □□□“□□□”

- □□□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□
- □□□□□□□□□□□□□□□

□□□□□

1. □□□□□□□

```
# □□□□□□□
ping <device-ip>

# □□□□□□□
telnet <device-ip> 8080
```

□□□ □□□ ping □ telnet □□
□□□□□ □□□□ - □□□□□□□□□□□□□□□

2. □□□□

□ Web UI → □□ → □□□□ → □□□□□

- IP □□□□□□□□
- □□□□□□□□□□ 8080□□
- □□□□□□□□□

□ `config/runtime.exs` □□

```
%{
  address: "10.7.15.66",  # □□□ IP□
  name: "Site-A-BS1",
  port: "8080",           # □□□□□□
  web_username: "admin",  # □□□□□□□
  web_password: "password" # □□□□□□
}
```

3. □□□□□□□□□

Web UI → □□□□□□ → □□□□□□□

查找：

[error] Authentication failed → 凭据不正确 [error] Connection refused → 端口/防火墙问题 [error] Timeout → 网络连接问题
[error] Certificate error → 管理员密钥/证书问题

解决方案：

网络问题：

1. 验证设备已开机并正常运行
2. 检查 RAN 监控器与设备之间的网络路由
3. 验证防火墙允许：
RAN 监控器 → 设备端口 8080
设备 → RAN 监控器端口 9076（webhooks）
4. 从 RAN 监控器服务器直接测试

凭据不正确：

1. 验证凭据在设备 WebLM 界面上是否有效
2. 更新 config/runtime.exs 中的凭据
3. 重启 RAN 监控器
4. 监控日志以确认注册成功

端口/防火墙问题：

1. 验证配置中的端口是否正确
2. 检查两侧的防火墙规则
3. 测试端口可访问性：telnet <device-ip> 8080
4. 查看设备侧的安全设置

管理员密钥/证书问题：

1. 验证文件是否存在：
priv/external/nokia/ne.key.pem priv/external/nokia/ne.cert.der
2. 检查文件权限（应可读）

3. □□□□□□□□□□□ Nokia □□□□
4. □□□□□□□□□□□ Nokia □□

□□□□□□□□□

□□□

- □□□□□□□□□□□□□
- □□□□□□“□□□□”□□
- Web UI □□□□□□□□□□□/□□
- □□□□□□□□□

□□□□□

1. □□□□□□□

Web UI → □□ → □□□□ → □□□□□□□□

- □□□□□□□□□□□
- □□□□□□□□□□
- □□□□□□□□□□

2. □□□□□□□□□

□ `config/runtime.exs` □□

```
nokia: %{
  ne3s: %{
    reregister_interval: 30  # □□ 30-60 □
  }
}
```

3. □□□□□□□□

- □□□□□□□□□□□□□□
- □□□□□□□□`ping <device-ip> -c 100`
- □□□□□□□□□□□□□□□

4. □□□□□□□

```
# □ RAN □□□□□□□□
date

# □□□□□□□□□□□□□□
# □□□□□□□□□□
```

□□□□□

□□□□□□□□□□

1. □ `reregister_interval` □□□ 30 □
2. □□ RAN □□□
3. □□□□□□□□

□□□□□□

1. □□□□□□□□□□□□□
2. □□□□□□□□□□□□□
3. □□□□□/□□□□□
4. □□□□□□□□□

□□□□□

1. □ RAN □□□□□□□□□□ NTP
2. □□□□□□□□□
3. □□□□□□□□□□□□□

□□□□□□

1. □□□□□□□□□□□
2. □□□□□□□□□□□□□
3. □□□□□□□□□□□□□□□□□□□

××□□□□□□□

□□□

- □□□ Web UI □□□□“□□□”□□□□
- □□ InfluxDB □□□□□□□□
- Grafana □□□□□□□□□
- InfluxDB □□□□□□□□□□□□

□□□□□

1. □□□□□□□□□□

Web UI → □□□

- □□□□□□□□□□
- □□□□□□□□□□□□□□□□
- □□□□□□□□□□□□

2. □□ **InfluxDB** □□

Web UI → InfluxDB □□□

- □□□□□□□□□□
- RAN □□□□□□□□ InfluxDB□

□□□□□

```
# □ RAN □□□□□□□
curl http://<influxdb-host>:8086/ping
```

3. □□□□□□□□□

□□□

- `[error] InfluxDB write failed` → □□□□□□□□
- `[error] Failed to collect metrics` → □□□□□□
- `[info] Metrics collected: 0` → □□□□□□□□

4. □□□□ InfluxDB

□□ InfluxDB □□□□□□□□□□

```
# InfluxDB 1.x
influx -database 'nokia-monitor' -execute '
  SELECT COUNT(*) FROM PerformanceMetrics
  WHERE basebandName='''Site-A-BS1'''
  AND time > now() - 1h
'

# InfluxDB 2.x
influx query 'from(bucket:"nokia-monitor")
  |> range(start: -1h)
  |> filter(fn: (r) => r.basebandName == "Site-A-BS1")
  |> filter(fn: (r) => r._measurement == "PerformanceMetrics")
  |> count()'
```

□□□□□

InfluxDB □□□□□

1. □□ InfluxDB □□□□□□
2. □□ `config/runtime.exs` □□□□□□□
   - □□□□
   - □□□8086□
   - □□□/□□□
   - □□/API □□
3. □ RAN □□□□□□□□□□
4. □□□□□□□□□□□ 8086
5. □□□□□□□ RAN □□□

InfluxDB □□□□□

1. □□□□□□□□□□□/□□□□□□
2. □□ InfluxDB □□□□□□□□□□□
3. □□□□□□□□□□□ API □□
4. □□□□□□□ `config/runtime.exs`

5. □□ RAN □□□

InfluxDB □□□□□

1. □□□□□□□□`df -h`
2. □□□□□□□
3. □□□□□□□□□□□
4. □□ □□□□□□□□□

□□□□□□□□□

1. □□□□□□□□□□□□□□□
2. □□□□□□□□□ webhook URL □□□□
3. □□□□□□□□□□□
4. □□ RAN □□□ webhook □□□□□□□□□□□□□ 9076□

□□□□□□

□□□□□□□□□□□

□□□

- Grafana □□□□□□□□□□□□□□
- □□□□□□□□□□□
- InfluxDB □□□□□□□□□□□

□□□□□

1. □□□□□□□□□□□□□

□□□□□□□□□□□□□□□

```
# □□□□□□□□□□□□□□□
journalctl -u ran_monitor --since "2025-12-29" --until "2025-12-
30"
```

2. 检查设备连接历史

Web UI → 基站 → 设备 → 查看“最后联系”历史

设备在间隙期间是否连接？
是否存在连接问题？

3. 检查 InfluxDB 可用性

在间隙期间是否有 InfluxDB 中断？

检查 InfluxDB 日志
查看监控/警报历史

解决方案：

RAN 监控器停机：

服务中断期间数据间隙是正常的
历史数据无法回填
记录事件并恢复服务

设备断开连接：

调查设备断开的原因
修复连接问题
断开连接期间数据间隙是正常的
未来数据将恢复收集

InfluxDB 中断：

指标可能已收集但未存储
检查 RAN 监控器日志以获取写入失败信息
恢复 InfluxDB 服务
数据间隙无法恢复

预防：

实施 RAN 监控器正常运行时间的监控

- □□□□□□□□□□□□
- □□ InfluxDB □□□□
- □□□□□□□□□□□□□□/□□

Web UI □□

□□□□□□□ Web UI

□□□

- □□□□□□□□ https://<ran-monitor-ip>:9443
- □□□□□□□□
- SSL □□□□

□□□□□

1. □□ Web UI □□□□□□

□□□□□□□□□

```
[info] Running ControlPanelWeb.Endpoint with cowboy
```

□□□□□

```
ps aux | grep control_panel
netstat -tulpn | grep 9443
```

2. □□□

□□□□□□□

```
telnet <ran-monitor-ip> 9443
```

□ RAN □□□□□□□□□

```
curl -k https://localhost:9443
```

3. □□□□□

```
# □□□□□□□□□
sudo iptables -L -n | grep 9443

# □
sudo firewall-cmd --list-ports
```

□□□□□

□□□□□□

1. □□□□□□□□□
   ```
   sudo firewall-cmd --add-port=9443/tcp --permanent
   sudo firewall-cmd --reload
   ```
2. □□□□□□

Web UI □□□

1. □□ `config/runtime.exs` □□ Web □□□
2. □□ SSL □□□□□□□□
3. □□□□□□□□□□□□□□□□
4. □□ RAN □□

SSL □□□□

1. □□□□□□□□□□□□□□□
   ```
   ls -l priv/cert/omnitouch.pem
   ls -l priv/cert/omnitouch.crt
   ```
2. □□□□□□□□
   ```
   openssl x509 -in priv/cert/omnitouch.crt -text -noout
   ```

3. □□□□□□□□□□□□□□□□
4. □□ RAN □□□

□□□□□

1. □□ `config/runtime.exs` □□□□□□
2. □□□□□□□□□□□□□□□
3. □□□ `CONTROL_PANEL_HTTPS_PORT` □□□□

□□□Web UI □□□□□□□□

□□□

- Web UI □□□
- □□□□□□□□□□□□□□□□
- □□□□□□□□□□

□□□□□

1. □□□□□□□

□ `config/runtime.exs` □□□□□□□□□□□□

```
airscales: [
  # □□□□□□□□□
]
```

2. □□□□□□□

□□□□□□□ MySQL □□

```
mysql -u ran_monitor_user -p ran_monitor -e "SELECT * FROM
airscales;"
```

3. □□□□□□□□

□□□□□□□□□□□□□□□□

□□□□□

□□□□□□

1. □ `config/runtime.exs` □□□□□
2. □□ RAN □□□
3. □□□□□□ Web UI □

□□□□□□□□

1. □□ MySQL □□□□□□
2. □□ `config/runtime.exs` □□□□□
3. □□□□□□□
4. □□ RAN □□□

□□□□

□□□MySQL □□□□

□□□

- □□□□□□□□□□□□□□□□□□
- Web UI □□□□□□□□□□
- “□□□□□□□”□□

□□□□□

1. □□ **MySQL** □□□□□□

```
systemctl status mysql
# □
systemctl status mariadb
```

2. □□□

□ RAN □□□□□□□

```
mysql -h <mysql-host> -u <username> -p <database>
```

3. □□□□

□ `config/runtime.exs` □□

```
config :ran_monitor, RanMonitor.Repo,
  username: "ran_monitor_user",
  password: "password",
  hostname: "localhost",
  database: "ran_monitor",
  pool_size: 10
```

□□□□□

MySQL □□□□

1. □□ MySQL □□□
   ```
   systemctl start mysql
   ```
2. □□□□□□□□□□
3. RAN □□□□□□□□□□

□□□□□□□

1. □□□□□□□□□□□□□□□□□□□□□□
2. □□□□□□□
3. □□□□□□□□□□ `config/runtime.exs`
4. □□ RAN □□□

□□□□□

1. □□□ MySQL □□□□□□□□□
2. □□□□□□□□□□□□ 3306
3. □□ MySQL □□□□□□□□□□□□□□□□□□□□□

□□□□□

1. □□ MySQL max_connections □□
2. □□□□□□□□□□□□ pool_size
3. □□ RAN □□□

□□□□

□□□□ CPU □□□□□□□

□□□

- RAN □□□□□□□□□ CPU □ RAM
- □□□□□□□□□□□
- □□□□□□□□
- □□□□□□□

□□□□□

1. □□□□□□□□□

```
# CPU □□□
top -p $(pgrep -f ran_monitor)

# □□□□□□□
ps aux | grep ran_monitor
```

2. □□□□□□□□□□

□□□□□□□□□

- □□□□ = □□□□□□□□
- □□□□□□□□□□□□□□

3. □□□□□□

□□□□□□□□□□□□

- □□□ = □□□ CPU/□□□□
- □□□□ 10 □□□□□□□□

4. □□□□□□□□□□□

□ `config/runtime.exs` □□

```
pool_size: 10  # □□□□□□□
```

□□□□□

□□□□□□□□□□□□□□□

1. □□□□□□□□□
2. □□□□□□□□□CPU/RAM□
3. □□□□□□□□□□□
4. □□□□□□□□□□□□□

□□□□□□□□□

1. □□□□□□□ pool_size
2. □□□□□□□□□ 2 □□□ + 5 □□□ Web UI
3. □□ RAN □□□
4. □□□□□□□□

□□□□□

1. □□□□□□□□□
2. □□□□□□□□□□□□□□□□□
3. □□□□□□□□□ RAN □□□
4. □□□□□□□□□□□□□

InfluxDB □□□□□

1. □□ InfluxDB □□□□□□
2. □□ InfluxDB □□□□□
3. □□□□□ InfluxDB □□□
4. □□□□□□□□□□□□

□□□Web UI □□□□

□□□

- Web UI □□□□□□□□□□□□
- □□□□□□□□
- □□□□□□□□□□□□□

□□□□□

1. □□□□□□□□

RAN □□□□□□□□□□□□

```
top
free -h
df -h
```

2. □□□□□□□□

□□□□□□□□□□□

```
# MySQL □□□□□
mysql -u root -p -e "SHOW VARIABLES LIKE 'slow_query_log%';"
```

3. □□□□□□□

□□□□□□□□□□□□□□□□□□□

□□□□□

□□□□□□□□□

1. □□□□□□□□
2. □□□□□□□□
3. □□□□□□□□□□□□□□□

□□□□□□

1. □□ MySQL □□
2. □□□□□□□□□□□□□□□□□□□□
3. □□□□□□□□□□□□

□□□□□

1. □□□□□□
2. □□□□□□□□□□
3. □□□□□□□□□□□□□

□□□

□□□□□□□□

□□□

- □□□□□□□□□□□□□
- □□□□□□□□□□□□□
- □□□□□□

□□□□□

1. □□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□

2. □□ **Webhook** □□□

Webhook □□□□□□□□□□

```
netstat -tulpn | grep 9076
```

□□□

```
tcp  0  0.0.0.0:9076  0.0.0.0:*  LISTEN
```

3. □□ Webhook □□

□□□□□□□□□ webhook URL □□□□ RAN □□□□

```
http://<ran-monitor-ip>:9076/webhook
```

4. □□□□□□□□

□□ webhook □□□□□□□□□□□□□□

5. □□ InfluxDB

□□□□□□□□

```
influx -database 'nokia-monitor' -execute '
  SELECT COUNT(*) FROM Alarms WHERE time > now() - 1h
'
```

□□□□

Webhook □□□□□□□

1. □□ `config/runtime.exs` □□ webhook □□□□
2. □□□□ 9076 □□□□□
3. □□ RAN □□□
4. □□□□□□□□□

□□□□□□

1. □□□□□□□□□□□□
2. □□□□□□□□ webhook URL
3. □□□□□□□□□□

□□□□□□

1. □□□□□□□□□□□ RAN □□□□□ 9076
2. □□□□□□□□□□□□□
3. □□□□□□□□□□□`telnet <ran-monitor-ip> 9076`

InfluxDB □□□□□

1. □□ InfluxDB □□
2. □□□□□□
3. □□ InfluxDB □□□□
4. □□□□□□□□□□□□□□□□

□□□

□□□□□

□□ **Web UI** □□□

1. □□□□□□□□□□□
2. □□□□□□□
3. □□□□
4. □□□□□□□□

□□□□□□□

□□□ systemd □□□□□

```
journalctl -u ran_monitor -f
```

□□□ mix □□

- □□□□□□□□□□□

□□□□

- □□/□□/□□ - □□□□□□

- □□ - □□□□□□□□
- □□ - □□□□
- □□ - □□□□□□
- □□ - □□□□□□

□□□□□□□

- □□□□□□□□“Site-A-BS1”□
- “error” □ “failed”
- “InfluxDB” □ “MySQL”
- “registration” □ “session”

InfluxDB □□

□□□□□□□□

```
influx -database 'nokia-monitor' -execute '
  SELECT * FROM PerformanceMetrics
  WHERE basebandName='''Site-A-BS1'''
  AND time > now() - 5m
  LIMIT 10
'
```

□□□□□□□□

```
influx -database 'nokia-monitor' -execute '
  SELECT COUNT(*) FROM PerformanceMetrics
  GROUP BY basebandName
'
```

□□□□□

```
influx -database 'nokia-monitor' -execute '
  SELECT * FROM Alarms
  WHERE time > now() - 1h
'
```

MySQL □□

□□□□□□□□□

```
SELECT name, address, port, registration_status
FROM airscales;
```

□□□□□□□□□□□□

```
mysql -u ran_monitor_user -p ran_monitor -e "SHOW PROCESSLIST;"
```

□□□□

□□□□□

```
# □□□□
ping <device-ip>

# □□□□□□□
telnet <device-ip> 8080
nc -zv <device-ip> 8080

# □□□□
traceroute <device-ip>
```

□□□□□□□

```
# □□□□
sudo iptables -L -n -v

# □□□□□□□
sudo iptables -L -n | grep 8080
```

获取帮助

联系支持之前

收集以下信息：

1. 问题描述

什么没有工作？
何时开始的？
最近有什么变化？

2. 错误消息

复制日志中的确切错误消息
包括时间戳
注意错误的频率

3. 系统信息

RAN 监控器版本
操作系统及版本
数据库版本（MySQL、InfluxDB）
监控的设备数量

4. 诊断结果

上述诊断步骤的结果
相关日志摘录
配置（清理密码）

5. 影响

受影响的设备数量？
这是否阻碍了操作？
业务影响是什么？

□□□□

- **Web UI □□** - □□□□□□□
- □□□□□□□ - □□□□□
- □□□□□□□□ - □□□□□
- **Grafana □□□□** - □□□□□
- □□□□□□□ - □□□□□
- □□□□□□□□□ - □□□□□
- □□□□ - □□□□□

□□□□□

□□□□□□□□

- Web UI □□□□□□□□□□□□
- □□□□□`journalctl -u ran_monitor`
- □□□□□□

□□□□□□□□□

- □□□□□□□
- □□□□□/□□
- □□□□□
- □□□□□

□□□□□□□□

- □□□□□ Web UI □□
- □□□□□□□□□□□□
- InfluxDB □□□□□□□
- □□□□□□□□

□□

□□□□□□□□□□□

1. □□□□□□□□□□□□□□
2. □□□□□□□
3. □□ Omnitouch □□□□□□□□□□
4. □□□□□
    - □□□□□□□□□□□□
    - □□□□
    - □□□□□□□□□□
    - □□□□

□□□□

- □□□□ - □□□□□□□
- **Web UI □□** - □□□□□□□□□
- □□□□□□□ - □□□□
- □□□□□□□ - □□□□□□□
- □□□□□□□□ - □□□□
- **Grafana □□□□** - □□□□□□□
- □□□□□□□□□ - □□□□□□□□□

Web UI □□

RAN □□□□□□□ - □□□□□□□

□□ RAN □□□□ Web □□□□□□□□□□

□□

1. □□
2. □□ Web UI
3. □□□□
4. □□□□
5. □□□□□□
6. □□□□
7. □□□□
8. □□□□ eNodeB □□
9. □□□□□□
10. □□□□□□□□
11. InfluxDB □□□□
12. □□□□□□
13. PM □□□□□□
14. □□□□□□
15. □□□□□□
16. Web UI □□□

□□□□

- □□□□□□ - □□□□□□□□

□□

RAN □□□□□□□□□□□ Web □□□□□□□□□□□

- □□□□□□□□ CA □□□□□
- □□□□□ `config/runtime.exs` □

□□□□□□□□□□□□□ □□□□□□□□□

□□□□□ □□□□□□□ 5 □□□□□□□□□□□□□□□□□□□

□□□□

□□□□□□□ RAN □□□□□□□□□

□□□□

□□□□

- □□□□□□□
- □□□□□□□□□□□□□□

□□□□

- □□/□□□□□□□□
- □□□□□□□
- □□□□□□□□□

□□□□

- □□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□

□□□□

- □□□□□□□□
- □□□□
- □□□□□□□

□□

- □ 5 □□□□□
- □□□□□□□□□□□□□□ = □□□□□ = □□□
- □□□□□□□□□
- □□□□□□

□□□□

□□□□□□□□□□□□□□□□□□□□□□

URL: `https://<ran-monitor-ip>:9443/nokia/enodeb`

□□□□□□□□□□□□□□□□□□□□□□ NOKIA eNodeB □□□□□

□□□□

□□□□□□□□□□□□□

□□□□	□□
□□□	□□□□□□□□
□□□	□□□□□□□□□□
□□□	□□□□□□□□
□□□	□□□□□□□□□□

□□□

□	□□
□□	□□□□□□□□□
□□	□□□□□“□□□”□□□□□“□□□”□□□□
□□	□□ IP □□□□□
□□	□□□□□“□□”□□□□□“□□□”□□□□
□□	□□□□□□

□□□□

□□□□□□□□□□□□□□

□□	□□
Ping	□□□□□□□□□□□
□□	□□□□□□□□□
□□□□	□□□□□□□□□□□□□□□□□□□□□□□□□□
□□□□	□□□□□□□□□□□□□

□□□□□□

□□□□□□□□□□□□□□□□□

□□	□□
□□□ **ID**	□□□□□□□□□
□□ **ID**	□□□□□□□□
□□□□	□□□□□□□□□□□□COMA□
□□□	□□□□□□□Nokia□

□□□□□

- □□□□□□□□
- □□□□□□□ IP □□□□
- □□□□□□□

□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□□

- □□□□□□□□□□
- □□□□□
- □□□□□□□
- □□□□□□□□

□□□□□□

- □□□□□□
- □□□□□□
- □□□□□□□□□
- □□□□□□□□□
- □□□□□□□

□□□□

- □□□□□□□□
- □□□□□□□□
- □□□□□□
- □□□□□□

□□□□

- □□□□□□□□□□
- □□□□□□□□
- □□□□□
- □□□□□□□

□□□□

- □□□□□
- □□□□□□□
- □□□□□
- □□□□□□

警报页面

在一个集中视图中监控网络中的所有故障。

警报信息

严重性级别：

关键（红色） - 影响服务，需立即采取行动
主要（橙色） - 显著降级，需紧急关注
次要（黄色） - 不影响服务，应该处理
警告（蓝色） - 信息性，监控趋势
已清除（绿色） - 先前活动的警报已解决

警报详细信息：

问题描述
可能原因
受影响的系统（DN - Distinguished Name）
时间戳（警报发生和最后更新时）

特性

颜色编码：

立即可视化识别严重性
红色 = 关键警报
橙色 = 主要警报
黄色 = 次要警报
蓝色 = 警告
绿色 = 已清除

排序和过滤：

按严重性、设备或时间排序

- □□□□□□□□
- □□□□□□□

□□□□□

- □□□□□□□□□□□□□□□□□□□□
- □□□□□□□□□□□
- □□□□□□□□□

□□□□□□□□□□□□□□□□□□ □□□□□□□□

□□□□

Web UI □□□□□□□□□□□□□□□□□□□□□□

□□□□

□□□□ □□□□□□□□□□□

□□□□

1. □□□□□□□□□□□
2. □□“□□□□□”
3. □□□□□□□□□
4. □□□□□□□□ XML □□

□□□□□□ □□□□□□□□□□□□□□□□□□□□□□

□□□□

□□□□ □□□□□□□□□□□

□□□□

1. □□ XML □□□□□
2. □□“□□□□□”

3. □□□□□□□□□□□“□□”□
4. □□□□□□□□□ ID □□□□□□

□□□ □□□□□□□□□□ - □□□□□□□

□□□□

□□□ □□□□□□□□□□□□□□□

□□□

1. □□□□□□□□ ID
2. □□“□□”
3. □□□□□□□□□□
4. □□□□□□□□□□□□□□□□

□□□ □□□□□□□□□□□□□□□□□□□□□□□□

□□□□

□□□ □□□□□□□□□□□

□□□

1. □□□□□□□□□ ID
2. □□“□□□□”
3. □□□□□□□□□□□
4. □□□□□□□□□□□/□□

□□□ □□□□□□□□□□□□□□□□□□□□ - □□□□□□□□□

□□□□□

□□□□□

1. □□□□□□□□□□□
2. □□□□□□□
3. □□□□□□□□□□□ ID□

4. □□□□□□□□□□□□□□
5. □□□□□□□□□□□
6. □□□□□□□□□
7. □□□□□□□□

□□□□□□□□□□□□□□□□□ AirScale □□□□□

□□□□ eNodeBs □□

□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□

□□□□ eNodeBs □□□□□□□

- □□□□□□□□□□
- □□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□

□□□□□

□□ ID

- □□□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□ ID

□□□□□□□

- □□□□□□□□□□□□□
- □□□□□□□□□□□□□□□

□□□□

- □□□□□□□□□□
- □□□□□□□□□□□□□□□

□□□□

- □□□□□□□□□□□□□
- □□□□□□□□□

□□□□□

□□

- □□□□□□□□□□□□□□
- □□□□□□□□□□□

□□

- □□□□□□□□□□
- □□□□□□□□/□□□□□

□□□□

- □□□□□□□□□□□□□
- □□□□□□□

□□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□

1. □□□□□□□□ **ID**
2. □□□□□□□□□ `config/runtime.exs` □□

```
airscales: [
  %{
    address: "10.7.15.66",
    name: "Site-A-BS1",
    port: "8080",
    web_username: "admin",
    web_password: "password"
  }
]
```

3. □□ **RAN** □□ □□□□□□□□

□□□□□□□□□□□□□□□ □□□□□□□□□

□□

- □□□□□□ □□□□□□□□□□□□□
- □□□□□ □□□□□□□□□□□□
- □□□ □□□□□□□□□□□□□
- □□□ □□□□□□□□□□□□□□□□

□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□

□□□□□□□□□

- □□ - □□□□□□□
- □□ - □□□□□□□□□
- □□ - □□□□
- □□ - □□□□
- □□ - □□□□
- □□ - □□□□□
- □□ - □□□□□
- □□ - □□□□□□

□□□ □□□□□□□□□□□□□□□□□□□□□□□□□

□□

□□□□□□□

- □□□□□□□□□□□□□□□□

- □□□□□□□□□ 500 □□□□
- □□□□□□□□

□□□

- □□/□□ - □□□□□□□□□□□□□□□
- ���□ - □□□□□□□□□□□□
- □□□□ - □□□□□□□□□□□□□□□□□□

□□□□□

- □□ - □□/□□/□□□□
- □□□ - □□□□
- □□ - □□□□
- □□ - □□□□
- □□ - □□□□
- □□ - □□□□

□□

□□□□□□□□□□

- □□□□□□□□□□
- □□□□□□□□ IP □□
- □□□□□□□□□

□□□□□□□

- □□□□□□□□□□□□□□□□□
- □□□□□□□□□
- □□□□□□□□□

□□□□□

- □□□□□□□□□
- □□□□□□□
- □□□□□□□

完成后恢复到信息级别

调查故障：

搜索错误消息和堆栈跟踪
查看故障时间附近的时间戳
与设备事件关联

最佳实践

在查看特定错误序列时使用暂停
设置适当的日志级别：
生产使用信息级
故障排除使用调试级
安静生产使用警告级
有效搜索 使用设备名称或错误关键字
日志级别更改在应用程序重启之前保持

数据保留政策页面

管理每个基站在 InfluxDB 中存储数据的时间长度。

全局设置显示

默认保留期

系统范围内的保留政策（小时/天）
在 config/config.exs 中配置默认：720 小时（30 天）

总记录数

所有设备的所有数据点计数
在页面刷新时更新

□□□□□□□

- □□□□□□□□□□□□
- □□□□□□□□□

□□□□□

□□□□□□□□□□□□

□□□□□□

- □□□□□
- □□□□□□□□□□/□□□□□
- □□□□□□□□□

□□□□□□

- □□□□□ - □□□□ PM □□□□□□
- □□ - □□□□□□□□□□
- □□ - □□□□□□□□□□□□
- □□ - □□□□□□□□□□□

□□□

- □□□□□□ - □□□□□□□□□□□□□□□□□□
- □□□□□□ - □□□□□□□□□□□□
- □□□□□□□ - □□□□□□□□□□□□□□□□□

□□□□□□

1. □□□□□ - □□□□□□□□□□□□□□□□□□
2. □□□□□□ - □□□□□□□□□□□□□□□□□
3. □□□□□ - □□□□□□□□□□□□□□□□□
4. □□□□□ - □□“□□□□□”□□□□□□

□□□□□

- **720** □□□**30** □□ - □□□□□□
- **2160** □□□**90** □□ - □□□□□□□□□□
- **4320** □□□**180** □□ - □□□□□□□
- **8760** □□□**365** □□ - ���□□□□□

□□

- □□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□□
- □□□□□□□□□□□
- □□ InfluxDB □□□□□□

□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□ □□□□□□□□□□

InfluxDB □□□□

□□□□ InfluxDB □□□□□□□□□□□□□□□□

URL: `https://<ran-monitor-ip>:9443/nokia/influx`

□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ InfluxDB □□□□□

□□□□

□□	□□
□□□□	□□□□□□□□□□□□□□□□
□□□	□□□ InfluxDB □□□□□
InfluxDB □□	□□□□□□□□□□□2.x□

□□□□□□

□□□□□□□□□□□□□□□□□

□□	□□
□□□□	□□□□□□□ PM □□□
□□	□□□□□□□□
□□	□□□□□□□□□□
□□	□□□□□□□□□

□□□□□□□□

□□□□□□□□□□ InfluxDB □□□□□□□□□□□□□□□□□

□□	□□
□□□□	□□□□□□□□□□□□□□□□□

□□	□□
□□□	□□□□□□□ InfluxDB □□□□□
□□□□	□□□□□□□□□□
□□	□□□□□□□□□□□□□□□□
□□□□	□□ InfluxDB □□□□□
□□□	□□□□□□□□KB/s □ MB/s□
□□□□□□□□□	□□□□□□□□□□□□□□□
□□□□	□□□□□□□□□□□□

□□□□□ □□□□□□□□□□□□□□□□

□□□□□□

□□	□□
□□	InfluxDB □□□□□□□
□□	InfluxDB □□□□□□□□□□□8086□
□□□	InfluxDB □□□□□□
□□	□□□□□□□
□□	□□□□□□□□□3□PerformanceMetrics□Configuration□Alarms□

□□□□

□□□□□□□□□□□□□□

- **InfluxDB** □□□ - □□□□□□□□□□□
- □□□□ - □□□□□□□□□□
- □□□□ - □□□□□□□□□
- □□□□ - □□□□□□□□

□□□□

□□□ 30 □□□□□□□

□□□□

□□	□□
□□ + □□□□□□□	□□□□□□□
□□ + □□□	□□□□□□□□ PM □□□□□
□□□	□□ InfluxDB □□□□□□□□□□□□
□□□□□□□□□/□□□	InfluxDB □□□□□□□□□□□□
□□□□□	□□□□ - □□□□□□□□□□□□□□□
□□□□	□□ - □□□□□□□□□

□□

- □□ InfluxDB □□□□□□□□
- □□□□□□□□□□□□□□□□□
- □□□□□□□□□□□
- □□□□□□□□□□□□□
- □□□□□□□□□

□□□□□□

□□□□ InfluxDB □□□□□□□□□□□□□□□□□

URL: `https://<ran-monitor-ip>:9443/nokia/metrics`

□□ InfluxDB □□□□□□□□□□□□□ Airscale □□□□□□□□□□□□

InfluxDB □□□□□□

□□□□□□□□□□□□□□□□□

□□	□□
□□□□	□□□□□ InfluxDB □□□□□□
□□□□	□□□□□□□□□□□□□
□□□□	□□ InfluxDB □□□□□□
□□□□	□□□□□□□□□□□□□□□

□ Airscale □ InfluxDB □□□□□□

□□□ InfluxDB □□□□□□□□□□□

□	□□
Airscale	□□□□
□□□□	□□□ PM □□□□□
□□	□□□□□□□□□□
□□	□□□□□□□□□□
□□□	□□□□□□□□□□□
□□□□	□□□□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□

□□□□

Erlang VM □□□□□□

□□	□□
□□□	□□□ Erlang VM □□□□
□□□□	Erlang □□□□□□□
□□□□□	□□□□□□□□□□□□□XML□JSON □□□
□□□□	□□□□□□□
□□□□	□□ Erlang □□□□□
□□□□	□□ CPU □□□□□□□□□0 □□□□

□□□□

□□□ 5 □□□□□□□

□□

- □□□□□□□□□□□□□□□□□□
- □□□□□□□□□□
- □□□□□□□□□□□
- □□□□□□□□□□□
- □□□□□□□□□□□

PM □□□□□□

□□□□□ InfluxDB □□□□□□□□PM□□□□□Nokia AirScale □□□□□□ 22,000 □□□□ PM □□□□□□□□□□□□□□□□

URL: `https://<ran-monitor-ip>:9443/nokia/pm-filters`

□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ PM □□□□□□□

PM □□□□□□



□□□□□□□□□“□□□ PM □□”□□□□□□□ PM □□□□□□□□□□

□□□

- □□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□
- □□□□□□□□ `pm_counters.csv` □□□□□□□

□□□□□□□□

□□□□□□□□ Nokia PM □□□□□□□□□□

□□□□

- ××□□□ ID □□□□□□□□□□□□□
- □□□□□□□□□□□□

□□□

- □□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□□□□□□□ 200 □□

□□□□□

□□	□□□□	□□
LTE	M8xxx	LTE L1/L2/L3 □□□
WCDMA	M5xxx	3G WCDMA □□□
5G-NR	M55xxx	5G NR □□□
5G-□□□	M51xxx	5G □□□□□
5G-□□	M40xxx	5G □□□□□

□□□

□□□

- □□□□□□□ □ `priv/pm_filters.etf` □
- □□□□□□□□□□□
- □□□□□□□□□□□

□□□□□□

InfluxDB □□□□□□□□□□□□□□□

- **PM** □□□□□□□ PM □□□□□□□□□□□
- □□□□□□□□□□□□□/□□□□□□□□

□□□□□□□□□□□□□□□□□ PM □□□□□□□□

□□□□□□

□□ Nokia AirScale □□□□□□□□□□□□□□

URL: `https://<ran-monitor-ip>:9443/nokia/firmware`

□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□□ RAN □□□□□ WebEM □“□□□□□”□□□□□□□□ HTTP URL □□□□□□□

□□□□

□□	□□
□□	□□ Nokia AirScale .zip □□□
□□ **URL**	□□□□ WebEM □□□□□□□□ HTTP URL
MD5 □□□	□□□□□□□□□□□□□□□□
□□□□	□□□□□□□□□□

□□□□□□

1. □□□□□□□□ RAN □□
2. □□ □□ **URL** □□□□□□ URL
3. □ WebEM □□□□□□□□□ □□□□□□
4. □□ URL □□□ □□□□□□
5. □□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□□ □□□□□□□□

□□□□□□□

□□□□□□□□□□□□□□□□□□□□

URL: `https://<ran-monitor-ip>:9443/nokia/data`

□□ ETS □□□□□□□□□ InfluxDB □□□□□□□□□□□□□□□□□

ETS □□□□□□□

□□□□□□□□□□□□□□□□□□□□□

□□	□□
Nokia □□□□	□□□□□□□□□□
Nokia □□□□	□□□□□□□□□□
□□□□□□□	□□□□□□□□□□□□
InfluxDB □□□□	□□□ InfluxDB □□□□

□□□□ **ETS** □□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□

□□□□□□□□□□□□□□□□□□

- □□□□□□□□□ TAR □□
- □□□□□□□□□□□□□

□□□□□□□□ □ `/tmp` □□□□□□□□□□□

InfluxDB □□□□□□

□□□ InfluxDB □□□□□□□□□□□□□□□□

- □□□□□PM □□□□
- □□□□
- □□□□

□□□□□□ □□“□□□□”□□□□□□□□□□□□□□ InfluxDB □□□

□□□□□ □□□□□□□□□ InfluxDB □□□□□□□□□

□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□ `config/runtime.exs` □□□□□□□□ ETS □□

□□

- □□□□□□□□□□□□
- □□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□
- □□□□□□□□□□□□

Web UI □□□

□□ Web UI □□□□□□□□□□

□□□□□□□

□□□□ □□□□□□□□□□□□□□□

□□□□

1. □□□□□□□
2. □□□□□□□□□□□□□□□
3. □□□□□□□□□□□□
4. □□□□□□□□/□□□□□□
5. □□□□□□□□□□□□
6. □□□□□□□□□□□

□□□ < 5 □□

□□□□□

□□□□ □□□□□□□□□

□□□□

1. □□□□□□□
2. □□□□□□□□□□□□□□□
3. □□□□□□□□□□□□□□□□
4. □□□□□□□□□□□
5. □□□□□□□□□□□□
6. □□□□□□□□□
7. □□□□□□□□
8. □□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□ □□□□□□□□□

□□□□

□□□□ □□□□□□□□□□

□□□□

1. □□□□□□□□□□□□□
2. □□□□□□□□□□□□□□□□□
3. □□□□□□□□□□□□
4. □□□□□□□□□ ID
5. □□□□□ ID □□□□□
6. □□□□□□□□□□□□□□□
7. □□□□□□□□□□□
8. □□□□□□□□□ 15-30 □□
9. □□□□□□□□□□□□□□□

□□□□□□□□□

- □□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□□□□
- □□□□□□□□□
- □□□□□□□□

□□□□□

□□□ □□□□□□□□□□□□□□□

□□□

1. □□□□□□□ eNodeBs □□□□□□□□
2. □□□□ ID □ IP □□
3. □□□□□□□ `config/runtime.exs`
4. □□ RAN □□□□□□□
5. □□□□□□□□□□□□
6. □□□□□□□□□□□□□
7. □□□□□□□□□ InfluxDB
8. □□□□□□□□□□□□
9. □□□ Grafana □□□

□□□□□□□□□□ □□□□□□□□

□□□□□□□□□

□□□ □□□□□□□□□□□□□

□□□

1. □□□□□□□□□□□□□□□
2. □□□□□□/□□□□□□□□□□□□□□□□
3. □□□□□□□□□□□□□□□
4. □□□□□□□□□□□□□□□
5. □□□□□□□□ping □□□
6. □□□□□□□□□
7. □□□□□□□□□□□□□□□□□□
8. □□□□□□□□□□□□□□
9. □□□□□□□□□□□□□
10. □□□□□□□

□□□□□□□□□□□□□ □□□□□□□□

□□□□

- □□□□ - □□□□□□□□
- □□□□□□□ - □□□□□□□
- □□□□□□□ - □□□□□□□□
- □□□□□□□□ - □□□□
- **Grafana** □□□□ - □□□□□□□
- □□□□□□□□□ - □□□□□□□□□
- □□□□□□□ - □□□□□□□□□

RAN □□□□□□

□□□□□□□ **(RAN)** □□□□□□□□

□ Omnitouch □□□□□□

□□

1. □□
2. RAN □□□□□
3. □□□□
4. Web UI □□
5. □□ Grafana □□□□
6. □□□□
7. □□□□
8. □□□□
9. □□

□□

RAN □□□□□□□ Nokia AirScale □□□ 3GPP LTE □ 5G □□□□□□□□□□□□□□□□□□□□ RAN □□□□ □□□□□□□□□□□□□□□□

□□□□

- □□□□ - □□□□□□□□□□□□
- □□□□□ - □□□□□□□□□□
- □□□□ - □□□□□□□□□□□□□□□□□□
- **Web** □□□ - □□□□ Web UI □□□□□□□□□□
- **Grafana** □□ - □□□□□□□□□□□□

□□□□

□□	□□	□□
RAN □□□□□	���□□□□□□□□□□□	□□□□
Web UI □□□	□□□□□□□	https://<server>:9443
MySQL □□	□□□□□□□□□	□□
InfluxDB	□□□□□□□□	http://<server>:8086
Grafana	□□□□□□□□	http://<server>:3000
TCE NSNTI □□	□□□□□□□	TCP □□ 49151
TCE TZSP □□	□□□□□□□ Wireshark	UDP □□ 37008

□□□□□□□□□□

*□□□□□□□□□□ LNMME □ S1 □□□□□□□□□□□□□□□□□□□ UE□□□ PRB □□□□□□□□□□□□□□□□□□□

RAN □□□□□

RAN □□□□□□□□□□□□□

1. □□□□□□ - □□□ Nokia □□□□□□□□□
2. □□□□□□□ - □ 10 □□□□□□ KPI□□□□□□
3. □□□□□ - □□□□□□□□□□□
4. □□□□□ - □□□□□□□□□□□□
5. □□□□□□□ - □□□□□□□□□□□□□□□
6. □□□□□□ - □□ Web UI □ Grafana □□□□□□□

□□□


OmniCharge
OmniRAN
Downloads
□□□□
Omnitouch Website
□□□□□□□
□□□□□□□□
□□□□□□
loop
[□ 10 □]
□□□□□□□□
□□□□□
□□□□□
loop
[□ 10 □]
□□□□□
□□□□□
□□□□□
loop
[□ 1 □□]
□□□□□
□□ XML
□□□□□□□□□□□□□□□□□□
□□□□□□□□
□□□□□
□□
RAN □□
□□□□
Web UI/Grafana

□□□□□

□□□□□

- □□□□□□□□□□□□□□
- □□□□□□□□□□/□□□
- □□□□□□□PRB □□□
- □□□□□□□□
- □□□□
- □□□□□□□

□□□

- □□□□□□□□□□□□□□□□□□□□□□
- □□□□□□□□□□
- □□□□□□□□□
- □□□□□□□□□

□□□

- □□□ XML □□□□□□□□□□□□□□□
- □□□□□□□□□□□□
- ◆◆□□□□□□□□
- □□□□□□□□□ 10 □□□

□□□□□□□□□□□□□□□□ □□□□□□□□

□□□□□□□□□□□□□□□ Nokia □□□□□□

□□□□

□□□□□□□


RAN □□□□
Nokia AirScale
□□ 1
Nokia AirScale
□□ 2
Nokia AirScale
□□ N...
Web UI
□□□□
Grafana
□□□□□□
RAN □□
□□□□
InfluxDB
□□□□
MySQL □□□
□□□□

❓❓□□□


RAN □□□□
Nokia AirScale
□□ 1
Nokia AirScale
□□ 2
Nokia AirScale
□□ N...
□□□□□
Web UI
□□□□
Grafana
□□□□□□
RAN □□□□
RAN □□
□□□□
MySQL □□□
□□□□
InfluxDB
□□□□

□□□□□□□□□□□□□□□□ □□□□□□□□□

跟踪收集实体 (TCE)

RAN 监控包括一个集成的跟踪收集实体，用于捕获和分析 LTE/5G 协议消息。这使得详细故障排除、驱动测试和 RF 优化成为可能。

什么是 TCE？

跟踪收集实体接收来自 Nokia AirScale 基站的跟踪数据，包含：

S1-AP 消息 - eNodeB 和 EPC 之间的控制平面信令
RRC 消息 - 无线资源控制信令
NAS 消息 - 非接入层信令
用户平面数据 - PDCP 层吞吐量信息

用例

驱动测试：

捕获终端用户 RF 体验
分析切换性能
测量信号质量（RSRP、RSRQ、SINR）
识别覆盖盲区

故障排除：

调试呼叫设置失败
分析切换问题
调查掉话
审查移动事件

RF 优化：

PCI 规划验证
邻接关系优化
切换参数调整
覆盖和容量分析

有关完整的跟踪收集程序和 Wireshark 分析，请参见 TCE MDT 数据收集指南。

Web UI □□

RAN □□□□□□□□□□ Web UI□□□□□□□□□□□□□□□□

□□□ `https://<ran-monitor-ip>:9443`

□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□

□□□□

□□□□□□□□□□□□

- □□□□□□□
- □□□□□□□□□□□/□□□□□□
- □□□□□□□□□□□□□□□
- □□□□□□□□

□ **5** □□□□□□□□□□□□□□□□

□□□□

□□□□□□□□□□□□□□□□□

- □□□□□□□□ = □□□□□□ = □□□
- □□□□□□□□□□
- □□□□□□□□
- □□□□□□□□□□□

□□□□□□□□□□□□□□□□□□□

警报页面

监控网络中的所有故障：

按严重性分类的颜色编码（红色 = 关键，橙色 = 主要，黄色 = 次要，蓝色 = 警告，绿色 = 已清除）
警报详情、可能原因、受影响系统
时间戳和持续时间跟踪
按严重性排序和过滤功能

有关警报处理程序的详细信息，请参见 警报管理指南。

□□□□

□□□□□□□□□□

1. □□ □□□□□□□□□
2. □□ □□□ → □□□□ ID
3. □□ □□□□ ID □□□
4. □□ □□□□□□
5. □□ □□□□□

□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□ □□□□□□□□□□□□□□□□□□□□

□□□□ eNodeB

□□□□□□□□□□□□□□□□□

- □□ ID□□□□□□□□□□
- □□□□□□
- □□□□□□
- □□□□□□□□□□□□□□

□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□ ID □□□□□□ `config/runtime.exs`□

应用日志

实时日志仪表板用于故障排除：

按日志级别过滤（紧急到调试）
在所有消息中搜索
暂停/恢复实时流
动态更改系统日志级别
按严重性颜色编码

有关故障排除程序的详细信息，请参见 故障排除指南。

数据保留政策

管理数据在 InfluxDB 中存储的时间：

查看全局保留政策和总记录计数
设置每个设备的保留期限
按测量类型查看记录计数（性能指标、配置、警报）
手动触发清理或清除设备的所有数据

有关完整的数据保留信息，请参见 数据保留政策指南。

InfluxDB □□

□□□□□□□□□□□□□□

- □□□□□□□□
- □□□□□□□□□
- □□□□
- □□□□□□□□□
- □ 5 □□□□□□□

□□□□□□□

- □□ + □□□□ = □□□□
- □□ + □□□ = □□□□□□
- □□□ = □□ InfluxDB □□□

完整的 Web UI 指南

有关全面的 Web UI 文档，包括所有功能、工作流程和最佳实践，请参见：
Web UI 指南 - 完整控制面板参考

使用 Grafana 进行监控

虽然 Web UI 提供实时可见性，但 Grafana 使深度历史分析和自定义仪表板成为可能。

为什么使用 Grafana？

Grafana 最适合：
几天/几周/几个月的历史趋势分析
根据您的需求量身定制的 KPI 仪表板
长期容量规划
模式识别和异常检测

- □□□□□ SLA □□
- □□□□□□□□□□□□

Web UI □□□□

- □□□□□□□□□
- □□□□□□□
- □□□□
- □□□□□□□
- □□□□□□□

□□ Grafana □□□□□□□□□□□□□□□□□□□□□□□□

□□□□□

□□□□□□□□□

- □□□□□□□□□□
- □□□□□□□□□□□□□
- □□□□□□□□□□□□□
- □□□□□□□□□□□
- □□□□□□□

NOC □□□□□□□

- □□□□□□□□
- □□□□□□□□
- □□□□□□□□ 24 □□□
- □□□□□□
- □□□□□□□□□

□□□□□□□□□□□

- □□□□□□□
- □□□□□□□□SINR□RSRP □□□
- □□□□□□RLC □□□RRC □□□□□
- □□□□□□□
- □□□□□□

Nokia AirScale □□□□□□

- PRB □□□□□□□/□□□
- □□□□□□□PDCP □□
- □□ UE □□
- □□□□□□□□
- □□□□□□□□□□
- RSSI □□
- RRC □□□□□□□
- □□□□ VSWR
- □□

□□□□□□□□□□□

常见操作

日常操作

每日健康检查（5-10 分钟）：

1. 打开 Web UI 仪表板
2. 验证所有设备显示绿色状态
3. 检查警报计数和严重性
4. 审查任何失败的设备
5. 根据需要调查问题

有关详细程序，请参见 Web UI 指南 - 工作流程。

警报调查：

1. 打开警报页面，按严重性排序
2. 点击警报以获取完整详情
3. 导航到受影响的设备
4. 与指标交叉参考
5. 确定所需操作并解决

有关警报处理程序的详细信息，请参见 警报管理指南。

设备管理

添加新基站：

1. 验证设备的网络连接
2. 检查未配置的 eNodeB 页面以查找设备
3. 将设备添加到 config/runtime.exs
4. 重启 RAN 监控
5. 验证注册成功（绿色状态）
6. 确认指标流向 InfluxDB

移除基站：

1. □□□□□□□□□□□□□□□□
2. □ `config/runtime.exs` □□□□□□□□□□
3. □□□□□□□□□□□□□□□□□□
4. □□ RAN □□
5. □□ Grafana □□□

□□□□□□□□

1. □□□□□□□□□□
2. □ `config/runtime.exs` □□□□□□
3. □□ RAN □□
4. □□□□□□□□□□

□□□□□□□□□□□□□□□□□□

□□□□□□□ - □□□□□□□

□□□□

□□□□□□□□□□□□□□

1. □□ □□□□□□□□□ - □□□□□□□□□□
2. □□ □□□□
3. □□ □□□ → □□□□ ID
4. □□ □□□□ ID → □□□□□
5. □□ □□□□□□
6. □□ □□□□□
7. □□ □□□□□ 15-30 □□
8. □□ □□□□□□□□□□□□□1 □□□□

□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□ AirScale □□□□□

□□□□□□□□□□□□□□□ □□□□□□□

□□□□

RAN □□□□□□□□□□□□□□

□□□□□□□NOC□□□□□

□□	□□	□□□□
Web UI □□	□□□□□□□□	□□□□□□□□□
□□□□□□	□□□□□□	□□□□□□□□□□□□
□□□□□□	□□□□□□□□	□□□□□□□□□□□□
□□□□□□	□□□□□□	□□□□□□□□□□□
□□□□□□	□□□□□□□	□□□□□□□□□
□□□□□□	□□□□□□	□□□□□□□□□□□□
□□□□□□□□	□□□□□□□□	□□□□□□□□□□□□

□□□□□□□

□□	□□	□□□□
Grafana □□□□	□□□□□□□□□	□□□□□□□□□□
Nokia □□□□	□□□□□□□	□□□□□□□□□
AirScale □□□	□□□□□□□	□□□□□□□□□
TCE MDT □□□□□	MDT □□□□□ Wireshark □□	□□□□□□□□□□□□□□
API □□□	REST API □□	□□□□□□□□□

□□□□□□□

□□	□□	□□□□
□□□□□□□□	□□□□□□□	□□□□□□□□□□

□□□□

□□□ RAN □□□

1. □ Web UI □□ □□□□□□□
2. □□ □□□□□□□ □□□□□□□□
3. □□ □□□□□□□ □□□□□□
4. □□ □□□□□□□ □□□□□□□□□□

□□□□□

1. □□ Grafana □□□□ □□□□□□□
2. □□ Nokia □□□□□ □□□□□
3. □□ □□□□□□□□□ □□□□□□□□

□□□□

□□□

□□	**URL**	□□
Web UI □□□	`https://<server>:9443`	□□□□□□□□
Grafana	`http://<server>:3000`	□□□□□□□□□
InfluxDB	`http://<server>:8086`	□□□□□□□□□□□□□□□□

□□□□

□□	□□
`config/runtime.exs`	□□□□□□□□□□□□□□□□□□□□
`priv/cert/`	□□ HTTPS Web UI □ SSL □□
`priv/external/nokia/`	□□□□□□□□□□
`priv/airscale_configs/`	□□□□□□□□□□ XML □□□

□□□□

□□□□□

- RAN □□□□□□□□□
- □□□□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□ 30 □□
- □□□□□□□□ MySQL □□□□

□□□□

- □ 10 □□□□□□□□□□□□□
- □ 10 □□□□□ + □□ Webhook □□□□
- □ 1 □□□□□□□□□□□□□□□□□□□□□□□□□□□□□
- □□□□□□□□□□ InfluxDB □□□□□□□□

□□□□□

- □□□□□720 □□□30 □□
- □□□□□□□□□□
- □□□□□□□□□□
- □□ Web UI □□□□□

□□□□□□□□□□□□□ □□□□□□□□□

常见工作流程

每日健康检查：

1. 打开 Web UI → 仪表板
2. 检查设备状态（全部为绿色？）
3. 审查警报计数
4. 调查任何问题

响应关键警报：

1. Web UI → 警报 → 按严重性排序
2. 点击警报以获取详细信息
3. 导航到设备
4. 审查最近的指标和配置更改
5. 实施解决方案
6. 验证警报已清除

添加新设备：

1. 验证网络连接
2. 编辑 config/runtime.exs
3. 将设备添加到 AirScale 列表
4. 重启 RAN 监控
5. 验证注册（绿色状态）

□□

□□□□□□□

□□	□□
□□□□□□□	□□□□□□□□□□
□□□□□□□	□□□□□□□□□□
□□□□□□□	□□□□□□□□□□
InfluxDB □□□□	□□□□□□□

□□□□□□□

□□□□□□□

1. □□□□□□□ → □□□□
2. □□□□□□□□ `ping <device-ip>`
3. □□ `config/runtime.exs` □□□□
4. □□□□□□□□□□□□

Grafana □□□□□□

1. □□□□□□□□□□□□□□□□□□
2. □□ InfluxDB □□□□□□□□□□
3. □□ InfluxDB □□□
4. □□ Grafana □□□□□

Web UI □□□□□

1. □□□□ 9443 □□□□□
2. □□□□□□□□□ HTTPS □□
3. □□ SSL □□□□□□
4. □□□□□□□□□ Web UI □□□□

有关完整的故障排除程序，请参见 故障排除指南。

获取帮助

在联系支持之前：

收集以下信息：

问题描述及其开始时间
应用日志中的错误消息
受影响的设备（名称/IP）
最近的配置更改
RAN 监控版本和操作系统

联系：

有关 RAN 监控的帮助：

Omnitouch 网络服务支持
包括收集的诊断信息
提供配置文件（清除密码）
包括相关日志摘录

自助服务：

1. 搜索 故障排除指南
2. 检查应用日志以获取特定错误
3. 审查最近的配置更改
4. 测试连接性和基本功能
5. 查阅相关文档指南

□□□□


□□□□
(□□□)
□□□□
□□
□□
□□□□
Web UI □□
□□□□□□□
□□□□□□
□□□□
□□□□□□□
□□□□
□□□□□□□
API □□
□□□□
□□□□□□□□
□□□□□□□
AirScale □□
□□□□
□□□□□□□
□□□□□□□□
Grafana □□□□
□□□□□□□
□□□□□□□
□□□□
Nokia □□□□□□
□□□□
□□□□□□□
□□□□